

Interior Panels Cut List

This cut list will produce paneling for two homes. Get 3 orange carts for this work.

Horizontal Cuts

Set up the panel saw for horizontal cuts. Using the templates, cut in this order and stack on a temporary cart:

Quantity	Height	Width
6	43 ½"	96"
4	44"	96"
7	38 ¼"	96"

Vertical Cuts

Set up the panel saw for vertical cuts. For each home, cut the following panels and mark each with the panel designator letter, and indicate the cut edge. Stack these panels on one cart per home in this order (back to front):

Width	Length	Label	Source
48"	88"	D	Uncut panel from plywood stack
38 ¼"	46 ¼"	E	Cut two E panels from one 38¼ x 96
48"	88"	G	Uncut panel from plywood stack
38 ¼"	88"	H	Temporary cart (thinnest panels); see below for cut-off.
44"	86 ½"	C	Temporary cart (widest panels)
48"	92"	A	Uncut panel from plywood stack
38 ¼"	92"	B	Temporary cart (thinnest panels)
44"	86 ½"	C	Temporary cart (widest panels)
48"	92"	A	Uncut panel from plywood stack
38 ¼"	92"	B	Temporary cart (thinnest panels)
43 ½"	44"	R2	Temporary cart (middle width panels)
43 ½"	44"	R2	Remainder from previous R2
43 ½"	92"	R1	Temporary cart (middle width panels)
43 ½"	92"	R1	Temporary cart (middle width panels)

Table saw

The cut-off piece from the H panel above will be 38 ¼" by 8 ½". Rip two 4" pieces on the table saw, using the 4" Trim template. The two halves will be used on the left side of the door, under the D panel. Label them as "left of door" and put one on each cart. Extras can go in the standing short-materials bin by the long-materials shelves.