Home Assistant

Make your home come alive with Home Assistant

Sibrecht Goudsmedt

What to talk about?

- How I started
- What is Home Assistant?
- What integrations?
- Tips
- MQTT Intermezzo
- Do It Yourself



How I Started


- Arduino Web Server Arduino
- Php Server and C# interface Laptop
- C# server with http 2 Laptops
- C# server with mqtt 2 Laptops
- Python server Rpi & Laptop
- Home Assistant Nuc & Telegram





What is Home Assistant?

- Domotica Software No Hardware
- Two weekly updates
 - Breaking changes!
- Integrations
 - v0.96 -> 1454 components
- Python 3.7
- Young: about 5 years
 - Big community



- Owntracks
- Google Home
- Telegram
- IKEA Tradfri
- MQTT & Arduino custom code
- Snapcast



OwnTracks - Location

- Turn everything off when no one home
- Automate only when home





- Owntracks
- Google Home
- Telegram
- IKEA Tradfri
- MQTT & Arduino custom code
- Snapcast




Google Home, Telegram &

Tradfri

Bedroom light control with google alarm

• Play music in some rooms

Control garage port






- Owntracks
- Google Home
- Telegram
- IKEA Tradfri
- MQTT & custom code/PCB
- Snapcast



MQTT & custom code/PCB

- Dmx protocol converter – light
- Garage port sensor and control
- Custom movement sensor
- Light/audio switch





- Owntracks
- Google Home
- Telegram
- IKEA Tradfri
- MQTT & Arduino custom code
- Snapcast



Snapcast

Snapcast

- Spotify
- Webradio
- Different rooms
- Synchronized in every room






Tips

Configuration validation

Validate your configuration if you recently made some changes to your configuration and want to make sure that it is all valid




1. Always check before YAML before restarting server

Configuration reloading

Some parts of Home Assistant can reload without requiring a restart. Hitting reload will unload their current configuration and load the new one.

RELOAD CORE RELOAD GROUPS RELOAD AUTOMATIONS RELOAD SCRIPTS



Control your Home Assistant server... from Home Assistant.

RESTART STOP



Tips


2. Try to split up the configuration.yaml file

```
automation: !include_dir_merge_list_automation
binary_sensor: !include dir merge list binary_sensor
#counter: !include dir merge named counters
cover: !include dir merge list covers
device_tracker: !include_dir_merge_list device_tracker
group: !include dir merge named group
input_boolean: !include dir merge named input boolean
light: !include dir merge list lights
#input_number: !include dir merge named input number
media_player: !include dir merge list mediaplayer
scene: !include_dir_merge_list scenes
script: !include dir merge named script
sensor: !include dir merge list sensor
switch: !include dir merge list switch
weather: !include weather.yaml
zone: !include_dir_merge_list zones
```




Tips

3. Use MQTTfx to view all MQTT messages.



MQTT Intermezzo



Do It Yourself

- https://github.com/sgoudsme/hass-intro
- Add MQTT light
- Download Telegram on smartphone
- Chat with the Botfather
 - Do all required steps
 - Get API key
- Chat with the userinfobot
 - Get your user id -> see configuration.yaml
- Insert ping pong example: https://www.home-assistant.io/components/telegram bot/
- Make commando to turn on/off mqtt light with Telegram
- Extra: find out how Hass uses the name of your telegram

MQTT light:

- Platform = mqtt
- Schema = json
- Cmd_tpc = "D2316/A/command"
 - With A = 1-2-3-4
- Enable brightness

