

Programming Manual for FDx SDK *Pro* for UNIX/Linux

For applications using SecuGen® fingerprint readers

SG1-0034A-003 (01/14)

© Copyright 1998-2014 SecuGen Corporation.

ALL RIGHTS RESERVED. Specifications are subject to change without notice. SecuGen, Auto-On, FDU03, FDU04, SDU03, SDU04, Smart Capture and U20 are trademarks or registered trademarks of SecuGen Corporation. All other brands or products may be trademarks, service marks or registered trademarks of their respective owners.

Contents

BEFORE YOU BEGIN		///
BIOMETRICS OVERVIEW	III	
ABOUT SECUGEN		
ABOUT SECUGEN PRODUCTS	IV	
CHAPTER 1. OVERVIEW		5
1.1. FEATURES		U
1.2. SYSTEM REQUIREMENTS	5 E	
		_
CHAPTER 2. INSTALLATION		6
2.1. INSTALLATION		
2.2. INCLUDED FILES		
CHAPTER 3. PROGRAMMING IN C/C++		8
3.1. CREATING SGFPM	8	
3.2. INITIALIZING SGFPM		
3.3. TERMINATING SGFPM	9	
3.4. OPENING THE SECUGEN FINGERPRINT READER	9	
3.5. GETTING DEVICE INFORMATION	9	
3.6. CAPTURING A FINGERPRINT IMAGE	10	
3.7. GETTING IMAGE QUALITY	10	
3.8. CONTROLLING BRIGHTNESS		
3.9. CREATING A TEMPLATE	11	
3.10. MATCHING TEMPLATES	12	
3.11. REGISTRATION PROCESS		
3.12. VERIFICATION PROCESS		
3.13. GETTING MATCHING SCORE	16	
3.14. USING AUTO-ON™		
3.15. TEMPLATE FORMAT		
3.16. MANIPULATING ANSI378 TEMPLATES		
3.17. MANIPULATING ISO19794-2 TEMPLATES	22	
3.18. GETTING VERSION INFORMATION OF MINEX COMPLIANT ALGORITHMS	24	
3. 10. GETTING VERSION INFORMATION OF MINEX COMPLIANT ALGORITHMS		
		25
CHAPTER 4. FUNCTION REFERENCE		25
CHAPTER 4. FUNCTION REFERENCE	25	25
CHAPTER 4. FUNCTION REFERENCE	25 25	25
CHAPTER 4. FUNCTION REFERENCE	25 25 26	25
CHAPTER 4. FUNCTION REFERENCE	25 25 26 30	25
CHAPTER 4. FUNCTION REFERENCE	25 25 26 30	25
CHAPTER 4. FUNCTION REFERENCE		25
CHAPTER 4. FUNCTION REFERENCE		25
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER		
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE.		
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM.		
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST.		
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO.		
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO.		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS.		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS. 6.1. SGFDXDEVICENAME.		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS 6.1. SGFDXDEVICENAME. 6.2. SGPPPORTADDR.		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION. 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS. 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS. 6.1. SGFDXDEVICENAME. 6.2. SGPPPORTADDR. 6.3. SGFDXSECURITYLEVEL		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER CHAPTER 5. STRUCTURE REFERENCE 5.1. SGDEVICEINFOPARAM 5.2. SGDEVICELIST 5.3. SGFINGERINFO 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS. 6.1. SGFDXDEVICENAME 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL 6.4. SGFDXTEMPLATEFORMAT 6.5. SGIMPRESSIONTYPE		40
CHAPTER 4. FUNCTION REFERENCE 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER CHAPTER 5. STRUCTURE REFERENCE 5.1. SGDEVICEINFOPARAM 5.2. SGDEVICELIST 5.3. SGFINGERINFO 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS 6.1. SGFDXDEVICENAME 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL 6.4. SGFDXTEMPLATEFORMAT 6.5. SGIMPRESSIONTYPE 6.6. SGFINGERPOSITION		40
CHAPTER 4. FUNCTION REFERENCE 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER CHAPTER 5. STRUCTURE REFERENCE 5.1. SGDEVICEINFOPARAM 5.2. SGDEVICEINFO 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS. 6.1. SGFDXDEVICENAME 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL 6.4. SGFDXTEMPLATEFORMAT 6.5. SGIMPRESSIONTYPE 6.6. SGFINGERPOSITION 6.7. SGFDXERRORCODE		40
CHAPTER 4. FUNCTION REFERENCE 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER CHAPTER 5. STRUCTURE REFERENCE 5.1. SGDEVICEINFOPARAM 5.2. SGDEVICELIST 5.3. SGFINGERINFO 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS 6.1. SGFDXDEVICENAME 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL 6.4. SGFDXTEMPLATEFORMAT 6.5. SGIMPRESSIONTYPE 6.6. SGFINGERPOSITION 6.7. SGFDXERRORCODE 6.8. OTHER CONSTANTS		40
CHAPTER 4. FUNCTION REFERENCE 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER CHAPTER 5. STRUCTURE REFERENCE 5.1. SGDEVICEINFOPARAM 5.2. SGDEVICELIST 5.3. SGFINGERINFO 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS 6.1. SGFDXDEVICENAME 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL 6.4. SGFDXTEMPLATEFORMAT 6.5. SGIMPRESSIONTYPE 6.6. SGFINGERPOSITION 6.7. SGFDXERRORCODE 6.8. OTHER CONSTANTS APPENDIX A. USING SGFPM OBJECTS DIRECTLY		40
CHAPTER 4. FUNCTION REFERENCE. 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION. 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS. 4.5. MATCHING FUNCTIONS. 4.6. FUNCTIONS FOR ANSI378 TEMPLATES. 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES. 4.8. OTHER. CHAPTER 5. STRUCTURE REFERENCE. 5.1. SGDEVICEINFOPARAM. 5.2. SGDEVICELIST. 5.3. SGFINGERINFO. 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS 6.1. SGFDXDEVICENAME. 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL. 6.4. SGFDXTEMPLATEFORMAT. 6.5. SGIMPRESSIONTYPE. 6.6. SGFINGERPOSITION. 6.7. SGFDXERRORCODE. 6.8. OTHER CONSTANTS APPENDIX A. USING SGFPM OBJECTS DIRECTLY. A.1. CREATING AN SGFPM OBJECT		40
CHAPTER 4. FUNCTION REFERENCE 4.1. SGFPM CREATION AND TERMINATION 4.2. INITIALIZATION 4.3. DEVICE AND CAPTURING FUNCTIONS 4.4. EXTRACTION FUNCTIONS 4.5. MATCHING FUNCTIONS 4.6. FUNCTIONS FOR ANSI378 TEMPLATES 4.7. FUNCTIONS FOR ISO19794-2 TEMPLATES 4.8. OTHER CHAPTER 5. STRUCTURE REFERENCE 5.1. SGDEVICEINFOPARAM 5.2. SGDEVICELIST 5.3. SGFINGERINFO 5.4. SGANSITEMPLATEINFO/SGISOTEMPLATEINFO CHAPTER 6. CONSTANTS 6.1. SGFDXDEVICENAME 6.2. SGPPPORTADDR 6.3. SGFDXSECURITYLEVEL 6.4. SGFDXTEMPLATEFORMAT 6.5. SGIMPRESSIONTYPE 6.6. SGFINGERPOSITION 6.7. SGFDXERRORCODE 6.8. OTHER CONSTANTS APPENDIX A. USING SGFPM OBJECTS DIRECTLY		43

Before You Begin

Biometrics Overview

Biometrics is an automated method of recognizing a person based on physical or behavioral characteristics. Biometric information that can be used to accurately identify people includes fingerprint, voice, face, iris, handwriting and hand geometry.

There are two key functions offered by a biometric system. One method is **identification**, a "one-to-many" matching process in which a biometric sample is compared sequentially to a set of stored samples to determine the closest match. The other is **verification**, a "one-to-one" matching process in which the biometric system checks previously enrolled data for a specific user to verify whether that individual is who he or she claims to be. The verification method provides the best combination of speed and security, especially where multiple users are concerned, and requires a user ID or other identifier for direct matching.

With an increasing reliance on online technology and other shared resources, the information age is quickly revolutionizing the way transactions are initiated and completed. Business transactions of all types are increasingly being handled online and remotely. This unprecedented growth in electronic transactions has underlined the need for a faster, more secure and more convenient method of user verification than passwords can provide.

Using biometric identifiers offers several advantages over traditional and current methods. This is because only biometric authentication is based on the identification of an intrinsic part of a human being. Tokens such as smart cards, magnetic stripe cards and physical keys, can be lost, stolen, duplicated or left behind. Passwords can be forgotten, shared, hacked or unintentionally observed by a third party. By eliminating all of these potential trouble spots, biometric technology can provide greater security, with convenience, needed for today's complex electronic landscape.

Advantages of Using Fingerprints

The advantages of using fingerprints include widespread public acceptance, convenience and reliability. It takes little time and effort to scan one's fingerprint with a fingerprint reader, and so fingerprint recognition is considered among the least intrusive of all biometric verification techniques. Ancient officials used thumbprints to seal documents thousands of years ago, and law enforcement agencies have been using fingerprint identification since the late 1800s. Fingerprints have been used so extensively and for so long, there is a great accumulation of scientific data supporting the idea that no two fingerprints are alike.

About SecuGen

SecuGen (www.secugen.com) provides biometric solutions for physical and network security employing advanced fingerprint recognition technology. The company's comprehensive product line includes high quality optical fingerprint readers and sensor component, software and development kits that are used for a variety of innovative applications including Internet, enterprise network and desktop security, physical access control, time and attendance management and financial and medical records control. SecuGen patented products feature the industry's longest warranty and are renowned for their accuracy, reliability and versatility. Based in Silicon Valley, SecuGen has been serving the global biometric community since 1998 and is an active member of the Biometrics Consortium (www.biometrics.org) and the BioAPI Consortium (www.bioapi.org).

About SecuGen Products

SecuGen Sensor Qualities

- **Excellent Image Quality:** Clear, distortion-free fingerprint images are generated using advanced, patent-pending optical methods. Quality imaging yields better sampling for minutiae data extraction.
- Durability: Mechanical strength tests show resistance to impact, shock and scratches.
- Powerful Software: Precise, fast processing algorithm ensures efficiency and reliability.
- Ruggedness and Versatility: Solid engineering and superior materials allows for use under extreme conditions.
- **Ergonomic Design:** Compact, modular design for seamless integration into small devices, ease of use and compatibility make it ideal for a broad range of applications.
- **Low Cost:** Products are developed to deliver high performance, zero maintenance at very affordable prices for general and industrial use.

Advantages of SecuGen Sensors Over Other Optical Sensors

- Unique optical method captures fine details, even from dry skin
- Extremely low image-distortion
- Reinforced materials
- Wear resistance
- Attractively small size
- Ease of integration
- Ready-to-use
- Low cost through longer life and no maintenance requirements

Advantages SecuGen Sensors Over Semiconductor (Capacitive) Sensors

- Non-metal, non-silicon components make it less susceptible to corrosion when exposed to salts, oil and moisture from skin and environment
- Superior surface properties eliminate need for costly coating and processing procedures
- · Greater mechanical strength, wear-resistance and durability
- · Broader range of applicability, especially for use in extreme conditions and climates
- Immunity from electrostatic discharge
- Low cost through longer life and no maintenance requirements

Strengths of SecuGen Software and Algorithms

- Unique image processing algorithm extracts fingerprint minutiae very accurately
- High signal-to-noise ratio processing algorithm screens out false features
- Highly efficient matching algorithm
- Fast overall process of extraction, matching and verification
- Encryption function to protect user privacy
- Compatibility with existing desktop, laptop PCs interface computers
- Ease in developing applications for various purposes

Chapter 1. Overview

SecuGen's FDx SDK *Pro* is designed to provide low level access to SecuGen's fingerprint readers using SecuGen's next-generation algorithm module. Programming with SecuGen's FDx SDK *Pro* is simple and easy to program and gives the most development flexibility among all SecuGen SDKs.

1.1. Features

- Uses SecuGen's new and improved next-generation algorithms
- Supports three kinds of fingerprint minutiae formats (or templates):
 - SG400: SecuGen's proprietary fingerprint minutiae format
 - o ANSI378: Finger Minutiae Format for Data Exchange (ANSI-INCITS 378-2004)
 - o ISO19794-2: Biometric Data Interchange Formats--Finger Minutiae Data (ISO/IEC 19794-2:2005)
- Provides low-level APIs for image capture, feature extraction and matching
 - The following extraction and matching algorithms, which are incorporated in libsgfpamx.so in this SDK, support the ANSI-INCITS 378-2004 standard and have been tested and proven to be MINEX Compliant (http://fingerprint.nist.gov/MINEX/):
 - SecuGen ANSI INCITS 378 Template Generator v3.5 (feature extraction algorithm)
 - SecuGen ANSI INCITS 378 Template Matcher v3.5 (matching algorithm)
- Gives a high degree of flexibility to developers of all kinds of applications and is easy to use

1.2. System Requirements

SecuGen USB readers capture a fingerprint image and digitize the image to an 8-bit gray-scale image at 500 DPI resolution. The host system then retrieves the image through its USB port for subsequent processing. The following SecuGen USB readers are supported:

- Hamster Plus
 - Based on all models of the FDU03-sensor class:
 HFDU03FR, HFDU03FRS, SDU03M, SDU03P
- Hamster IV
 - Based on all models of the FDU04 -sensor class: HFDU04, HSDU04P
- Hamster Pro 20
 - \circ Based on all models of the $\mbox{U20}$ -sensor class: $\mbox{U20}$

The following are the system requirements:

- IBM-compatible PC 486 or later
- 1 USB port (USB 2.0 required for FDU04 and U20-class readers)
- 64 MB RAM
- 80 MB available hard disk space
- Linux Kernel 2.6

Chapter 2. Installation

2.1. Installation

- 1. Unzip the FDx SDK Pro for UNIX/LINUX on your system.
- 2. Change directory to <installdir>/lib/target and run "make uninstall install"

2.2. Included Files

After unzipping the FDx SDK Pro for UNIX/LINUX, the following files are copied to your extraction directory (installdir).

<installdir>/readme.txt Latest information about current release

<installdir>/lib/target Runtime libraries
libsgfdu03.so FDU03 device driver
libsgfdu04.so FDU04 device driver
libsgfdu05.so FDU05 device driver

libsgfpamx.so Fingerprint algorithm module for extraction & matching (MINEX Compliant)

libsgfplib.so Main module

Makefile Makefile to install library files

<installdir>/bin/target directory Demo applications linked with either FDU03, FDU04 or FDU05 shared libraries

auto_on_fdu03
 auto_on_fdu04
 auto_on_fdu05
 Demo console application for auto on using FDU04
 Demo console application for auto on using FDU05

fpmatcher_fdu03 GTK+ Demo program for fingerprint capture, extract and match using FDU03 GTK+ Demo program for fingerprint capture, extract and match using FDU04 fpmatcher_fdu05 GTK+ Demo program for fingerprint capture, extract and match using FDU05

multidev_fdu03
multidev_fdu04
Demo console application for multiple device test using FDU03
multidev_fdu04
Demo console application for multiple device test using FDU04
Demo console application for multiple device test using FDU05
sgd2_fdu03
sgd2_fdu04
sgd2_fdu04
GTK+ Demo program for fingerprint capture using FDU04
sgd2_fdu05
GTK+ Demo program for fingerprint capture using FDU05

sgfplibtest_fdu03
 sgfplibtest_fdu04
 sgfplibtest_fdu04
 sgfplibtest_fdu05
 Demo console application for fingerprint capture, extract and match using FDU04
 sgfplibtest_fdu05
 Demo console application for fingerprint capture, extract and match using FDU05

test_auto_on_fdu03
 Driver console application for auto on fingerprint capture using FDU03
 test_auto_on_fdu04
 Driver console application for auto on fingerprint capture using FDU04
 test_auto_on_fdu05
 Driver console application for auto on fingerprint capture using FDU05

test_fdu03 Driver console application for fingerprint capture using FDU03
test_fdu04 Driver console application for fingerprint capture using FDU04
test_fdu05 Driver console application for fingerprint capture using FDU05

<installdir>/include directory
SDK library header file

sgfplib.h Declarations of function prototypes and structures used in the SDK

<installdir>/sgfplibtest Sample source code for sgfplibtest

<installdir>/sgd2
Sample source code for sgd2

<installdir>/fpmatcher Sample source code for fpmatcher

/usr/local/lib

Runtime modules installed by running "make uninstall install" in <installdir>/lib/target

libsgfdu03.soFDU03 device driverlibsgfdu04.soFDU04 device driverlibsgfdu05.soFDU05 device driver

libsgfpamx.so Fingerprint algorithm module for extraction & matching (MINEX Compliant)

libsgfplib.so Main module

Chapter 3. Programming in C/C++

SecuGen's FDx SDK *Pro* was designed for ease in programming and most flexibility for developers. All SDK functions are integrated into the **SGFPM** (**SecuGen FingerPrint Module**) class. The SGFPM class includes device initialization, fingerprint capture, minutiae extraction and matching functions. The developer can access SDK functions directly through the SGFPM class or through C functions that wrap the SGFPM class. C functions provide access to SDK functionalities through an SGFPM handle. In this chapter, C functions are explained. For direct access to the SGFPM class, refer to Appendix A.

3.1. Creating SGFPM

To use SGFPM, call **SGFPM_Create()**, which creates an SGFPM object and returns a handle to the SGFPM object. When calling **SGFPM_Create()**, pass a pointer to the handle to contain the SGFPM handle as a parameter. The SGFPM handle is used for the duration of the session to access other functions.

```
HSGFPM m_hFPM; // handle for SGFPM
DWORD err = SGFPM Create(&m hFPM);
```

3.2. Initializing SGFPM

If an SGFPM object is created, it should be initialized using SGFPM_Init() or SGFPM_InitEx(). SGFPM_Init() takes the device name, loads the driver that corresponds to the device name and initializes the fingerprint algorithm module based on device information. SGFPM_InitEx() takes image width, image height and resolution as parameters. Call SGFPM_InitEx() when using the fingerprint algorithm module without a SecuGen reader.

The table below summarizes the correlation among device name (device type), loaded device driver and initial image size when the **Init(SGFPMDeviceName devName)** function is called.

Device Name, Device Driver and Image Size

Device Name	Value	Device driver	Image Size (pixels)
SGDEV_FDU03	4	FDU03 / SDU03 USB driver	260*300
SGDEV_FDU04	5	FDU04 / SDU04 USB driver	258*336
SGDEV_FDU05	6	U20 USB driver	300*400

SGFPM_Init()

```
DWORD devname = SG_DEV_FDU03;
err = SGFPM Init(m hFPM, devname);
```

SGFPM_InitEx()

```
DWORD image_width = 260;
DWORD image_height = 300;
DOWRD image_dpi = 500;
err = SGFPM InitEx(m hFPM, image width, image height, image dpi);
```

3.3. Terminating SGFPM

SGFPM_Terminate() must be called prior to terminating the application. It frees up the memory used by the SGFPM object.

```
if (m_hFPM)
{
    SGFPM_Terminate(m_hFPM);
}
m hFPM = 0;
```

3.4. Opening the SecuGen Fingerprint Reader

To use a SecuGen fingerprint reader, call **SGFPM_OpenDevice()**. The second parameter (**devId**) of **SGFPM_OpenDevice()** can have different meanings depending on which type of fingerprint reader is used.

For USB readers, **devid** means device ID. If only one USB fingerprint reader is connected to the PC, **devid** will be 0. If multiple USB fingerprint readers are connected to one PC, **devid** can range from 0 to 9. The maximum number of SecuGen USB readers that can be connected to one PC is 10.

In general, if only one USB reader is connected to the PC, then 0 or USB_AUTO_DETECT is recommended.

```
DWORD devId = USB_AUTO_DETECT; // auto detect
err = SGFPM_OpenDevice(m_hFPM, devId);
```

3.5. Getting Device Information

Device information can be retrieved by calling **SGFPM_GetDeviceInfo()**, which obtains required device information such as image height and width. The device information is contained in the **SGDeviceInfoParam** structure. Refer to Chapter 5. Structure Reference for a detailed description of the **SGDeviceInfoParam** structure.

```
SGDeviceInfoParam device_info;
memset(&device_info, 0x00, sizeof(device_info));
error = SGFPM_GetDeviceInfo(m_hFPM, &device_info);

if (error == SGSGFDX_ERROR_NONE)
{
    m_DevID = device_info.DeviceID;

    m_DevSN = device_info.DeviceSN;
    m_ImgWidth = device_info.ImageWidth;
    m_ImgHeight = device_info.ImageHeight;
    m_Contrast = device_info.Contrast;
    m_Brightness = device_info.Brightness;
    m_Gain = device_info.Gain;
    m_ImageDPI = device_info.ImageDPI;
    char buffer[20];
    _ultoa(device_info.FWVersion, buffer, 16);
    m_FWVersion = CString(buffer);
}
```

3.6. Capturing a Fingerprint Image

After the reader is initialized, a fingerprint image can be captured. The SGFPM object provides three types of fingerprint image capture functions listed below. Captured fingerprints are 256 gray-level images, and image width and height can be retrieved by calling SGFPM_GetDeviceInfo(). The image buffer should be allocated by the calling application.

SGFPM_GetImage() captures an image without checking for the presence of a finger or checking image quality. **SGFPM_GetImageEx()** captures fingerprint images continuously, checks the image quality against a specified quality value and ignores the image if it does not contain a fingerprint or if the quality of the fingerprint is not acceptable. If a quality image is captured within the given time (the second parameter), **SGFPM_GetImageEx()** ends its processing. If a window handle is provided by the application, the drivers will draw a fingerprint image in the provided window using the handle value.

For more information about each of the following SGFPM image capture functions, refer to Chapter 4. Function Reference.

• SGFPM_GetImage()

```
[Example]
BYTE *buffer = new BYTE(m_ImageWidth*m_ImageHeight);

if (SGFPM_GetImage(m_hFPM, buffer) == SGSGFDX_ERROR_NONE) // Get image data from device {
    // Display image
    // Process image
}
delete [] buffer;
```

SGFPM_GetImageEx()

3.7. Getting Image Quality

To determine the fingerprint image quality, use GetImageQuality().

SGFPM_GetImageQuality()

```
DWORD img_qlty;
SGFPM_GetImageQuality(hFPM, ImageWidth, m_ImageHeight, fp_image, &mg_qlty);
if (img_qlty < 80)
// Capture again</pre>
```

3.8. Controlling Brightness

Depending on the fingerprint reader used, environmental factors and the specifications of the host system, the brightness of a fingerprint image may vary. To improve the quality of a captured image, the image brightness should be adjusted by changing the brightness setting of the reader using SGFPM_Configure() or SGFPM_SetBrightness(). Using SGFPM_Configure() presents a built-in dialog box in the driver from which the user can easily adjust brightness and receive instant feedback from the fingerprint image displayed. SGFPM_SetBrightness() can also be used to control brightness of the reader. Brightness default values vary among the different types of SecuGen readers.

• SGFPM_Configure()

```
HWND hwnd = 0;
SGFPM_SetBrightness(m_hFPM, hwnd); // Show device configuration box in the driver.
```

SGFPM_ SetBrightness()

```
SGFPM_SetBrightness(m_hFPM, 70); // Set from 0 to 100.
```

3.9. Creating a Template

To register or verify a fingerprint, a fingerprint image is first captured, and then feature data (minutiae) is extracted from the image into a **template**. Minutiae are the unique core points near the center of every fingerprint, such as ridges, ridge endings, bifurcations, valleys and whorls.

Use **SGFPM_CreateTemplate()** to extract minutiae from a fingerprint image to form a template. The buffer should be assigned by the application. To get the buffer size of the minutiae, call **SGFPM_GetMaxTemplateSize()**. It will return the maximum buffer size for data in one template. The actual template size can be obtained by calling **SGFPM_GetTemplateSize()** after the template is created. The **SGFPM_CreateTemplate()** API creates only one set of data from an image.

Note: Templates having the ANSI378 or ISO19794-2 format may be merged. For more information about template formats, refer to Section <u>Section 3.15</u>. <u>Template Format</u>. For more information about merging templates, refer to Section 3.16. Manipulating ANSI378 Templates and Section 3.17. Manipulating ISO19794-2 Templates.

SGFPM_CreateTemplate()

```
// Get a fingerprint image
DWORD qlty = 80;
err = SGFPM_GetImageEx(m_hFPM, m_ImgBuf, 5000, NULL, qlty);

// Create template from captured image
BYTE* minBuffer;
err = SGFPM_GetMaxTemplateSize(m_hFPM, &maxTemplateSize);
minBuffer = new BYTE[maxTemplateSize];

// Set information about template
SGFingerInfo finger_info;
finger_info.FingerNumber = GetFingerPos();
finger_info.ImageQuality = (WORD)qlty;
finger_info.ImpressionType = SG_IMPTYPE_LP;
finger_info.ViewNumber = 1;

err = SGFPM CreateTemplate(m hFPM, &finger info, m ImgBuf, minBuffer);
```

3.10. Matching Templates

Templates are matched during both registration and verification processes. During registration, it is recommended to capture at least two image samples per fingerprint for a higher degree of accuracy. The minutiae data from each image sample can then be compared against each other (i.e. matched) to confirm the quality of the registered fingerprints. This comparison is analogous to a password confirmation routine that is commonly required for entering a new password.

During verification, newly input minutiae data is compared against registered minutiae data. Similar to the registration process, verification requires the capture of a fingerprint image followed by extraction of the minutiae data from the captured image into a template.

To match templates, the FDx SDK *Pro* provides four kinds of matching functions. Each function requires two sets of template data for matching.

SGFPM_MatchTemplate(): This function matches templates having the same format as the default format. When calling this function, each template should include only one sample (or view) per template. The default format is SG400 (SecuGen proprietary format) but can be changed by calling SGFPM_SetTemplateFormat(). For more information about template formats, refer to Section 3.15. Template Format.

SGFPM_MatchTemplateEx(): This function can match templates having different template formats. This function can also specify the template format for each template and can match templates that have multiple views per template.

SGFPM_MatchAnsiTemplate(): This function is the same as **SGFPM_MatchTemplateEx()** except that it supports only ANSI378 templates.

SGFPM_MatchIsoTemplate(): This fucntion is the same as **SGFPM_MatchTemplateEx()** except that it supports only ISO19794-2 templates.

Function	Template Format	Can match templates with different formats?
SGFPM_MatchTemplate	SG400 (System default)	No
SGFPM_MatchTemplateEx	Specified template format	Yes
SGFPM_MatchAnsiTemplate	ANSI378	No
SGFPM_MatchIsoTemplate	ISO19794-2	No

SGFPM_MatchTemplate()

SGFPM_MatchTemplateEx()

```
BYTE*
       m RegTemplate1;
                            // Will contain SG400 template
BYTE*
        m RegTemplate2;
                             // Will contain ANSI378 template
// Make SG400 template
err = SGFPM SetTemplateFormat(m hFPM, TEMPLATE FORMAT SG400);
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, qlty);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m RegTemplate1);
// Make ANSI378 template
err = SGFPM SetTemplateFormat(m hFPM, TEMPLATE FORMAT ANSI378);
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, glty);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m RegTemplate2);
DWORD sl = SL NORMAL;
                            // Set security level as NORMAL
BOOL matched;
err = SGFPM MatchTemplateEx(m hFPM, m RegTemplate1,
                            TEMPLATE FORMAT SG400,
                                             // Must be 0 if template format is SG400
                            m_ RegTemplate2,
                            TEMPLATE FORMAT ANSI378,
                                            // Currently only one sample
                            sl,
                            &matched);
```

• SGFPM_MatchAnsiTemplate()

```
DWORD err;
BOOL matched = FALSE;
SGANSITemplateInfo sample info;
err = SGFPM GetAnsiTemplateInfo(m hFPM, m EnrollTemplate, &sample info);
matched = TRUE;
bool finger found = false;
for (int i = 0; i < sample info.TotalSamples; i++)</pre>
  if(sample info.SampleInfo[i].FingerNumber == finger pos) // Try match for same finger
    finger found = true;
   err = SGFPM MatchAnsiTemplate(m hFPM,
                                                m EnrollTemplate, i, m FetBufM,
                                                                                        0,
SecurityLevel[m SecureLevel.GetCurSel()], &matched);
   if (!matched)
     break;
  }
```

SGFPM_MatchIsoTemplate()

```
DWORD err;
BOOL matched = FALSE;

// ISO19794-2
SGISOTemplateInfo sample_info = {0};
err = SGFPM_GetIsoTemplateInfo(m_hFPM, m_StoredTemplate, &sample_info);

matched = FALSE;
int found_finger = -1;
for (int i = 0; i < sample info.TotalSamples; i++)</pre>
```

```
{
    // ISO19794-2
    err = SGFPM_MatchIsoTemplate(m_hFPM, m_StoredTemplate, i, m_FetBufM, 0, SL_NORMAL,
&matched);
    if (matched)
    {
        found_finger = sample_info.SampleInfo[i].FingerNumber;
        break;
    }
}
```

3.11. Registration process

To register a fingerprint, a fingerprint image is first captured, and then feature data (minutiae) is extracted from the image into a template. It is recommended to capture at least two image samples per fingerprint for a higher degree of accuracy. The minutiae data from each image can then be compared against each other (i.e. matched) to confirm the quality of the registered fingerprints. This comparison is analogous to a password confirmation routine that is commonly required for entering a new password.

Overview of Registration Process

- 1. Capture fingerprint images: SGFPM_GetImage() or SGFPM_GetImageEx()
- Extract minutiae from each captured fingerprint image: SGFPM_CreateTemplate()
- 3. Match each template to determine if they are acceptable for registration: SGFPM_MatchTemplate()
- 4. Save templates to file or database to complete registration

Example: Using two fingerprint images to register one fingerprint

```
BYTE*
       m RegTemplate1;
BYTE*
       m RegTemplate2;
err = SGFPM GetMaxTemplateSize(m hFPM, &m MaxTemplateSize);
m RegTemplate1 = new BYTE[m MaxTemplateSize];
m RegTemplate2 = new BYTE[m MaxTemplateSize];
// Get first fingerprint image and create template from the image
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, qlty);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m ReqTemplate1);
// Get second fingerprint image and create template from the image
err = SGFPM GetImageEx(m_hFPM, m_ImgBuf, 5000, NULL, qlty);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m RegTemplate2);
DWORD sl = SL NORMAL; // Set security level as NORMAL
BOOL matched;
err = SGFPM_MatchTemplate(m_hFPM, m_ RegTemplate1, m_ RegTemplate2, s1, &matched);
if (matched)
// Save these templates somewhere
```

3.12. Verification Process

The verification process involves matching newly input minutiae data against registered minutiae data. Similar to the registration process, verification requires the capture of a fingerprint image followed by extraction of the minutiae data from the captured image into a template.

Overview of Verification Process

- 1. Capture fingerprint image: SGFPM_GetImage() or SGFPM_GetImageEx()
- Extract minutiae data from captured image: SGFPM_CreateTemplate()
- 3. Match newly made template against registered templates: SGFPM_MatchTemplate()
 - Adjust the security level according to the type of application. For example, if fingerprint-only authentication is used, set the security level higher than **SL_NORMAL** to reduce false acceptance (FAR).

Example: Input minutiae data is matched against two registered minutiae data samples

```
BYTE* m VrfTemplate1;
err = SGFPM GetMaxTemplateSize(m hFPM, &m MaxTemplateSize);
m_ VrfTemplate1= new BYTE[m_MaxTemplateSize];
// Get first fingerprint image and create template from the image
err = SGFPM_GetImageEx(m_hFPM, m_ImgBuf, 5000, NULL, qlty);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m VrfTemplate1);
DWORD sl = SL NORMAL; // Set security level depending on applications.
DWORD err;
BOOL matched1, matched2;
err = SGFPM MatchTemplate(m hFPM, m RegTemplate1, m VrfTemplate1, sl);
err = SGFPM_MatchTemplate(m_hFPM, m_RegTemplate2, m_ VrfTemplate1, sl);
if (err == SGSGFDX ERROR NONE)
   if (matched1 && matched2)
       // Matched
   else
       // Not matched
```

3.13. Getting Matching Score

For improved quality control during the registration or verification process, a matching score can be used instead of a security level setting to determine the success of the operation. The matching score can be specified so that only sets of minutiae data that exceed the score will be accepted; data below the score will be rejected. The matching score may have a value from 0 to 199. **SGFPM_GetMatchingScore()** requires two sets of minutiae data of the same template format. **SGFPM_GetMatchingScoreEx()** requires two sets of minutiae data, but they can take different template formats. For more information about template formats, refer to <u>Section 3.15. Template Format</u>. For more information about **SGFPM_GetMatchingScoreEx()**, refer to <u>Section 4.5. Matching Functions</u>.

```
DWORD score;
if (SGFPM_GetMatchingScore(m_hFPM, m_RegTemplate1, m_RegTemplate1, &score) ==
SGSGFDX_ERROR_NONE)
{
   if (score > 100)
      // Enroll these fingerprints to database
   else
      // Try again
}
```

To understand how the matching scores correlate with typical security levels, refer to the chart below. For more information about security levels, refer to <u>Section 4.5. Matching Functions</u>.

Security Level vs. Corresponding Matching Score

Constant	Value	Corresponding Matching Score
SL_NONE	0	0
SL_LOWEST	1	30
SL_LOWER	2	50
SL_LOW	3	60
SL_BELOW_NORMAL	4	70
SL_NORMAL	5	80
SL_ABOVE_NORMAL	6	90
SL_HIGH	7	100
SL_HIGHER	8	120
SL_HIGHEST	9	140

3.14. Using Auto-On™

Auto-OnTM is a function that allows the reader to automatically detect the presence of a finger without requiring the user to prompt the system before receiving a fingerprint. To use this function, Auto-On should be enabled using **SGFPM_EnableAutoOnEvent()**. Once Auto-On is enabled, the application can receive a message from the device driver whenever an Auto-On event occurs in the reader.

In the UNIX/Linux environment, message queues are used for communication between the device driver and the host application. When no finger is present the messages from the driver contain a **<u>zero</u>**. When a finger is present, the driver will send a **<u>non-zero</u>** value.

• Enabling Auto-On

```
[Example]
bool StartAutoOn(LPSGFPM m sgfplib)
 DWORD result;
 bool StartAutoOn = false;
 // Create unique key via call to ftok()
 //Create unique message key
 key = ftok(".", 'a'); //'a' is an arbitrary seed value
 // Open the queue - create if necessary
 if((msg qid = msgget(key, IPC CREAT|0660)) == -1)
  return false;
 // EnableAutoOnEvent(true)
 result = m sgfplib->EnableAutoOnEvent(true, &msg qid, NULL);
 if (result != SGFDX ERROR NONE)
   printf("FAIL - [%ld]\n", result);
 }
 else
   StartAutoOn = true;
   printf("SUCCESS - [%ld]\n", result);
 return StartAutoOn;
```

• Disabling Auto-On

Handling Auto-On event in application

Check for finger presence in a separate thread or a while loop that pops messages from the message queue. The following function is an example:

```
long fingerPresent()
  int fingerPresent = 0;
  printf("Reading message queue ...\n");
#ifdef _FDU05
           qbuf.mtype = FDU05 MSG;
#endif
#ifdef FDU04
           qbuf.mtype = FDU04_MSG;
#endif
#ifdef FDU03
            qbuf.mtype = FDU03 MSG;
#endif
  msgrcv(msg_qid, (struct msgbuf *)&qbuf, MAX_SEND_SIZE, qbuf.mtype, 0);
   if (strlen(qbuf.mtext) > 0)
      fingerPresent= atol(qbuf.mtext);
   return fingerPresent;
```

3.15. Template Format

The FDx SDK *Pro* supports three types of fingerprint template formats:

- SecuGen's proprietary template format ("SG400")
- ANSI-INCITS 378-2004 "Finger Minutiae Format for Data Exchange" ("ANSI378")
- ISO/IEC 19794-2:2005 "Biometric Data Interchange Formats-- Finger Minutiae Data" ("ISO19794-2")

As default, SGFPM creates SecuGen proprietary templates (TEMPLATE_FORMAT_SG400). To change the template format, use **SGFPM_SetTemplateFormat()**.

SG400 templates are encrypted for high security and have a size of 400 bytes. ANSI378 templates are not encrypted, and their size is variable depending on how many fingers are registered in the structure and how many minutiae points are found.

For more information about the ANSI378 template, refer to the standard document titled "Information technology - Finger Minutiae Format for Data Interchange," document number ANSI-INCITS 378-2004, available at the ANSI website http://webstore.ansi.org.

For more information about the ISO19794-2 template, refer to the standard document titled "Information technology -- Biometric Data Interchange Formats -- Part 2: Finger Minutiae Data," document number ISO / IEC 19794-2:2005, available at the ISO website under Subcommittee JTC 1 / SC 37 (Biometrics) http://www.iso.org/iso/iso_catalogue/catalogue_tc/catalogue_detail.htm?csnumber=38746.

Once the template format is set, it will affect the execution of the SGFPM module.

The following APIs are affected by **SGFPM_SetTemplateFormat()**:

- SGFPM_GetMaxTemplateSize()
- SGFPM_CreateTemplate()
- SGFPM_GetTemplateSize()
- SGFPM_MatchTemplate()
- SGFPM_GetMatchingScore()

The following APIs work only when the template format is **TEMPLATE FORMAT_ANSI378**:

- SGFPM_GetTemplateSizeAfterMerge()
- SGFPM_MergeAnsiTemplate()
- SGFPM_MergeMultipleAnsiTemplate()
- SGFPM_GetAnsiTemplateInfo()
- SGFPM_MatchAnsiTemplate()
- SGFPM_GetAnsiMatchingScore()

The following APIs work only when the template format is **TEMPLATE_FORMAT_ISO19794**:

- SGFPM_GetIsoTemplateSizeAfterMerge()
- SGFPM_MergelsoTemplate()
- SGFPM_MergeMultipleIsoTemplate()
- SGFPM_GetIsoTemplateInfo()
- SGFPM_MatchIsoTemplate()
- SGFPM_GetIsoMatchingScore()

The following APIs work with any template format:

- SGFPM MatchTemplateEx()
- SGFPM_GetMatchingScoreEx()
- Defining template format

```
enum SGFDxTemplateFormat
{
    TEMPLATE_FORMAT_ANSI378 = 0x0100,
    TEMPLATE_FORMAT_SG400 = 0x0200,
    TEMPLATE_FORMAT_ISO19794 = 0x0300,
};
```

Setting template format to ANSI378

```
{\tt SGFPM\_SetTemplateFormat(m\_hFPM,\ TEMPLATE\_FORMAT\_ANSI378);}
```

Setting template format to SG400

```
SGFPM_SetTemplateFormat(m_hFPM, TEMPLATE_FORMAT_SG400);
```

Setting template format to ISO19794

SGFPM SetTemplateFormat (m hFPM, TEMPLATE FORMAT ISO19794);

3.16. Manipulating ANSI378 Templates

The ANSI378 template format allows multiple fingers and multiple views per finger to be stored in one template. To support this feature, FDx SDK *Pro* provides the following special APIs:

- SGFPM_GetTemplateSizeAfterMerge()
- SGFPM_MergeAnsiTemplate()
- SGFPM_MergeMultipleAnsiTemplate()
- SGFPM_GetAnsiTemplateInfo()
- SGFPM_MatchAnsiTemplate()
- SGFPM_GetAnsiMatchingScore()

Merging two ANSI378 templates

After creating an ANSI378 template from a fingerprint image, additional ANSI378 templates can be merged into one template. To do this, use **SGFPM_MergeAnsiTemplate()**, which takes two ANSI378 templates and merges them into one template. The merged template size will be less than the sum of the sizes of all input templates. Call **SGFPM_GetTemplateSizeAfterMerge()** to obtain the exact template size of the merged template before using **SGFPM_MergeAnsiTemplate()**.

```
m_Template1;
BYTE*
BYTE*
        m Template2;
err = SGFPM GetMaxTemplateSize(m hFPM, &m MaxTemplateSize);
m Template1 = new BYTE[m MaxTemplateSize];
m Template2 = new BYTE[m MaxTemplateSize];
// Get first fingerprint image and create template from the image
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, 80);
err = SGFPM CreateTemplate(m_hFPM, 0, m_ImgBuf, m_Template1);
// Get second fingerprint image and create template from the image
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, 80);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m Template2);
// Save template after merging two templates - m_Template1, m_Template2
BYTE* merged template;
DWORD buf size;
err = SGFPM_GetTemplateSizeAfterMerge(m_hFPM, m_Template1, m_Template2, &buf_size);
merged template = new BYTE[buf size];
err = SGFPM_MergeAnsiTemplate(m_hFPM, m_Template1, m_Template2, merged_template);
// Save m EnrollTemplate to file
SaveTemplate(file name, merged template, buf size);
delete [] merged_template; // Freed by calling application
```

Merging multiple ANSI378 templates

More than two ANSI378 templates may be merged into one template using SGFPM_MergeMultipleAnsiTemplate(). The merged template size will be less than the sum of the sizes of

all source templates. To determine the buffer size for the merged template, use the sum of the size for each template and then later obtain the actual size of merged template after calling SGFPM_MergeMultipleAnsiTemplate().

```
BYTE* target template;
DWORD size1, size2;
DWORD err;
DWORD real size = 0;
// Buffer for input templates - source template
err = SGFPM GetTemplateSize(m hFPM, template1, &size1);
err = SGFPM GetTemplateSize(m hFPM, template2, &size2);
BYTE* source template = new BYTE[size1 + size2]; // Make stack of each template
memcpy(&source template[0], template1, size1);
memcpy(&source template[size1], template2, size2);
// Allocate buffer for output template - merged template
target template = new BYTE[size1+ size2];
err = SGFPM MergeMultipleAnsiTemplate(m hFPM, source template, 2, target template);
delete [] source template;
// Get actual size of merged template
// Actual size will be less than size1+size2
err = SGFPM_GetTemplateSize(m_hFPM, target_template, &real_size);
```

Getting information about an ANSI378 template

The ANSI378 template format allows multiple fingers and multiple views per finger to be stored in one template. To match one sample (view) against a sample in other template, information about the template may be needed. To get sample information about a template, use **SGFPM_GetAnsiTemplateInfo()**.

```
DWORD err;
int matched samples = 0;
SGANSITemplateInfo sample infol, sample info2;
err = SGFPM GetAnsiTemplateInfo(m hFPM, g EnrollData, &sample info1);
err = SGFPM_GetAnsiTemplateInfo(m_hFPM, g_VrfData, &sample_info2);
for (int i = 0; i < sample infol.TotalSamples; i++)</pre>
   for (int j = 0; j < sample info2.TotalSamples; j++)</pre>
      BOOL matched;
      err = SGFPM MatchAnsiTemplate(m hFPM, g EnrollData, i, g VrfData, 0, sl, &matched);
      if (matched)
            matched samples++;
}
if (err == SGFDX ERROR NONE)
   if (matched samples)
      m ResultEdit.Format("Found %d matched samples: ", matched samples);
   else
```

```
m_ResultEdit.Format("Cannot find matched sample");
}
else
   m ResultEdit.Format("MatchTemplate() failed. Error = %d ", err);
```

3.17. Manipulating ISO19794-2 Templates

The ISO19794-2 template format allows multiple fingers and multiple views per finger to be stored in one template. To support this feature, FDx SDK *Pro* provides the following special APIs:

- SGFPM_GetIsoTemplateSizeAfterMerge()
- SGFPM_MergelsoTemplate()
- SGFPM_MergeMultipleIsoTemplate()
- SGFPM_GetIsoTemplateInfo()
- SGFPM_MatchIsoTemplate()
- SGFPM_GetIsoMatchingScore()

• Merging two ISO19794-2 templates

After creating an ISO19794-2 template from a fingerprint image, additional ISO19794-2 templates can be merged into one template. To do this, use **SGFPM_MergelsoTemplate()**, which takes two ISO19794-2 templates and merges them into one template. The merged template size will be less than the sum of the sizes of all input templates. Call **SGFPM_GetIsoTemplateSizeAfterMerge()** to obtain the exact template size of the merged template before using **SGFPM_MergelsoTemplate()**.

```
BYTE*
        m Template1;
BYTE*
       m Template2;
 // Set template format to ISO19794-2
err = SGFPM SetTemplateFormat(m hFPM, TEMPLATE FORMAT ISO19794);
err = SGFPM GetMaxTemplateSize(m hFPM, &m MaxTemplateSize);
m Template1 = new BYTE[m MaxTemplateSize];
m Template2 = new BYTE[m MaxTemplateSize];
// Get first fingerprint image and create template from the image
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, 80);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m Template1);
// Get second fingerprint image and create template from the image
err = SGFPM GetImageEx(m hFPM, m ImgBuf, 5000, NULL, 80);
err = SGFPM CreateTemplate(m hFPM, 0, m ImgBuf, m Template2);
// Save template after merging two templates - m Template1, m Template2
BYTE* merged template;
DWORD buf_size;
err = SGFPM_GetIsoTemplateSizeAfterMerge(m_hFPM, m_Template1, m_Template2, &buf_size);
merged template = new BYTE[buf size];
err = SGFPM_MergeIsoTemplate(m_hFPM, m_Template1, m_Template2, merged_template);
// Save m EnrollTemplate to file
SaveTemplate(file name, merged_template, buf_size);
delete [] merged template; // Freed by calling application
```

Merging multiple ISO19794-2 templates

ISO19794-2 than two templates may be merged into one template SGFPM MergeMultipleIsoTemplate(). The merged template size will be less than the sum of the sizes of all source templates. To determine the buffer size for the merged template, use the sum of the size for each and then later obtain the actual size of merged template after SGFPM_MergeMultipleIsoTemplate().

```
BYTE* target template;
DWORD size1, size2;
DWORD err;
DWORD real size = 0;
// Buffer for input templates - source template
err = SGFPM GetTemplateSize(m hFPM, template1, &size1);
err = SGFPM GetTemplateSize(m hFPM, template2, &size2);
BYTE* source template = new BYTE[size1 + size2]; // Make stack of each template
memcpy(&source template[0], template1, size1);
memcpy(&source template[size1], template2, size2);
// Allocate buffer for output template - merged template
target template = new BYTE[size1+ size2];
err = SGFPM MergeMultipleIsoTemplate(m hFPM, source template, 2, target template);
delete [] source template;
// Get actual size of merged template
// Actual size will be less than size1+size2
err = SGFPM GetTemplateSize(m hFPM, target template, &real size);
```

Getting information about an ISO19794-2 template

The ISO19794-2 template format allows multiple fingers and multiple views per finger to be stored in one template. To match one sample (view) against a sample in other template, information about the template may be needed. To get sample information about a template, use **SGFPM_GetIsoTemplateInfo()**.

```
DWORD err;
BOOL matched = FALSE;
// TSO19794-2
SGISOTemplateInfo sample info = {0};
err = SGFPM GetIsoTemplaTeInfo(m hFPM, m StoredTemplate, &sample info);
matched = FALSE;
int found_finger = -1;
for (int \bar{i} = 0; i < sample info. Total Samples; i++)
    err = SGFPM MatchIsoTemplate(m hFPM, m StoredTemplate, i, m FetBufM, 0, SL NORMAL,
                                  &matched);
    if (matched)
         found finger = sample info.SampleInfo[i].FingerNumber;
         break;
if (err == SGFDX ERROR NONE)
   if (found finger >= 0)
     m ResultEdit.Format("The fingerprint data found. Finger Position: %s",
                          g FingerPosStr[found finger]);
```

```
else
    m_ResultEdit.Format("Cannot find matched fingerprint data");
} else
{
    m_ResultEdit.Format("MatchIsoTemplate() failed. Error = %d ", err);
}
```

3.18. Getting Version Information of MINEX Compliant Algorithms

To obtain version information about the MINEX Compliant algorithms, use **SGFPM_GetMinexVersion()**. Currently, the extractor version number is 0x000A0035, and the matcher version number is 0x000A8035.

```
DWORD extractor, matcher;
err = SGFPM_GetMinexVersion(m_hFPM, &extractor, &matcher);

CString sz_ver;
sz_ver.Format("(Extractor:0x%08X, Matcher:0x%08X)", extractor, matcher);
SetWindowText( T("SecuGen ANSI MINEX Test ") + sz ver);
```

Chapter 4. Function Reference

4.1. SGFPM Creation and Termination

DWORD SGFPM_Create(HSGFPM* phFPM)

Creates the SGFPM object internally

Parameters

phFPM

The pointer to contain the handle of the SGFPM object

Return values

SGFDX_ERROR_NONE = No error SGFDX_ERROR_CREATION_FAILED = Failed to create SGFPM object

SGFPM_Terminate(HSGFPM hFpm)

Exits the SGFPM module

Parameters

pFPM

The handle of the SGFPM object

• Return values

SGFDX_ERROR_NONE = No error

4.2. Initialization

DWORD SGFPM_Init(HSGFPM hFpm, DWORD devName)

Initializes SGFPM with device name information. The SGFPM object loads appropriate drivers with device name (devName) and initializes fingerprint algorithm module based on the device information.

Parameters

pFPM

The handle of the SGFPM object

devName

Specifies the device name

SG_DEV_FDU03: device name for USB FDU03 and SDU03-based readers SG_DEV_FDU04: device name for USB FDU04 and SDU04-based readers

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_CREATION_FAILED = Failed to create SGFPM object

SG DEV FDU05: device name for U20-based USB readers

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_DRVLOAD_FAILED = Failed to load driver

DWORD SGFPM_InitEx(HSGFPM hFpm, DWORD width, DWORD height, DWORD dpi)

Initializes SGFPM with image information. Use when running fingerprint algorithm module without a SecuGen reader.

Parameters

pFPM

The handle of the SGFPM object

width

Image width in pixels

height

Image height in pixels

dpi

Image resolution in DPI

• Return values

```
SGFDX_ERROR_NONE = No error
```

SGFDX_ERROR_CREATION_FAILED = Failed to create SGFPM object

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_DLLLOAD_FAILED = Failed to load algorithm library

DWORD SGFPM_SetTemplateFormat(HSGFPM hFpm, WORD format)

Sets template format. Default format is SecuGen proprietary format (TEMPLATE_FORMAT_SG400).

Parameters

pFPM

The handle of the SGFPM object

format

Specifies template format

TEMPLATE_FORMAT_ANSI378: ANSI-INCITS 378-2004 format

TEMPLATE_FORMAT_SG400: SecuGen proprietary format

TEMPLATE_FORMAT_ISO19794: ISO/IEC 19794-2:2005 format

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_CREATION_FAILED = Failed to create SGFPM object

SGFDX_ERROR_INVALID_TEMPLATE_TYPE: Wrong template format

4.3. Device and Capturing Functions

DWORD SGFPM_EnumerateDevice(HSGFPM hFpm, DWORD* ndevs, SGDeviceList** devList, DWORD devName = SG_DEV_UNKNOWN)

Enumerates currently attached reader to the system. If devName is not specified (SG_DEV_UNKNOWN), then it returns a list of all SecuGen readers attached to the system. If devName is specified (SG_DEV_FDU03 or SG_DEV_FDU04), it enumerates only the devices that belong to the specified device class.

Parameters

pFPM

The handle of the SGFPM object

ndevs

The number of attached USB readers

devList

Buffer that contains device ID and device serial number. For more information, see <u>Section 5.2.</u> <u>SGDeviceList</u>.

devName

Device name. Should be one of the following values:

 $SG_DEV_UNKNOWN = 0$

 $SG_DEV_FDU03 = 0x04$

SG DEV FDU04 = 0x05

 $SG_DEV_FDU05 = 0x06$

Returned values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_FUNCTION_FAILED = General function fail error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

DWORD SGFPM_OpenDevice(HSGFPM hFpm, DWORD devId)

Initializes the fingerprint reader

Parameters

pFPM

The handle of the SGFPM object

devld

Specifies the device ID for USB readers. The value can be from 0 to 9. The maximum number of supported readers attached at the same time is 10.

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_SYSLOAD_FAILED = Failed to loading system files

SGFDX_ERROR_INITIALIZE_FAILED = Failed to initialize chip

SGFDX_ERROR_DEVICE_NOT_FOUND = Device not found

DWORD SGFPM_CloseDevice(HSGFPM hFpm)

Closes the opened device. SGFPM_OpenDevice() must be called before this function is used.

Parameters

pFPM

The handle of the SGFPM object

Return values

SGFDX_ERROR_NONE = No error

DWORD SGFPM_GetDeviceInfo(HSGFPM hFpm, SGDeviceInfoParam* pInfo)

Gets device information from the driver (before device initialization)

Parameters

pFPM

The handle of the SGFPM object

pinfo

A pointer to SGDeviceInfoParam. SGDeviceInfoParam is explained in Chapter 5. Structure Reference.

Return values

SGFDX_ERROR_NONE = No error

DWORD SGFPM_Configure(HSGFPM hFpm, HWND hwnd)

Displays the driver's configuration dialog box

Parameters

ρFPM

The handle of the SGFPM object

hwnd

The parent window handle

Return values

SGFDX_ERROR_NONE = No error

DWORD SGFPM_SetBrightness(HSGFPM hFpm, DWORD brightness)

Controls brightness of image sensor

Parameters

pFPM

The handle of the SGFPM object

brightness

Must be set to a value from 0 to 100

Return values

SGFDX_ERROR_NONE = No error SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

DWORD SGFPM_SetLedOn(HSGFPM hFpm, bool on)

Turns optic unit LED on/off

Parameters

pFPM

The handle of the SGFPM object

on

True: Turns on LED False: Turns off LED

Return values

SGFDX_ERROR_NONE = No error

DWORD SGFPM_GetImage(HSGFPM hFpm, BYTE* buffer)

Captures a 256 gray-level fingerprint image from the reader. The image size can be retrieved by calling **SGFPM_GetDeviceInfo()**. **SGFPM_GetImage()** does not check for image quality. To get image quality of a captured image, use **SGFPM_GetImageQuality()**. To get the approximate image quality while capturing, use **GetImageEx()**.

Parameters

pFPM

The handle of the SGFPM object

buffer

A pointer to the buffer containing a fingerprint image. The image size can be retrieved by calling **GetDeviceInfo()**.

Return values

```
SGFDX_ERROR_NONE = No error
SGFDX_ERROR_WRONG_IMAGE = Capture image is not a real fingerprint image
SGFDX_ERROR_INVALID_PARAM = Invalid parameter used
```

SGFDX_ERROR_LINE_DROPPED = Image data lost

DWORD SGFPM_GetImageQuality(HSGFPM hFpm, DWORD width, DWORD height, BYTE* imgBuf, DWORD* quality)

Gets the quality of a captured (scanned) image. The value is determined by two factors. One is the ratio of the fingerprint image area to the whole scanned area, and the other is the ridge quality of the fingerprint image area. A quality value of 50 or higher is recommended for registration. A quality value of 40 or higher is recommended for verification.

Note: The returned quality value is different from the value used in **SGFPM_GetImageEx()**. The quality value in **SGFPM_GetImageEx()** represents only the ratio of the fingerprint image area to the whole scanned area.

Parameters

pFPM

The handle of the SGFPM object

width

Image width in pixels

height

Image height in pixels

imgBuf

Fingerprint image data

quality

The return value indicating image quality

Return values

SGFDX_ERROR_NONE = No error SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

DWORD SGFPM_GetImageEx(HSGFPM hFpm, BYTE* buffer, DWORD time = 0, HWND dispWnd , DWORD quality)

Captures fingerprint images from the reader until the quality of the image is greater than the value of the quality parameter. The captured fingerprint is a 256 gray-level image; image size can be retrieved by calling the **SGFPM_GetDeviceInfo()** function. A quality value of 50 or higher is recommended for registration. A quality value of 40 or higher is recommended for verification.

Note: The returned quality value is different from the value used in **SGFPM_GetImage()**. The quality value in **GetImageEx()** represents only the ratio of the fingerprint image area to the whole scanned area.

Parameters

pFPM

The handle of the SGFPM object

buffe

Pointer to buffer containing a fingerprint image

timeout

The timeout value (in milliseconds) used to specify the amount of time the function will wait for a valid fingerprint to be input on the fingerprint reader

dispWnd

Window handle used for displaying fingerprint images

quality

The minimum quality value of an image, used to determine whether to accept the captured image

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_LINE_DROPPED = Image data lost

SGFDX_ERROR_TIME_OUT = No valid fingerprint captured in the given time

DWORD SGFPM EnableAutoOnEvent (HSGFPM hFpm, BOOL enable, HWND hwnd, void* reserved)

Allows the reader to automatically detect the presence of a finger without requiring the user to prompt the system before receiving a fingerprint. **SGFPM_EnableAutoOnEvent()** enables or disables the Auto-On function. Once Auto-On is enabled, the application can receive a message from the device driver whenever an Auto-On event occurs in the reader.

When calling **SGFPM_EnableAutoOnEvent()**, pass the handle of the window that will receive the **Auto-On** message. The **Auto-On** message is defined as 0x8100 in sgfplib.h.

Parameters

ρFPM

The handle of the SGFPM object

enable

TRUE: enables Auto-On FALSE: disables Auto-On

hwnd

Window handle to receive Auto-On message

reserved

Not used

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

Remarks

When the application receives an Auto-On message, wParam will have event type (Finger ON or OFF) and IParam will have information of the device from which the event occurred.

wParam:

Contains event type.

SGDEVEVNET_FINGER_ON(1) = Finger is on the sensor

SGDEVEVNET_FINGER_OFF(0) = Finger is removed from the sensor

IParam^{*}

Contains device information. The device information is contained in SGDeviceInfoParam.

4.4. Extraction Functions

DWORD SGFPM_GetMaxTemplateSize(HSGFPM hFpm, DWORD* size)

Gets the maximum size of a fingerprint template (view or sample). Use this function before using **SGFPM_CreateTemplate()** to obtain an appropriate buffer size. If the template format is SG400, it returns fixed length size 400.

Note: The returned template size means the maximum size of one view or sample.

Parameters

pFPM

The handle of the SGFPM object

Size

The pointer to contain template size

Return values

SGFDX ERROR NONE = No error

DWORD SGFPM_CreateTemplate(HSGFPM hFpm, FingerInfo* fpInfo, BYTE *rawImage, BYTE* minTemplate)

Extracts minutiae from a fingerprint image to form a template having the default format

Parameters

pFPM

The handle of the SGFPM object

fpInfo

Fingerprint information. It is stored in template. For **ANSI378** templates, this information can be retrieved from the template using **GetAnsiTemplateInfo()**. For **SG400** templates, this information cannot be seen in the template. For more information about the structure, refer to <u>section 5.3 SGFingerInfo</u>. For **ISO19794** templates, this information can be retrieved from the template using **GetIsoTemplateInfo()**.

rawlmg

256 Gray-level fingerprint image data

minTemplate

Pointer to buffer containing minutiae data extracted from a fingerprint image

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_FEAT_NUMBER = Inadequate number of minutia

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = 103 = Error while decoding template 1

SGFDX_ERROR_INVALID_TEMPLATE2 = 104 = Error while decoding template 2

DWORD SGFPM_GetTemplateSize(HSGFPM hFpm, BYTE* minTemplate, DWORD* size)

Gets template size. If the template format is SG400, it will return 400. If the template format is ANSI378 or ISO19794, template size may vary.

Parameters

pFPM

The handle of the SGFPM object

minTemplate

Pointer to buffer containing minutiae data extracted from a fingerprint image

size

The pointer to contain template size

Return values

SGFDX_ERROR_NONE = No error

4.5. Matching Functions

DWORD SGFPM_MatchTemplate(HSGFPM hFpm, BYTE *minTemplate1, BYTE *minTemplate2, DWORD secuLevel, BOOL* matched)

Compares two sets of minutiae data of the **same** template format. The template format should be the same as that set by **SGFPM_SetTemplateFormat()** and should include only one sample. To match templates that have more than one sample, use **SGFPM_MatchTemplateEx()** or **SGFPM_MatchAnsiTemplate()**.

It returns TRUE or FALSE as a matching result(**matched**). Security level(**secuLevel**) affects matching result. The security level may be adjusted according to the security policy required by the user or organization

Parameters

pFPM

The handle of the SGFPM object

minTemplate1

A pointer to the buffer containing minutiae data extracted from a fingerprint image

minTempate2

A pointer to the buffer containing minutiae data extracted from a fingerprint image

secuLevel

A security level as specified in "fplibnew.h" by one the following nine security levels: SL_LOWEST, SL_LOWER, SL_LOW, SL_BELOW_NORMAL, SL_NORMAL, SL_ABOVE_NORMAL, SL_HIGH, SL_HIGHER and SL_HIGHEST. SL_NORMAL is recommended in usual case.

matched

Contains matching result. Ifpassed templates are same templates, TRUE is returned. If not, FALSE is returned.

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

DWORD SGFPM_MatchTemplateEx(HSGFPM hFpm, BYTE* minTemplate1, WORD tempateType1, DWORD sampleNum1, BYTE* minTemplate2, WORD tempateType2, DWORD sampleNum2, DWORD secuLevel, BOOL* matched)

Compares two sets of minutiae data, which can be of different template formats (SG400 or ANSI378). It returns TRUE or FALSE as a matching result (**matched**). Security level (**secuLevel**) affects matching result. The security level may be adjusted according to the security policy required by the user or organization.

Parameters

pFPM

The handle of the SGFPM object

minTemplate1

A pointer to the buffer containing minutiae data extracted from a fingerprint image

templateType1

Specifies format of minTemplate1. Should be either TEMPLATE_FORMAT_SG400 or TEMPLATE_FORMAT_ANSI378.

sampleNum1

Position of a sample to be matched in minTemplate1. If templateType1 is TEMPLATE_FORMAT_ANSI378, it can have a value from 0 to (number of samples -1) in minTemplate1. If templateType1 is TEMPLATE_FORMAT_SG400, this value is ignored.

minTemplate2

A pointer to the buffer containing minutiae data extracted from a fingerprint image

templateType2

Specifies format of minTemplate2. Should be either TEMPLATE_FORMAT_SG400 or TEMPLATE FORMAT_ANSI378.

sampleNum2

Position of a sample to be matched in minTemplate2. If templateType2 is TEMPLATE_FORMAT_ANSI378, it can have a value from 0 to (number of samples -1) in minTemplate2. If templateType2 is TEMPLATE_FORMAT_SG400, this value is ignored.

secuLevel

A security level as specified in "fplibnew.h" by one the following nine security levels: SL_LOWEST, SL_LOWER, SL_LOW, SL_BELOW_NORMAL, SL_NORMAL, SL_ABOVE_NORMAL, SL_HIGHEST, SL_HIGHEST, SL_NORMAL is recommended in usual case.

matched

TRUE: Same template FALSE: Not same template

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

DWORD SGFPM_GetMatchingScore(HSGFPM hFpm, BYTE* minTemplate1, BYTE* minTemplate2, DWORD* score)

Gets matching score of two sets of minutiae data of the same template format

Parameters

pFPM

The handle of the SGFPM object

minTemplate1

A pointer to the buffer containing minutiae data extracted from a fingerprint image

minTemplate2

A pointer to the buffer containing minutiae data extracted from a fingerprint image

score

Matching score. Returned score has a value from 0 to 199.

· Returned values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

DWORD SGFPM_ GetMatchingScoreEx(HSGFPM hFpm, BYTE* minTemplate1, WORD tempateType1, DWORD sampleNum1, BYTE* minTemplate2, WORD tempateType2, DWORD sampleNum2, DWORD* score);

Gets matching score of two sets of minutiae data, which can be of different template formats (SG400 or ANSI378)

Parameters

рFPM

The handle of the SGFPM object

minTemplate1

A pointer to the buffer containing minutiae data extracted from a fingerprint image

templateType1

Specifies format of minTemplate1. Should be either TEMPLATE_FORMAT_SG400 or TEMPLATE_FORMAT_ANSI378.

sampleNum1

Position of a sample to be matched in minTemplate1. If templateType1 is TEMPLATE_FORMAT_ANSI378, it can have a value from 0 to (number of samples -1) in minTemplate1. If templateType1 is TEMPLATE_FORMAT_SG400, this value is ignored.

minTemplate2

A pointer to the buffer containing minutiae data extracted from a fingerprint image

templateType2

Specifies format of minTemplate2. Should be either TEMPLATE_FORMAT_SG400 or TEMPLATE_FORMAT_ANSI378.

sampleNum2

Position of a sample to be matched in minTemplate2. If templateType2 is TEMPLATE_FORMAT_ANSI378, it can have a value from 0 to (number of samples -1) in minTemplate2. If templateType2 is TEMPLATE_FORMAT_SG400, this value is ignored.

score

Matching score. Returned score has a value from 0 to 199.

Returned values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

4.6. Functions for ANSI378 Templates

DWORD SGFPM_GetTemplateSizeAfterMerge(HSGFPM hFpm, BYTE* ansiTemplate1, BYTE* ansiTemplate2, DWORD* size)

Calculates template size if two templates – ansiTemplate1 and ansiTemplate2 – are merged. Use this function to determine exact buffer size before using **SGFPM_MergeAnsiTemplate()**.

Parameters

pFPM

The handle of the SGFPM object

ansiTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

ansiTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

size

Template size if two templates are merged

Return values

```
SGFDX_ERROR_NONE = No error
```

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

DWORD SGFPM_MergeAnsiTemplate(HSGFPM hFpm, BYTE* ansiTemplate1, BYTE* ansiTemplate2, BYTE* outTemplate)

Merges two ANSI378 templates and returns a new merged template. The merged template (outTemplate) size will be less than sum of the sizes of the two input templates (size of ansiTemplate1 + size of ansiTemplate2). Call SGFPM_GetTemplateSizeAfterMerge() to determine the exact buffer size for outTemplate before calling SGFPM_MergeAnsiTemplate().

Parameters

pFPM

The handle of the SGFPM object

ansiTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

asniTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

outTempate

The buffer containing merged data. The buffer should be assigned by the application. To determine the exact buffer size, call SGFPM_GetTemplateSizeAfterMerge().

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

DWORD SGFPM_MergeMultipleAnsiTemplate(HSGFPM hFpm, BYTE* inTemplates, DWORD nTemplates, BYTE* outTemplate)

Merges multiple ANSI378 templates and returns a new merged template. The merged template (**outTemplate**) size will be less than sum of the sizes of all templates in **inTemplates**.

Parameters

рFPM

The handle of the SGFPM object

inTemplates

A series of ANSI378 templates [ANSITemplate-1, ANSITemplate-2, ANSITemplate-3, ...;ANSITemplate-n] *nTemplates*

The number of templates in inTemplates

outTempate

The buffer containing new merged template data. The buffer should be assigned by the application.

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

DWORD SGFPM_GetAnsiTemplateInfo(HSGFPM hFpm, BYTE* ansiTemplate, SGANSITemplateInfo* templateInfo)

Gets information of an ANSI378 template. Call this function before **SGFPM_MatchAnsiTemplate()** to obtain information about a template.

Parameters

pFPM

The handle of the SGFPM object

anisiTemplate

ANSI378 template

templateInfo

The buffer that contains template information. For more information see SGANSITemplateInfo structure.

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

DWORD SGFPM_MatchAnsiTemplate(HSGFPM hFpm, BYTE* ansiTemplate1, DWORD sampleNum1, BYTE* ansiTemplate2, DWORD sampleNum2, DWORD secuLevel, BOOL* matched)

Compares two sets of ANSI378 templates. It returns TRUE or FALSE as a matching result (**matched**). Security level (**secuLevel**) affects matching result. The security level may be adjusted according to the security policy required by the user or organization

Parameters

pFPM

The handle of the SGFPM object

ansiTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum1

Position of sample to be matched in **ansiTemplate1**. It can be from 0 to (number of samples -1) in **ansiTemplate1**

ansiTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum2

Position of sample to be matched in ansiTemplate2. It can be from 0 to (number of samples -1) in ansiTemplate2

secuLevel

A security level as specified in "fplibnew.h" by one the following nine security levels: SL_LOWEST, SL_LOWER, SL_LOW, SL_BELOW_NORMAL, SL_NORMAL, SL_ABOVE_NORMAL, SL_HIGHE, SL_HIGHEST. SL_NORMAL is recommended in usual case.

matched

TRUE: Same template FALSE: Not same template

Return values

SGFDX_ERROR_NONE = No error

```
SGFDX_ERROR_INVALID_TEMPLATE1 = Error in ansiTemplate1
SGFDX_ERROR_INVALID_TEMPLATE1 = Error in ansiTemplate1
SGFDX_ERROR_INVALID_TEMPLATE2 = Error in ansiTemplate2
```

DWORD SGFPM_GetAnsiMatchingScore(HSGFPM hFpm, BYTE* ansiTemplate1, DWORD sampleNum1, BYTE* ansiTemplate2, DWORD sampleNum2, DWORD* score)

Gets matching score

Parameters

pFPM

The handle of the SGFPM object

ansiTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum1

Position of sample to be matched in **ansiTemplate1**. It can be from 0 to (number of samples -1) in **ansiTemplate1**

ansiTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum2

Position of sample to be matched in ansiTemplate2. It can be from 0 to (number of samples -1) in ansiTemplate2

score

Matching score. Returned score has a value from 0 to 199.

Return values

```
SGFDX_ERROR_NONE = No error
SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type
SGFDX_ERROR_INVALID_TEMPLATE1 = Error in ansiTemplate1
SGFDX_ERROR_INVALID_TEMPLATE2 = Error in ansiTemplate2
```

4.7. Functions for ISO19794-2 Templates

DWORD SGFPM_GetIsoTemplateSizeAfterMerge(HSGFPM hFpm, BYTE* isoTemplate1, BYTE* isoTemplate2, DWORD* size)

Calculates template size if two templates – isoTemplate1 and isoTemplate2 – are merged. Use this function to determine exact buffer size before using **SGFPM_MergelsoTemplate()**.

Parameters

pFPM

The handle of the SGFPM object

isoTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

isoTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

size

Template size if two templates are merged

Return values

```
SGFDX_ERROR_NONE = No error
SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type
SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1
SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2
```

DWORD SGFPM_MergelsoTemplate(HSGFPM hFpm, BYTE* isoTemplate1, BYTE* isoTemplate2, BYTE* outTemplate)

Merges two ISO19794-2 templates and returns a new merged template. The merged template (outTemplate) size will be less than sum of the sizes of the two input templates (size of isoTemplate1 + size of isoTemplate2). Call SGFPM_GetTIsoemplateSizeAfterMerge() to determine the exact buffer size for outTemplate before calling SGFPM_MergeIsoTemplate().

Parameters

pFPM

The handle of the SGFPM object

isoTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

isoTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

outTempate

The buffer containing merged data. The buffer should be assigned by the application. To determine the exact buffer size, call **SGFPM_GetIsoTemplateSizeAfterMerge()**.

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in minTemplate1

SGFDX_ERROR_INVALID_TEMPLATE2 = Error in minTemplate2

DWORD SGFPM_MergeMultipleIsoTemplate(HSGFPM hFpm, BYTE* inTemplates, DWORD nTemplates, BYTE* outTemplate)

Merges multiple ISO19794-2 templates and returns a new merged template. The merged template (**outTemplate**) size will be less than sum of the sizes of all templates in **inTemplates**.

Parameters

pFPM

The handle of the SGFPM object

inTemplates

A series of ISO19794-2 templates [ISOTemplate-1, ISOTemplate-2, ISOTemplate-3, ..., ISOTemplate-n]

nTemplates

The number of templates in inTemplates

outTempate

The buffer containing new merged template data. The buffer should be assigned by the application.

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_PARAM = Invalid parameter used

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

DWORD SGFPM_GetIsoTemplateInfo(HSGFPM hFpm, BYTE* isoTemplate, SGISOTemplateInfo* templateInfo)Gets information of an ISO19794-2 template. Call this function before **SGFPM_MatchIsoTemplate()** to obtain information about a template.

Parameters

pFPM

The handle of the SGFPM object

isoTemplate

ISO19794-2 template

templateInfo

The buffer that contains template information. For more information see SGISOTemplateInfo structure.

Return values

SGFDX_ERROR_NONE = No error SGFDX_ERROR_INVALID_PARAM = Invalid parameter used SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

DWORD SGFPM_MatchIsoTemplate(HSGFPM hFpm, BYTE* isoTemplate1, DWORD sampleNum1, BYTE* isoTemplate2, DWORD sampleNum2, DWORD secuLevel, BOOL* matched)

Compares two sets of ISO19794-2 templates. It returns TRUE or FALSE as a matching result (**matched**). Security level (**secuLevel**) affects matching result. The security level may be adjusted according to the security policy required by the user or organization

Parameters

pFPM

The handle of the SGFPM object

isoTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum1

Position of sample to be matched in **isoTemplate1**. It can be from 0 to (number of samples -1) in **isoTemplate1**

isoTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum2

Position of sample to be matched in **isoTemplate2**. It can be from 0 to (number of samples -1) in **isoTemplate2**

secuLevel

A security level as specified in "fplibnew.h" by one the following nine security levels: SL_LOWEST, SL_LOWER, SL_LOW, SL_BELOW_NORMAL, SL_NORMAL, SL_ABOVE_NORMAL, SL_HIGH, SL_HIGHER and SL_HIGHEST. SL_NORMAL is recommended in usual case.

matched

TRUE: Same template FALSE: Not same template

Return values

SGFDX_ERROR_NONE = No error

SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type

SGFDX_ERROR_INVALID_TEMPLATE1 = Error in isoTemplate1

 ${\sf SGFDX_ERROR_INVALID_TEMPLATE2} = {\sf Error} \ {\sf in} \ {\sf isoTemplate2}$

DWORD SGFPM_GetIsoMatchingScore(HSGFPM hFpm, BYTE* isoTemplate1, DWORD sampleNum1, BYTE*isoTemplate2, DWORD sampleNum2, DWORD* score)

Gets matching score

Parameters

pFPM

The handle of the SGFPM object

isoTemplate1

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum1

Position of sample to be matched in **isoTemplate1**. It can be from 0 to (number of samples -1) in **isoTemplate1**

isoTempate2

A pointer to the buffer containing minutiae data. A template can have more than one sample.

sampleNum2

Position of sample to be matched in **isoTemplate2**. It can be from 0 to (number of samples -1) in **isoTemplate2**

score

Matching score. Returned score has a value from 0 to 199.

Return values

SGFDX_ERROR_NONE = No error SGFDX_ERROR_INVALID_TEMPLATE_TYPE = Wrong template type SGFDX_ERROR_INVALID_TEMPLATE1 = Error in isoTemplate1 SGFDX_ERROR_INVALID_TEMPLATE2 = Error in isoTemplate2

4.8. Other

DWORD SGFPM_GetMinexVersion(HSGFPM hFpm, DWORD *extractor, DWORD* matcher))

Gets version of MINEX Compliant algorithms used in this SDK

Parameters

pFPM

The handle of the SGFPM object

extractor

Version of MINEX Compliant extractor (template generator)

matcher

Version of MINEX Compliant matcher (template matcher)

Return values

SGFDX_ERROR_NONE = No error

Chapter 5. Structure Reference

5.1. SGDeviceInfoParam

```
typedef struct tagSGDeviceInfoParam
 DWORD DeviceID:
 BYTE DeviceSN[SGDEV_SN_LEN+1]; // Device serial number, SN length = 15
 DWORD ComPort;
                                      // Parallel readers => PP address; USB readers => USB (0x3BC+1)
 DWORD ComSpeed;
                                      // Parallel readers => PP mode; USB reader => 0
 DWORD ImageWidth;
                                      // Image width
 DWORD ImageHeight;
                                      // Image height
 DWORD Contrast;
                                     // 0 ~ 100
 DWORD Brightness;
                                      // 0 ~ 100
 DWORD Gain;
                                      // Device dependent
 DWORD ImageDPI;
                                      // Image resolution
 DWORD FWVersion;
                                      // Firmware version
} SGDeviceInfoParam;
```

Description

Used when calling SGFPM_GetDeviceInfo()

Members

DeviceID

Device ID for USB readers (0 - 9)

DeviceSN

Device serial number for USB readers. SGDEV_SN_LEN = 15

ComPort

Not used

ComSpeed

Not used

ImageWidth

Fingerprint image width in pixels

ImageHeight

Fingerprint image height in pixels

Brightness

Current brightness value (0-100)

Contrast

Current contrast value (0-100)

Gair

Amplification (1, 2, 4, or 8) of image brightness (higher values yields darker images)

ImageDPI

Fingerprint image resolution in DPI

FWVersion

Device firmware version number for USB readers

5.2. SGDeviceList

```
typedef struct tagSGDeviceList
{
    DWORD DevName;
    DWORD DevID;
    WORD DevType;
    BYTE DevSN[SGDEV_SN_LEN+1];
} SGDeviceList;
```

Description

Used to obtain the currently attached device list in SGFPM_EnumerateDevice()

Members

DevName

Device name (SG_DEV_FDU03 or SG_DEV_FDU04)

DevID

Device ID for USB readers

DevType

Not used

DeviceSN

Device serial number for USB readers (SGDEV_SN_LEN = 15)

5.3. SGFingerInfo

```
typedef struct tagSGFingerInfo {
   WORD FingerNumber;
   WORD ViewNumber;
   WORD ImpressionType;
   WORD ImageQuality;
} SGFingerInfo;
```

Description

Used when calling SGFPM_CreateTemplate(). The provided information will be put into the template. For ANSI378 or ISO 19794-2 templates, this information can be seen from the template structure format. For SG400 templates, this information cannot be seen in the template.

Members

FingerNumber

Fingerprint position number

```
SG_FINGPOS_UK (0x00):
                         Unknown finger
SG_FINGPOS_RT (0x01):
                         Right thumb
SG_FINGPOS_RI (0x02):
                          Right index finger
SG_FINGPOS_RM (0x03):
                         Right middle finger
SG_FINGPOS_RR (0x04):
                         Right ring finger
SG_FINGPOS_RL (0x05):
                         Right little finger
SG_FINGPOS_LT (0x06):
                         Left thumb
SG_FINGPOS_LI (0x07):
                         Left index finger
SG_FINGPOS_LM (0x08):
                         Left middle finger
SG_FINGPOS_LR (0x09):
                         Left ring finger
SG_FINGPOS_LL (0x0A):
                         Left little finger
```

ViewNumber

Sample number for each finger (starts at 0)

ImpressionType

```
Impression type (should be 0 for SecuGen readers)

SG_IMPTYPE_LP (0x00): Live-scan plain

SG_IMPTYPE_LR (0x01): Live-scan rolled

SG_IMPTYPE_NP (0x02): Non-live-scan plain

SG_IMPTYPE_NR (0x03): Non-live-scan rolled
```

ImageQuality

Image quality value (0 – 100). To get an image quality, use GetImageQuality().

5.4. SGANSITemplateInfo/SGISOTemplateInfo

```
typedef struct tagSGANSITemplateInfo {
   DWORD TotalSamples;
   SGFingerInfo SampleInfo[225];
} SGANSITemplateInfo, SGISOTemplateInfo;
```

Description

Used when calling SGFPM_GetAnsiTemplateInfo() or SGFPM_GetIsoTemplateInfo(). The provided information will be put into the template. For ANSI378 templates, this information can be seen from the template structure format. For SG400 templates, this information cannot be seen in the template. For ISO19794-2 templates, this information can be seen from the template structure format.

Members

TotalSamples

Indicates the number of samples in a template. One template can have a maximum of 225 samples. Number of samples = Max finger number 15 * Max View Number 15 = 225

SampleInfo

Information of each sample in a template. Refer to SGFingerInfo structure.

Chapter 6. Constants

6.1. SGFDxDeviceName

Device Name	Value	Description
SG_DEV_UNKNOWN	0	Not determined
SG_DEV_FDU03	0x04	FDU03 or SDU03-based reader
SG_DEV_FDU04	0x05	FDU04-based reader
SG_DEV_FDU05	0x06	U20-based reader

6.2. SGPPPortAddr

Port Address	Value	Description
AUTO_DETECT	0	Auto detect
USB_AUTO_DETECT	0x3BC+1	USB Auto detect

6.3. SGFDxSecurityLevel

Security Level	Value	Description
SL_NONE	0	No Security
SL_LOWEST	1	Lowest
SL_LOWER	2	Lower
SL_LOW	3	Low
SL_BELOW_NORMAL	4	Below normal
SL_NORMAL	5	Normal
SL_ABOVE_NORMAL	6	Above normal
SL_HIGH	7	High
SL_HIGHER	8	Higher
SL_HIGHEST	9	Highest

6.4. SGFDxTemplateFormat

Template Format	Value	Description
TEMPLATE_FORMAT_ANSI378 TEMPLATE_FORMAT_SG400 TEMPLATE_FORMAT_ISO19794	0x0100 0x0200 0x0300	ANSI-INCITS 378-2004 format SecuGen proprietary format ISO/IEC 19794-2:2005 format

6.5. SGImpressionType

Security Level	Value	Description
SG_IMPTYPE_LP	0x00	Live-scan plain
SG_IMPTYPE_LR	0x01	Live-scan rolled
SG_IMPTYPE_NP	0x02	Non-live-scan plain
SG_IMPTYPE_NR	0x03	Non-live-scan rolled

6.6. SGFingerPosition

Security Level	Value	Description
SG_FINGPOS_UK	0x00	Unknown finger
SG_FINGPOS_RT	0x01	Right thumb
SG_FINGPOS_RI	0x02	Right index finger
SG_FINGPOS_RM	0x03	Right middle finger
SG_FINGPOS_RR	0x04	Right ring finger
SG_FINGPOS_RL	0x05	Right little finger
SG_FINGPOS_LT	0x06	Left thumb
SG_FINGPOS_LI	0x07	Left index finger
SG_FINGPOS_LM	0x08	Left middle finger
SG_FINGPOS_LR	0x09	Left ring finger
SG_FINGPOS_LL	0x0A	Left little finger

6.7. SGFDxErrorCode

Error Code	Value	Description	
General Er	ror Codes		
SGFDX_ERROR_NONE SGFDX_ERROR_CREATION_FAILED SGFDX_ERROR_FUNCTION_FAILED SGFDX_ERROR_INVALID_PARAM SGFDX_ERROR_NOT_USED SGFDX_ERROR_DLLLOAD_FAILED	0 1 2 3 4 5	No error SGFPM object creation failed Function call failed Invalid parameter used Not used function Library loading failed	
SGFDX_ERROR_DLLLOAD_FAILED_DRV SGFDX_ERROR_DLLLOAD_FAILED_ALGO	6 7	Device driver loading failed Algorithm library loading failed	
Device Driver	Device Driver Error Codes		
SGFDX_ERROR_SYSLOAD_FAILED SGFDX_ERROR_INITIALIZE_FAILED SGFDX_ERROR_LINE_DROPPED SGFDX_ERROR_TIME_OUT SGFDX_ERROR_DEVICE_NOT_FOUND SGFDX_ERROR_DRVLOAD_FAILED SGFDX_ERROR_WRONG_IMAGE SGFDX_ERROR_LACK_OF_BANDWIDTH SGFDX_ERROR_DEV_ALREADY_OPEN SGFDX_ERROR_GETSN_FAILED SGFDX_ERROR_UNSUPPORTED_DEV	51 52 53 54 55 56 57 58 59 60 61	Cannot find driver sys file Chip initialization failed Image data lost GetImageEx() timeout Device not found Driver file load failed Wrong image Lack of USB Bandwidth Device is already opened Serial number does not exist Unsupported device	

Extract & Matching Error Codes			
SGFDX_ERROR_FEAT_NUMBER SGFDX_ERROR_INVALID_TEMPLATE_TYPE SGFDX_ERROR_INVALID_TEMPLATE1 SGFDX_ERROR_INVALID_TEMPLATE2 SGFDX_ERROR_EXTRACT_FAIL	101 102 103 104 105	Inadequate number of minutiae Wrong template type Error in decoding template 1 Error in decoding template 2 Extraction failed	
SGFDX_ERROR_EXTRACT_FAIL SGFDX_ERROR_MATCH_FAIL	105 106	Matching failed	

6.8. Other Constants

•	SGDEV_SN_LEN	15 // Device serial number length
•	WM_APP_SGAUTOONEVENT	0x8100
•	SGDEVEVNET_FINGER_OFF	0
•	SGDEVEVNET FINGER ON	1

Appendix A. Using SGFPM Objects Directly

All SDK functions are integrated into the SGFPM class. To access the SGFPM class (not by handle), get the pointer of an SGFPM object using **CreateSGFPMObject()**. When you have finished using the SGFPM object, destroy the SGFPM object using **DestroySGFPMObject()**.

A.1. Creating an SGFPM object

To get a pointer to an SGFPM object, use CreateSGFPMObject(). To create and use the SGFPM object, it should be called.

A.2. Destroying an SGFPM object

When exiting a program, you must destroy the SGFPM object with **DestroySGFPMObject()**.

A.3. Accessing other member functions

All member functions are nearly the same as the functions in the C style APIs described in Chapter 3. The only difference is that functions are accessed through object pointers, not handles.

```
g Fpm->Init(devName);
g Fpm->InitEx(width, height, dpi);
g Fpm->SetTemplateFormat(format)
                                    // Default format is SG400
g Fpm->EnumerateDevice(ndevs, devList)
g Fpm->OpenDevice(devId)
g Fpm->CloseDevice()
g Fpm->GetDeviceInfo(pDeviceInfo)
g Fpm->Configure(hwnd)
g Fpm->SetBrightness(brightness)
g Fpm->SetLedOn(onoff)
g Fpm->GetImage(buffer)
g Fpm->GetImageEx(buffer, time = 0, dispWnd, quality)
g Fpm->GetImageQuality(width, height, imgBuf, quality)
g Fpm->EnableAutoOnEvent(enable, hwnd, reserved)
g Fpm->GetMaxTemplateSize(size)
g Fpm->CreateTemplate(fpInfo, rawImage, minTemplate)
g Fpm->GetTemplateSize(buf, size)
g Fpm->MatchTemplate(minTemplate1, minTemplate2, secuLevel, matched)
g Fpm->GetMatchingScore(min1, min2, score)
g Fpm->GetTemplateSizeAfterMerge(ansiTemplate1, ansiTemplate2, size)
g_Fpm->MergeAnsiTemplate(ansiTemplate1, ansiTemplate2, outTemplate)
```

```
q Fpm->MergeMultipleAnsiTemplate(inTemplates, nTemplates, outTemplate)
g Fpm->GetAnsiTemplateInfo(BYTE* ansiTemplate, SGANSITemplateInfo* templateInfo)
g Fpm->MatchAnsiTemplate(ansiTemplate1,sampleNum1,
                         ansiTemplate2,sampleNum2,secuLevel, matched)
g Fpm->GetAnsiMatchingScore(ansiTemplate1, sampleNum1, ansiTemplate2, sampleNum2, score)
g Fpm->MatchTemplateEx(minTemplate1, tempateType1, sampleNum1, minTemplate2,
                                     tempateType2, sampleNum2, secuLevel, matched)
g Fpm->GetMatchingScoreEx(minTemplate1, tempateType1, sampleNum1, minTemplate2,
                          tempateType2, sampleNum2, score)
g_Fpm->GetMinexVersion(extractor, matcher)
// ISO19794-2
g_Fpm->MergeIsoTemplate(isoTemplate1, isoTemplate2, outTemplate)
g Fpm->MergeMultipleIsoTemplate(inTemplates, nTemplates, outTemplate)
g Fpm->GetIsoTemplateInfo(isoTemplate, templateInfo)
g Fpm->MatchIsoTemplate(isoTemplate1, sampleNum1,
                         isoTemplate2, sampleNum2,
                         secuLevel, matched)
g_Fpm->GetIsoMatchingScore(isoTemplate1, sampleNum1,
                           isoTemplate2,sampleNum2,score)
```