



Pre-Job Start:

1. EOG Resources Contractor Training
2. FR Clothing (Outermost Layer)
3. Safety Boots
4. Hard Hat
5. Eye Protection (ANZI-Z87 w/ side shields)
6. Gas Meter (recommended 4 gas)
7. Initiate JSA
8. SDS Available in Cab
9. Understand SWA

Site Arrival:

1. Follow RUMA Routes and Obey Speed Limits
2. Enter Pad and Secure Vehicle
3. Perform a pad walk to ensure a safe work area, absence of spills and tank levels.
4. Check in on active/attended pads if your work is in that area or unsure of hazards.
5. Locate ESD and set cone as a backing target
6. Position truck for safe egress as well as to maintain traffic flow.
7. Traffic Cone deployed at front corner of truck.
8. Complete JSA

Loading/Unloading

1. The truck is secured with park brakes and wheel chocks.
2. The truck is grounded, and an approved transfer hose is being used.
3. Confirm commodity to be transferred and adequate volume to load.
4. Secondary containment available at pump and connection point
5. Securing device placed on all fluid transfer connections
6. Vent line in place**(see additional guidelines below)
7. Sight Glasses are recommended at any time operating near 3' buffer level.
8. Witches hat or screen for any type of work other than production tanks.
9. Maintain safe buffer with water/oil interface level. (3')
10. Monitoring progress from outside of truck while loading.
11. Site is secured with all tank valves, load valves and bleeder valves closed post transfer.

**Vent Line Operations: EOG Pads will continue to use the closed vent systems. Legacy Encino Pads are not designed for closed loop venting at this point. These pads will continue to use atmospheric vents. 30ft vent line directing flow away from possible ignition sources.

Document Title: Water Hauler Loading / Unloading Recommendations

Document Type: Guidance Document

Applicability: Oklahoma City Division



Operational Notes:

1. Fire Extinguisher Readily Accessible.
2. Check in at any active site where work may be occurring in your work area
3. Notify the Control Room if oil/condensate is loaded or poor-quality loads.
4. No oil or condensate shall be transported offsite on water trucks.
5. Notify the Control Room if any product needs returned to tanks.
6. 3 Points of contact when exiting and entering vehicles.
7. 360° Walk Around before departing from any site.
8. Notify Control Room and Carrier Management of any spills or incidents.
9. Utilize SWA as deemed necessary.
10. Use extreme caution on SIMOPS Locations. Some will require special direction or change of normal operating procedure. If unsure gather direction before proceeding
11. Identified Hazards are reported using the Good Catch Program.
12. No truck maintenance on pad without prior EOG Rep. approval

KPA Reporting – Forms, Good Catches/Near Misses



CARE Team

Please Scan to input any Good Catches, Hazard Observations,
Safety Engagements, or Near Misses.
If you need any assistance please contact EOG Safety

Contact List

EOG Control Room 24/7: (234) 980-1135