



Harvey Frac – Traffic Control Plan

The following information must be reviewed by any heavy traffic drivers who will be providing services to the Harvey frac.

Sand staging is at the Followway Pad (used only as needed):

- **50884 Headley Ridge Rd, Beallsville, Ohio 43716**

Harvey 911 Address:

- **51780 Atkinson Run Rd, Beallsville, Ohio 43716**

Directions for entering the frac:

From the east:

- 1) 1.0 miles past Pugh Ridge Rd/Headley Ridge Rd on **SR-556**, turn left onto **Atkinson Run Rd**.
- 2) Travel **Atkinson Run Rd** for 0.3 miles & bear left onto **Harvey lease rd**.

From the west:

- 1) 0.4 miles past Mellott Ridge Rd on **SR-556**, turn right onto **Atkinson Run Rd**.
- 2) Travel **Atkinson Run Rd** for 0.3 miles & bear left onto **Harvey lease rd**.

****Inbound traffic has the right-of-way on Atkinson Run Rd****

CB Channel 12 will be utilized for communications inbound and outbound from the frac. **Starr Logistics** Traffic Control will be located on Atkinson Run Rd & Headley Ridge Rd to assist in communications.

NOTE: Atkinson Run Rd should be regarded as a **1-lane road**. Drivers will need to communicate their entry to Traffic Control while on SR-556 at Callouts #1 & 2 (from the east) & Callouts #1A & 2A (from the west).


Callout Points are as follows: 1A, 2A, 3, 4, & 5 – see map for reference.

NO JAKE BRAKES INBOUND OR OUTBOUND NEAR RESIDENTS

Call Gulfport Dispatch if you have any questions: **740-552-4350**



Topo: Entire Route View





Topo: Followway Pad (Harvey Staging)





Topo: On-Pad Traffic Flow

