

Title:	Gulfport Produced Water Reuse – Offloading Guideline			
Type:	Operating Guideline	Version:	7/18/2026	
Function:	General	Last Reviewed:	7/18/2026	
Dissemination:	Internal only	Original Issuance:	06/30/2026 (v.1)	
Owner:	Chief Operating Officer			
				O.G.E11-206

1. PURPOSE

All Water Haulers working on a Gulfport (“Gulfport or the “Company”) location are expected to follow the requirements and processes outlined below. Ultimately, we want to successfully transfer fluids while ensuring that we conduct the job tasks safely and meet environmental protection requirements.

2. SCOPE

This guideline provides specific instructions for managing the EHS risks that are associated with off-loading produced water on a Gulfport location.

3. PROCESS

1. All traffic into the Gulfport reuse location shall follow the Traffic Control Plan (TCP) for the respective location & shall follow all posted speed limits.
 2. Upon entering the authorized haul route, trucks shall radio in on the designated CB channel of their position per signs. (utilizing the callout signs, when applicable).
 3. When space is verified at the offload station on the pad, driver shall proceed into the location at a speed not exceeding 5mph.
 4. **Before backing into position, driver must verify that there are two spotters** (one in front; one in the rear) to assist in safe movement.
 5. Once backed into the designated lane for offloading, drivers shall set their brakes & await further instruction.
 6. Offload station attendants will **review JSA & truck manifest** for verification prior to the driver exiting the vehicle.
 7. Driver shall have and put in place the following items:
 - a. **Cone at the front of the truck**
 - b. **Catch pan at the pump**
 - c. **Wheel chocks**
 - d. **Cone at rear passenger side of truck/trailer**
 - e. **Fire Extinguisher easily accessible on exterior of truck/trailer**
 8. Offload station attendant will place a large cone with a flag at the front of the truck, designating that this truck is not to move. **Cone and flag shall only be moved by offload station attendant.**
 9. Driver will connect hose and ground cable to truck.
 - a. Sight tubes are highly required.
 - b. Secondary cam lock securement must be used. (Pins, straps, clips)
 10. Once verified by offload station attendant & driver, driver will open their valves, and offload attendants will open the valves on the manifold to begin offloading.
 - a. **Driver is the only qualified person to operate valves on their truck.**
 - b. **Offload attendants are the only qualified persons to operate valves on Gulfport’s manifold.**
 11. Once offload is complete, driver will disconnect hose and verify that all valves and caps on truck are in proper off and locked position.
 12. Driver will complete a 360 walk around inspection and remove their Front cone/catch pan/wheel chocks/rear passenger cone.
- Note: Driver shall not enter their vehicle to leave without first doing a 360 inspection.**
13. Offload station attendants will remove the flag in front of the truck once verified that the driver is safe to pull away from the offload manifold & escort the truck from its lane.
 14. Follow location TCP for exit from the Gulfport location.

This document is uncontrolled when printed.
Users must verify this document against the latest controlled version available.

4. DEFINITIONS

N/A

5. RELATED DOCUMENTS

N/A