



E.L. ROBINSON
ENGINEERING
801 Watermark Drive, Suite 310 • Columbus, Ohio 43215
www.elrobinsonengineering.com

LOAD HAUL ROUTE MAP DRIVING DIRECTIONS

FLAINS PREPARED FOR:

[illegible]



Coad Approved RUMA Route

From I-70:

- 1. Follow I-70 towards exit 193 for OH-513.
- 2. Take exit 193 and head south on OH-513 S for 2.2 miles.
- 3. Turn left onto Oxford Rd./T.R. 962 and continue for 3.0 miles ending at the Coad entrance.

From I-77:

- 1. Follow I-77 toward exit 44A for I-70 E.
- 2. Take exit 44A for I-70 E toward Wheeling.
- 3. Merge onto I-70 E and continue for 12.9 miles.
- 4. Take exit 193 for OH-513 toward Quaker City.
- 5. Turn right onto OH-513 S and continue for 2.2 miles.
- 6. Turn left onto Oxford Rd./T.R. 962 and continue for 3.0 miles ending at the Coad entrance.

From the South (Quaker City, OH):

- 1. Take OH-513 N/Batesville Rd./Pike St. and follow for 4.6 miles.
- 2. Turn right onto Oxford Rd./T.R. 962 and continue for 3.0 miles ending at the Coad entrance.

It is advisable to keep the attached RUMA either in all vehicles or accessible by mobile device. All oversized/overloaded vehicles will need a permit through the ODOT website. Any route applied for with ODOT that can't be navigated will kick back with an alternate route. Please contact ARU's Field Superintendent, Jeff Beck, at 614-896-0599 or jeff.beck@ascentresources.com prior to using the route. Even though ODOT approves, it still could include unauthorized roads/bridges.

PLANS PREPARED BY:



E.L. ROBINSON

ENGINEERING

1801 Watermark Drive, Suite 310 • Columbus, Ohio 43215

www.elrobinsonengineering.com

PLANS PREPARED BY:



COAD
HAUL ROUTE MAP
DRIVING DIRECTIONS
OXFORD TWP., GUERNSEY CO., OH

3

3

PLANS PREPARED FOR:



REV. NO.

SHEET NO.

DATE

DESCRIPTION