



INFINITY

Carpenter FWI Well Pad

Haul Route



 Permitted Antero Route
 State Route

Township		County	Monroe
Address	49348 SR 379	City, State	Lewisville, OH 43754
Site Entrance Coordinates	+39.81475, -81.30781	Site Center Coordinates	

Haul Route Directions to Site

1. Traveling SR-379 turn east onto Carpenter FWI lease road
2. Carpenter lease road is approximately 0.4 miles north of the SR-379 and SR-78 intersection