



Rover Pi 4 Leaf

1 → DC Motor Driver 3.3V
3 → Acceleration Tilt Module SDA
4 → Buck Converter 5V
5 → Acceleration Tilt Module SCL
6 → DC Motor Driver GND
11 → DC Motor Driver In 1
13 → DC Motor Driver In 2
15 → DC Motor Driver En A
O 16 → DC Motor Driver In 3
17 → Acceleration Tilt Module 3.3V
18 → DC Motor Driver In 4
22 → DC Motor Driver En B
34 → Acceleration Tilt Module GND
35 → DC Motor Driver Encoder Left
O 37 → DC Motor Driver Encoder Left
O 37 → DC Motor Driver Encoder Right
39 → Buck Converter GND