Machine-Level Programming I: Basics

Today: Machine Programming I: Basics

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

Intel x86 Processors

Dominate laptop/desktop/server market

Evolutionary design

- Backwards compatible up until 8086, introduced in 1978
- Added more features as time goes on

Complex instruction set computer (CISC)

- Many different instructions with many different formats
 - But, only small subset encountered with Linux programs
- Hard to match performance of Reduced Instruction Set Computers (RISC)
- But, Intel has done just that!
 - In terms of speed. Less so for low power.

Intel x86 Evolution: Milestones

Transistors MHz Name Date **28086** 5-10 1978 **29K** ♣ First 16-bit Intel processor. Basis for IBM PC & DOS 1MB address space **2386** 1985 275K **16-33** ♣ First 32 bit Intel processor, referred to as IA32 Added "flat addressing", capable of running Unix Pentium 4E 2004 **125M** 2800-3800 First 64-bit Intel x86 processor, referred to as x86-64 Core 2 2006 1060-3500 291M ♣ First multi-core Intel processor Core i7 2008 **731M** 1700-3900 Four cores

Our Coverage

- **!** IA32
 - The traditional x86
- **2** x86-64
 - The standard
- Presentation
 - Book covers x86-64
 - Web aside on IA32
 - We will only cover x86-64


Today: Machine Programming I: Basics

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

Definitions

- Architecture: (also ISA: instruction set architecture) The parts of a processor design that one needs to understand or write assembly/machine code.
 - **Examples:** instruction set specification, registers.
- Microarchitecture: Implementation of the architecture.
 - Examples: cache sizes and core frequency.
- **Code Forms:**
 - Machine Code: The byte-level programs that a processor executes
 - Assembly Code: A text representation of machine code
- **Example ISAs:**
 - Intel: x86, IA32, Itanium, x86-64
 - ARM: Used in almost all mobile phones

Assembly/Machine Code View



Programmer-Visible State


- **PC:** Program counter
 - Address of next instruction
 - Called "RIP" (x86-64)
- Register file
 - Heavily used program data
- Condition codes
 - Store status information about most recent arithmetic or logical operation

Memory

- Byte addressable array
- Code and user data
- Stack to support procedures

Turning C into Object Code

- Code in files pl.c p2.c
- Compile with command: gcc -Og pl.c p2.c -o p
 - Use basic optimizations (-Og) [New to recent versions of GCC]
 - Put resulting binary in file p



Compiling Into Assembly

C Code (sum.c)

Generated x86-64 Assembly

```
sumstore:
   pushq %rbx
   movq %rdx, %rbx
   call plus
   movq %rax, (%rbx)
   popq %rbx
   ret
```

Obtain with command

Produces file sum.s

Warning: Can get very different results on different machines due to different versions of gcc and different compiler settings.

Assembly Characteristics: Data Types

- Unteger" data of 1, 2, 4, or 8 bytes
 - Data values
 - Addresses (untyped pointers)
- Floating point data of 4, 8, or 10 bytes
- **Code:** Byte sequences encoding series of instructions
- No aggregate types such as arrays or structures
 - Just contiguously allocated bytes in memory

Assembly Characteristics: Operations

- Perform arithmetic function on register or memory data
- Transfer data between memory and register
 - Load data from memory into register
 - Store register data into memory
- Transfer control
 - Unconditional jumps to/from procedures
 - Conditional branches

Object Code

Code for sumstore

0x0400595: 0x53 0x48 0x89 0xd3 0xe8 0xf2 0xff 0xff

0x48

0x89

0x03

0x5b

0xc3

- Total of 14 bytes
- Each instruction1, 3, or 5 bytes
- Starts at address
 0x0400595

Assembler

- Translates .s into .o
- Binary encoding of each instruction
- Nearly-complete image of executable code
- Missing linkages between code in different files

Linker

- Resolves references between files
- Combines with static run-time libraries
 - E.g., code for malloc, printf
- Some libraries are dynamically linked
 - Linking occurs when program begins execution

Machine Instruction Example

0x40059e: 48 89 03

&C Code

Store value t where designated by dest

Assembly

Move 8-byte value to memoryQuad words in x86-64 parlance

Operands:

t: Register %rax

dest: Register %rbx

*dest: Memory M[%rbx]

Object Code

3-byte instruction

Stored at address 0x40059e

Disassembling Object Code

Disassembled

```
0000000000400595 <sumstore>:
 400595:
          53
                           push
                                  %rbx
 400596: 48 89 d3
                           mov
                                  %rdx,%rbx
 400599: e8 f2 ff ff ff callq
                                  400590 <plus>
 40059e: 48 89 03
                                  %rax,(%rbx)
                           mov
 4005a1: 5b
                                  %rbx
                           pop
 4005a2: c3
                           reta
```

Disassembler

```
objdump -d sum
```

- Useful tool for examining object code
- Analyzes bit pattern of series of instructions
- Produces approximate rendition of assembly code
- Can be run on either a . out (complete executable) or . o file

Alternate Disassembly

Object

Disassembled

```
0 \times 0400595 :
    0x53
    0x48
    0x89
    0xd3
    0xe8
    0xf2
    0xff
    Oxff
    0xff
    0x48
    0x89
    0 \times 03
    0x5b
    0xc3
```

Within gdb Debugger

```
gdb sum
disassemble sumstore
```

Disassemble procedure

x/14xb sumstore

Examine the 14 bytes starting at sumstore

What Can be Disassembled?

```
% objdump -d WINWORD.EXE

WINWORD.EXE: file format pei-i386

No symbols in "WINWORD.EXE".
Disassembly of section .text:

30001000 <.text>:
30001000:
30001001:
30001003:
30001005:
Microsoft End User License Agreement
3000100a:
```

- Anything that can be interpreted as executable code
- Disassembler examines bytes and reconstructs assembly source

Today: Machine Programming I: Basics


- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

x86-64 Integer Registers

%rax	%eax	%r8	%r8d
%rbx	%ebx	%r9	%r9d
%rcx	%ecx	%r10	%r10d
%rdx	%edx	%r11	%r11d
%rsi	%esi	%r12	%r12d
%rdi	%edi	%r13	%r13d
%rsp	%esp	%r14	%r14d
%rbp	%ebp	%r15	%r15d

Can reference low-order 4 bytes (also low-order 1 & 2 bytes)

Some History: IA32 Registers



Origin (mostly obsolete)

accumulate

counter

data

base

source index

destination index

stack pointer base pointer


Moving Data

Moving Data
movq Source, Dest:

- Operand Types
 - Immediate: Constant integer data
 - Example: \$0x400, \$-533
 - Like C constant, but prefixed with \\$'
 - Encoded with 1, 2, or 4 bytes
 - **Register:** One of 16 integer registers
 - Example: %rax, %r13
 - But %rsp reserved for special use
 - Others have special uses for particular instructions
 - Memory: 8 consecutive bytes of memory at address given by register
 - Simplest example: (%rax)
 - Various other "address modes"

%rax	
%rcx	
%rdx	
%rbx	
%rsi	
%rdi	
%rsp	
%rbp	

movq Operand Combinations



Cannot do memory-memory transfer with a single instruction

Simple Memory Addressing Modes

- Normal (R) Mem[Reg[R]]
 - Register R specifies memory address
 - Aha! Pointer dereferencing in C

movq (%rcx),%rax

- Displacement D(R) Mem[Reg[R]+D]
 - Register R specifies start of memory region
 - Constant displacement D specifies offset


movq 8(%rbp),%rdx

Example of Simple Addressing Modes

```
void swap
  (long *xp, long *yp)
{
  long t0 = *xp;
  long t1 = *yp;
  *xp = t1;
  *yp = t0;
}
```

```
swap:
  movq (%rdi), %rax
  movq (%rsi), %rdx
  movq %rdx, (%rdi)
  movq %rax, (%rsi)
  ret
```

```
void swap
   (long *xp, long *yp)
{
   long t0 = *xp;
   long t1 = *yp;
   *xp = t1;
   *yp = t0;
}
```



Memory

Register	Value
%rdi	хp
%rsi	ур
%rax	t0
%rdx	t1

```
swap:
  movq (%rdi), %rax # t0 = *xp
  movq (%rsi), %rdx # t1 = *yp
  movq %rdx, (%rdi) # *xp = t1
  movq %rax, (%rsi) # *yp = t0
  ret
```


Registers

%rdi	0x120
%rsi	0x100
%rax	
%rdx	


Memory

	Address
123	0x120
	0x118
	0x110
	0x108
456	0x100

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```



```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```




```
movq (%rdi), %rax # t0 = *xp


movq (%rsi), %rdx # t1 = *yp

movq %rdx, (%rdi) # *xp = t1
```

movq %rax, (%rsi) # *yp = t0

ret





```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```

Simple Memory Addressing Modes

- Normal (R) Mem[Reg[R]]
 - Register R specifies memory address
 - Aha! Pointer dereferencing in C

movq (%rcx),%rax

- Displacement D(R) Mem[Reg[R]+D]
 - Register R specifies start of memory region
 - Constant displacement D specifies offset

movq 8(%rbp),%rdx

Complete Memory Addressing Modes

Most General Form

D(Rb,Ri,S) Mem[Reg[Rb]+S*Reg[Ri]+D]

Onstant "displacement" 1, 2, or 4 bytes

♣ Rb: Base register: Any of 16 integer registers

©Ri: Index register: Any, except for %rsp

Scale: 1, 2, 4, or 8 (why these numbers?)

Special Cases

(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]]

D(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]+D]

(Rb,Ri,S) Mem[Reg[Rb]+S*Reg[Ri]]

Address Computation Examples

%rdx	0xf000	
%rcx	0x0100	

Expression	Address Computation	Address
0x8(%rdx)	0xf000 + 0x8	0xf008
(%rdx,%rcx)	0xf000 + 0x100	0xf100
(%rdx,%rcx,4)	0xf000 + 4*0x100	0xf400
0x80(,%rdx,2)	2*0xf000 + 0x80	0x1e080

Today: Machine Programming I: Basics

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

Address Computation Instruction

- leaq Src, Dst
 - Src is address mode expression
 - Set Dst to address denoted by expression

Uses

- Computing addresses without a memory reference
 - E.g., translation of p = &x[i];
- - k = 1, 2, 4, or 8

Example

```
long m12(long x)
{
   return x*12;
}
```

Converted to ASM by compiler:

```
leaq (%rdi,%rdi,2), %rax # t <- x+x*2
salq $2, %rax # return t<<2</pre>
```

Some Arithmetic Operations

Two Operand Instructions:

Format Computation			
addq	Src,Dest	Dest = Dest + Src	
subq	Src,Dest	Dest = Dest – Src	
imulq	Src,Dest	Dest = Dest * Src	
salq	Src,Dest	Dest = Dest << Src	Also called shiq
sarq	Src,Dest	Dest = Dest >> Src	Arithmetic
shrq	Src,Dest	Dest = Dest >> Src	Logical
xorq	Src,Dest	Dest = Dest ^ Src	
andq	Src,Dest	Dest = Dest & Src	
orq	Src,Dest	Dest = Dest Src	

- Watch out for argument order!
- No distinction between signed and unsigned int (why?)

Some Arithmetic Operations

One Operand Instructions

```
incq Dest Dest = Dest + 1

decq Dest Dest = Dest - 1

negq Dest Dest = -Dest

notq Dest Dest = \sim Dest
```

See book for more instructions

Arithmetic Expression Example

```
long arith
(long x, long y, long z)
{
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
}
```

```
arith:
  leaq (%rdi,%rsi), %rax
  addq %rdx, %rax
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx
  leaq 4(%rdi,%rdx), %rcx
  imulq %rcx, %rax
  ret
```

Interesting Instructions

- **leaq**: address computation
- **&** salq: shift
- **imulq**: multiplication
 - But, only used once

Understanding Arithmetic Expression Example

```
long arith
(long x, long y, long z)
{
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
}
```

```
arith:
  leaq (%rdi,%rsi), %rax # t1
  addq %rdx, %rax # t2
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx # t4
  leaq 4(%rdi,%rdx), %rcx # t5
  imulq %rcx, %rax # rval
  ret
```

Register	Use(s)
%rdi	Argument x
%rsi	Argument y
%rdx	Argument z
%rax	t1, t2, rval
%rdx	t4
%rcx	t5

Machine Programming I: Summary

- History of Intel processors and architectures
 - Evolutionary design leads to many quirks and artifacts
- **C**, assembly, machine code
 - New forms of visible state: program counter, registers, ...
 - Compiler must transform statements, expressions, procedures into low-level instruction sequences
- Assembly Basics: Registers, operands, move
 - The x86-64 move instructions cover wide range of data movement forms
- Arithmetic
 - C compiler will figure out different instruction combinations to carry out computation