

# **Study Material**

Program Code: All Program

Semester: First

**Course Name: Basic Science (Physics)** 

Course Code: 22102

**Topic Name: Electricity, Magnetism & Semiconductors** 


UO2e: Distinguish the given conductors, semiconductors and insulators on the basis of energy bands.

LO9: Student will be able to discuss conduction in semiconductors - charge carriers, intrinsic/extrinsic, p-type, and n-type.

Date: 01/09/2020

Course Expert: S. K. Rawat

Concept Map:



Key words: conductors, insulators, semiconductors, energy band diagram, valence band, conduction band, forbidden gap,

### **Key Questions:**

- 1. What is an intrinsic semiconductor?
- 2. How extrinsic semiconductors are formed?
- 3. Difference between intrinsic and extrinsic semiconductor.
- 4. Formation of N-type semiconductor.
- 5. Formation of P-type semiconductor.
- 6. Difference between N-type and P-type semiconductor.

### **Key Definition:**

- 1. A semiconductor in an extremely pure form is known as intrinsic semiconductor.
- 2. A semiconductor formed by adding impurities to a pure semiconductor for increasing conductivity is called as extrinsic semiconductor.
- 3. The process of adding impurities to pure semiconductors are called doping.
- When a small amount of pentavalent impurity is added to a pure semiconductor, it is known as n-type semiconductor.
- 5. When a small amount of trivalent impurity is added to a pure semiconductor, it is called p-type semiconductor.



### Notes

### Classification of semiconductors

There are two types of semiconductors such as -

- (i) Intrinsic Semiconductor and
- (ii) Extrinsic Semiconductor

### **Intrinsic Semiconductors**

A semiconductor in an extremely pure form is known as intrinsic semiconductor. Silicon and Germanium in extremely pure form is known as intrinsic semiconductor.

When electric field is applied across an intrinsic semiconductor, the electron-hole pairs are generated. The conduction of current takes place by two processes, namely, by free electrons and holes as shown in following Fig 1.

The free electrons are produced due to breaking of some covalent bonds. At the same time, holes are generated in the covalent bonds. Due to application of electric field, conduction through the semiconductor is by both free electrons and holes. The energy required to break such a covalent bond is equal to the band gap energy  $E_g$ . If the temperature of an intrinsic semiconductor is increased, beyond room temperature, a large number of electron-hole pairs are generated. Thus for an intrinsic semiconductor, concentration of free electron ' $n_e$ ' is equal to the concentration of holes ' $n_0$ ', i.e.,  $n_e = n_p$ .

Fig. 2 shows the energy band diagram for an intrinsic semiconductor at room temperature.




Figure 1: Intrinsic semiconductor with broken bond




Figure 2: Energy band diagram for intrinsic semiconductor

# **Extrinsic Semiconductors**

At room temperature, the conductivity of intrinsic semiconductor is too small to be useful for any practical applications. Conductivity of intrinsic semiconductor can be increased by adding suitable impurities to it. The purpose of adding impurity is to increase current carrying capacity of pure semiconductor, by increasing either the number of free electrons or holes in the semiconductor. Thus the process of adding impurities to pure semiconductors are called doping and the impurity atom are called dopants.

## Comparison between intrinsic semiconductor and extrinsic semiconductor

Intrinsic semiconductor	Extrinsic semiconductor
1. It is pure semi-conducting material and no	1. It is prepared by doping a small quantity of impurity atoms to
impurity atoms are added to it.	the pure semi-conducting material.
2. Examples: crystalline forms of pure Si and Ge.	2. Examples: Si and Ge crystals with impurity atoms of As, Sb, P
	etc. or B, Aℓ etc.
3. The number of free electrons in the	3. The number of free electrons and holes is not equal. There is
conduction band and the number of holes in	excess of electrons in n-type semiconductors and excess of
valence band is exactly equal.	holes in p-type semiconductors.
Its electrical conductivity is low.	4. Its electrical conductivity is high.
5. Its electrical conductivity depends on	5. Its electrical conductivity depends upon the temperature as
temperature alone.	well as on the quantity of doped impurity atoms.

### Doping

The process of adding impurities to pure semiconductors is called doping.

"When any trivalent or pentavalent impurity is added to pure semiconductor, then it is called as extrinsic semiconductor". Or Doped semiconductors are called extrinsic semiconductors.

Depending upon the type of impurity added, extrinsic semiconductors are classified as:

- (i) n-type semiconductor and
- (ii) p-type semiconductor



### n-type semiconductor

"When a small amount of pentavalent impurity is added to a pure semiconductor, it is known as n-type semiconductor".

### Formation of n-type semiconductor

When Si or Ge crystal is doped with pentavalent impurity such as As, Sb, P, we get n-type semiconductor. Pentavalent atom has 5 electrons in its valence orbit. Fig. 3 shows the structure of n-type semiconductor.

As germanium (Ge) atom has 4 valence electrons (atomic no. 32) and when a small amount of pentavalent impurity like arsenic (As) is added to germanium (Ge) semiconductor, a large number of free electrons become available in the semiconductor. The reason is simple, arsenic is pentavalent impurity (5 valence electrons) and its 4 valence electrons form covalent bonds with 4 germanium atoms. The fifth valence electron of arsenic remains free.

Therefore, for each arsenic atom added, one free electron will be available in the Ge semiconductor. Since every pentavalent dopant atom donated one electron for conduction; it is called donor impurity.




Figure 3: Structure of n-type semiconductor




Figure 4: Energy band diagram of n-type semiconductor

### p-type semiconductor

"When a small amount of trivalent impurity is added to a pure semiconductor, it is called p-type semiconductor".

### Formation of P-type semiconductor

When Si or Ge crystal is doped with trivalent impurities such as gallium (Ga), indium (In), boron (B) and aluminum (AI) we get p-type semiconductor. Trivalent atom has 3 electrons in its valence orbit. Fig. 5 shows the structure of p-type semiconductor. Every trivalent impurity atom shares its 3 electrons with 3 neighbouring silicon (Si) atoms to form covalent bond. But, the bond between the fourth neighbour and the trivalent atom has a vacancy or hole as shown in Fig. 2.8. As the trivalent impurity has a tendency to accept any electron in its close vicinity, they are called acceptor impurity. As this semiconductor has large number of holes and conductivity is because of positively charged holes, it is called p-type semiconductor.

Fig. 6 displays energy band diagram for p-type semiconductor at room temperature.




Figure 5: Structure of p-type semiconductor




Figure 6: Energy band diagram of p-type semiconductor



Comparison between n-type semiconductor and p-type semicond	uctor
---	-------

n-type semiconductor	p-type semiconductor
<ol> <li>An extrinsic semiconductor which is obtained by doping the impurity atoms of V<sup>th</sup> group of the periodic table to the pure Ge and Si semi-conductor.</li> </ol>	<ol> <li>An extrinsic semiconductor which is obtained by doping the impurity atoms of III<sup>rd</sup> group of the periodic table to the pure Ge and Si semi-conductor.</li> </ol>
<ol><li>The impurity atoms added, provide extra electrons in the structure and are called donor atoms.</li></ol>	<ol><li>The impurity atoms added, create vaccines of electrons (i.e. holes) in the structure and are called acceptor atoms.</li></ol>
<ol><li>The electrons are majority carriers and holes are minority carriers.</li></ol>	<ol><li>The holes are majority carriers and electrons are minority carriers.</li></ol>
<ol> <li>The concentration of electrons is much greater than holes.</li> </ol>	4. The concentration of holes is much greater than electrons.
5. The donor energy level is close to the conduction band and for away from the valence band.	<ol><li>The acceptor energy level is close to the Valence band and for away from the Conduction band.</li></ol>

## Link to YouTube/ OER/ video/e-book:

- 1. <a href="http://hyperphysics.phy-astr.gsu.edu/hbase/hframe.html">http://hyperphysics.phy-astr.gsu.edu/hbase/hframe.html</a>
- 2. https://www.electronics-tutorials.ws/diode/diode 1.html
- 3. <a href="https://www.electronics-notes.com/articles/basic\_concepts/conductors-semiconductors-insulators/what-is-a-semiconductor.php">https://www.electronics-notes.com/articles/basic\_concepts/conductors-semiconductors-insulators/what-is-a-semiconductor.php</a>

# Key Take away:

- 1. Intrinsic and extrinsic semiconductor.
- 2. N-type and P-type semiconductor.



## **Formative Assessments**

<22102>: <All Program>: < All Program >: <Electricity, Magnetism & Semiconductors>: <UO2e>:

<LO9>: <Assessments>: <Formative>

<S. K. Rawat>

Assessment Type: Formative Assessments: Embedded questions in video/ PPT

Set 1			
Question No 1	Question No 2	Question No 3	
A doped semiconductor is also known as	At absolute temperature, an intrinsic semiconductor has	Intrinsic semiconductor at room temperature will have available for	
		conduction.	
Remembering	Understanding	Applications	
a) Intrinsic semiconductor	a) a few free electrons	a) electrons	
b) Extrinsic semiconductor	b) many holes	b) holes	
c) Diffused semiconductor	c) many free electrons	c) both electrons and holes	
d) None of the above	d) no holes or free electrons d) None of the above		
Ans: < Extrinsic semiconductor > Ans: < no holes or free electrons >		Ans: <both and="" electrons="" holes=""></both>	

Set 2				
Question No 1	Question No 2	Question No 3		
Si atom with its four valence electrons shares an electron with each of its neighbouring atom.	Acceptor-type impurities	What type of material is obtained when intrinsic semiconductor is doped with pentavalent impurity?		
Remembering	Understanding	Understanding		
a) 2	a) can be added to silicon but not to germanium	a) N-type semiconductor		
b) 4	b) create excess electrons	b) Extrinsic semiconductor		
c) 6	c) must have three valence electrons	c) P-type semiconductor		
d) 8	d) must have five valence electrons	d) Insulator		
Ans: <4 >	Ans: < must have three valence electrons >	Ans: < N-type semiconductor >		



# **Practice Worksheets**

<22102>: <All Program>: < All Program >: <Electricity, Magnetism & Semiconductors>: <UO2e>:

<LO9>: <Assessments>: <Summative>

<S. K. Rawat>

_		1	
A.	The term bias in electronics usually means -		
a)	The value of ac voltage in the signal.	В.	What can a semiconductor sense?
b)	The condition of current through a pn	a)	Pressure
	junction.	b)	Temperature
c)	The value of dc voltages for the device to	c)	Magnetism
-	operate properly.	d)	All of the above
d)	The status of the diode.	۵,	All of the above
	The status of the diode.		
Ans A:		Ans B:	
		D.	When a small amount of pentavalent impurity
C.	The process of adding impurities to pure		(such as As or Sb or P) is added to a pure
	semiconductors are called		semiconductor (Si or Ge), it is called as
a)	dopants		semiconductor.
b)	agents	a)	n-type
c)	ageing	b)	p-type
		,	
d)	doping	c)	pn-type
		d)	np-type
Ans C:		Ans D:	
E.	When a small amount of trivalent impurity		
	(such as Ga or B or Al) is added to a pure	_	
	semiconductor (Si or Ge), it is called as		Arsenic is atom.
	semiconductor.	a)	trivalent
2)		b)	quadravalent
a)	n-type	c)	pentavalent
b)	p-type	d)	None of the above
c)	pn-type		
<u>d)</u>	np-type		
Ans E:		Ans F:	
-	Callium in atom	H.	When a pure semiconductor is heated, its
_	Gallium is atom.		resistance
a)	trivalent	a)	increases
b)	quadravalent	b)	decreases
c)	pentavalent		remains same
d)	None of the above	•	first increases and then decreases
Ans G:		Ans H:	
I.	Which of the following cannot exist outside	J.	In semiconductors, conductivity is
	a semiconductor?		due to positively charged electrons.
a)	Electrons	a)	n-type
b)	Holes	b)	p-type
c)	Both electrons and holes	c)	pn-type
d)	None of the above	d)	np-type
Ans I:		Ans J:	
A113 1.		A113 J.	