Installing GNU Radio

```
Sudo apt-get update
sudo apt-get install git python3 python3-pip
sudo pip3 install --upgrade git+https://github.com/gnuradio/pybombs.git
pybombs auto-config
pybombs recipes add-defaults
sudo apt-get install python-pip
pip install mako
sudo apt-get install libcppunit-dev
pip install numpy lxml cheetah
sudo apt-get install pyqt4-dev-tools
pip3 install PythonQwt
sudo apt-get install python3-qtpy
sudo apt-cache search qt4
sudo apt-get install qt4-qmake
sudo apt-get install libqwt-dev
pybombs prefix init ~/gnuradio -R gnuradio-stable
create a file with
nano setEnviroment.sh
inside write:
export PYTHONPATH=$PYTHONPATH:~/gnuradio/lib/python2.7/dist-packages
export LD LIBRARY PATH=$LD LIBRARY PATH:~/gnuradio/lib
save with Ctrl+X than Y and Enter.
chmod +x setEnviroment.sh
source gnuradio/setup_env.sh
sudo apt install libcanberra-gtk-module libcanberra-gtk3-module
```

installing out of tree modules from recipes

```
pybombs install gr-ham
cd gnuradio/src/
rm -rf gr-iqbal/
git clone -b gr3.7 https://github.com/osmocom/gr-iqbal.git
cd
pybombs install gr-iqbal
sudo apt-get install libssl-dev
open your web browser and go to https://cmake.org/download/
Download the latest stable release for Unix/Linux Source higher than 3.13
cmake-3.16.5.tar.gz
extract the downloaded file and navigate to it in the terminal (~/Downloads/cmake-3.16.5), enter these
commands to install:
./bootstrap && make && sudo make install
cd gnuradio/src/
rm -rf gr-osmosdr/
git clone -b gr3.7 <a href="https://git.osmocom.org/gr-osmosdr">https://git.osmocom.org/gr-osmosdr</a>
cd
pybombs install gr-osmosdr
sudo apt-get install libosmocore-dev
sudo apt-get install libosmocore
sudo apt-get install libsctp-dev libsctp1
pybombs install libosmocore
sudo apt-get install lksctp-tools
```

```
pybombs install gr-gsm
cd gnuradio/src/
rm -rf gr-foo/
git clone -b maint-3.7 https://github.com/bastibl/gr-foo
rm -rf gr-ieee-80211/
git clone -b maint-3.7 https://github.com/bastibl/gr-ieee802-11.git
mv gr-ieee802-11/ gr-ieee-80211/
pybombs install gr-ieee-80211
pybombs install gr-lte
pybombs install gr-mac
pybombs install gr-adsb
pybombs install gr-bluetooth
pybombs install gr-lpwan
pybombs install gr-radar
pybombs install gr-ofdm
pybombs install gr-satellites
pybombs install gr-tutorial
pybombs install gr-psk-burst
pybombs install gr-fsk-burst
```

pybombs run gnuradio-companion