

Nexa SafeLock

Product ID: NEX-1009 | Category: Keypad smart door lock

Description

- A keypad smart lock for a standard residential deadbolt. It offers temporary entry codes, auto-lock timing, activity history, and an emergency mechanical key. It should be installed only on a correctly aligned door.

Key features

- Up to 30 entry codes with optional expiration dates.
- Auto-lock timer and door-ajar reminder.
- Physical key override and battery-level alerts.

Setup

- Install with the door open and confirm the bolt moves freely by hand.
- Pair the lock in the app, then create an owner code and a backup code.
- Test lock and unlock actions before closing the door for normal use.

How to use

- Enter a valid code followed by the confirm key to unlock.
- Create a temporary code for guests and remove it after the visit.
- Replace all four AA batteries when the app sends a low-battery warning.

Error codes and resolutions

E1001: Bolt obstructed.

Open the door and test bolt movement; adjust strike alignment before retrying.

E1012: Code rejected.

Confirm the code is active in the app and enter it slowly before pressing confirm.

E1020: Battery critically low.

Use the mechanical key, then replace all batteries with new matching cells.