

③ When ~~P-N~~ ^{When Applied} Reverse Diode bias, the
→ this result in an increase in the potential barrier & resistance also.

→ minority carriers create reverse saturation current flow in beginning.

④ If applied voltage increases rapidly, there is increased kinetic energy due to minority charge carriers which affect majority charges. For this stage the diode breaks down, on the voltage is called breakdown voltage.

They may also destroy the diode.