How to login to wireless router

1. Open any Web Browser and enter 192.168.1.1 in the address bar as in the image.

2. Enter the details which are mentioned below & as shown in the image
   Default Account: useradmin
   Default Password: drlec

3. Now press login and the below page will appear

4. Click on the Network to open the wireless settings

5. Set your new wireless network name in SSID.
6. Set your new wireless password in WPA key.
7. Click on apply to set the new changes.
8. Now connect your device with the new wireless network name with new password.