## Complete this lab as follows:

- 1. Log in to the CISCO switch.
  - 1. Maximize the Google Chrome window for better viewing.
  - 2. In the Username and Password fields, enter **cisco** (the password is case sensitive).
  - 3. Select Log In.
- 2. Enable Jumbo Frames.
  - 1. From the left pane, expand and select **Port Management > Port Settings**.
  - 2. For Jumbo Frames, select **Enable**.
  - 3. Select Apply.
- 3. Save the changes to the switch's startup configuration file.
  - 1. From the upper right of the switch window, select **Save**.
  - 2. For Source File Name, make sure Running configuration is selected.
  - 3. For Destination File Name, make sure **Startup configuration** is selected.
  - 4. Select Apply.
  - 5. Select OK.
  - 6. Select **Done**.
- 4. Reboot the switch.
  - 1. From the left pane, under Administration, select Reboot.
  - 2. Select **Reboot** to reboot the switch immediately.
  - Select OK.
- 5. Log in to the Cisco switch and check switch statistics for any errors.
  - 1. In the Username and Password fields, enter **cisco** (the password is case sensitive).
  - 2. Select Log In.
  - From the left pane, expand and select Status and Statistics > RMON > Statistics.
  - 4. For *Interface*, use the drop-down list to select **GE28**.
  - 5. Review the statistics for Undersize, Oversize, Jabbers, and Collisions.
  - 6. Answer the questions.