Complete this lab as follows:

- 1. Add the cable modem to the workspace.
 - 1. Under Shelf, expand Routers.
 - 2. Drag the Cable Modem/Router from the shelf to the workspace.
 - 3. Select **Back** to switch to the back view of the cable modem.
- 2. Connect the modem to the WAN connection.
 - 1. Under Shelf, expand the **Cables** category.
 - 2. Select the Coaxial Cable, RG-6 cable.
 - 3. From the Selected Component pane:
 - Drag a Coaxial Type F connector to the applicable port on the cable modem.
 - Drag the other **Coaxial Type F** connector to the applicable port on the wall plate.
- 3. Connect the computer to the cable modem.
 - 1. Over the computer, select **Back** to switch to the back view of the computer.
 - 2. Under Shelf, select the Cat6a Cable, RJ45 cable.
 - 3. From the Selected Component pane:
 - Drag an RJ45 Shielded Connector to the Ethernet port on the cable modem.
 - Drag the other RJ45 Shielded Connector to the Ethernet port on the computer (not the Ethernet card in the slot).
- 4. Provide power to the modem.
 - 1. Under Shelf, select the **Power Adapter, AC to DC**.
 - 2. From the Selected Component pane:
 - Drag the **DC Power Connector** to the port on the cable modem.
 - Drag the AC Power Adapter end to the power outlet.
- 5. Verify that the computer is connected to the internet.
 - 1. On the monitor, select Click to view Windows 11.
 - 2. From the notification area, right-click the *Network* icon and select **Network and Internet settings**.

The diagram should indicate an active connection.