Electronic Devices

Modified By Niloy Goswami

Prepared By Dr. Md. Kabiruzzaman

Reference book:

Electronic Devices and Circuit Theory (Chapter-1)

Robert L. Boylestad and L. Nashelsky, (11th Edition)




Department of Electrical and Electronics Engineering American International University-Bangladesh(AIUB)



Reference Books

electronic devices and circuit theory

ROBERT L. BOYLESTAD | LOUIS NASHELSKY



FIFTH EDITION

MICROELECTRONIC CIRCUITS

Adel S. Sedra
University of Waterloo

Kenneth C. Smith

New York Oxford OXFORD UNIVERSITY PRESS 2004



Mid

CHART	ER 1: Semiconductor Diodes		2.11	Zener Diodes	91
				Voltage-Multiplier Circuits	98
1.1	Introduction	1		Practical Applications	101
1.2	Semiconductor Materials: Ge, Si, and GaAs	2		Summary Computer Analysis	111 112
1.3	Covalent Bonding and Intrinsic Materials	3	2.13	Computer Analysis	1112
1.4	Energy Levels	5	CHAPT	ER 3: Bipolar Junction Transistors	129
1.5	n-Type and p-Type Materials	7	3.1	Introduction	129
1.6	Semiconductor Diode	10	3.2	Transistor Construction	130
			3.3	Transistor Operation	130 131
1.7	Ideal Versus Practical	20	3.4 3.5	Common-Base Configuration Common-Emitter Configuration	136
1.8	Resistance Levels	21	3.6	Common-Collector Configuration	143
1.9	Diode Equivalent Circuits	27	3.7	Limits of Operation	144
1.10	Transition and Diffusion Capacitance	30	3.8	Transistor Specification Sheet	145
1.11	Reverse Recovery Time	31	3.9	Transistor Testing	149
	Diode Specification Sheets	32		Transistor Casing and Terminal Identification	151
1.12	•		3.11	Transistor Development	152 154
1.13	Semiconductor Diode Notation	35		Summary Computer Analysis	155
1.14	Diode Testing	36	3.13	Computer Analysis	155
1.15	Zener Diodes	38	CHAPT	ER 4: DC Biasing-BJTs	160
1.16	Light-Emitting Diodes	41	4.1	Introduction	160
1.17		48	4.2	Operating Point	161
		49	4.3	Fixed-Bias Configuration	163
1.10	Computer Analysis	49	4.4	Emitter-Bias Configuration Voltage-Divider Bias Configuration	169 175
			4.5 4.6	Collector Feedback Configuration	181
СНАРТ	ER 2: Diode Applications	55	4.7	Emitter-Follower Configuration	186
			4.8	Common-Base Configuration	187
2.1	Introduction	55	4.9	Miscellaneous Rias Configurations	189
2.2	Load-Line Analysis	56	4.10	Summary Table	192
2.3	Series Diode Configurations	61	4.11	Design Operations	194
2.4	Parallel and Series-Parallel Configurations	67	4.12	Multiple BJT Networks Current Mirrors	199 205
2.5	AND/OR Gates	70	4.14	Current Source Circuits	208
2.6	Sinusoidal Inputs; Half-Wave Rectification	72	4.15	pnp Transistors	210
	Full-Wave Rectification		4.16	Transistor Switching Networks	211
2.7		75		Troubleshooting Techniques	215
2.8	Clippers	78		Bias Stabilization	217
2.9	Clampers	85		Practical Applications Summary	226 233
2.10	Networks with a dc and ac Source	88		Computer Analysis	235
			7.21		

Final

CHAPTER 5: BJT AC Analysis		253	CHAPTER 7: FET Biasing	422
5.1	Introduction	253	7.1 Introduction	422
5.2	Amplification in the AC Domain	253	7.2 Fixed-Bias Configuration	423
5.3	BJT Transistor Modeling	254	7.3 Self-Bias Configuration	427
5.4	The re Transistor Model	257	7.4 Voltage-Divider Biasing	431
5.5	Common-Emitter Fixed-Bias Configuration	262	7.5 Common-Gate Configuration	436
5.6	Voltage-Divider Bias	265	7.6 Special Case $V_{GS_Q} = 0 \text{ V}$	439
5.7	CE Emitter-Bias Configuration	267	7.7 Depletion-Type MOSFETs	439
5.8	Emitter-Follower Configuration	273	7.8 Enhancement-Type MOSFETs	443
5.9	Common-Base Configuration	277	7.9 Summary Table	449
5.10	Collector Feedback Configuration	279	7.10 Combination Networks	449
5.11	Collector DC Feedback Configuration	284	7.11 Design	452
5.12	Effect of R_L and R_S	286	7.12 Troubleshooting	455
5.13	Determining the Current Gain	291	7.13 p-Channel FETs	455
5.14	Summary Tables	292	7.14 Universal JFET Bias Curve	458
5.15	Two-Port Systems Approach	292	7.15 Practical Applications	461
5.16	Cascaded Systems	300	7.16 Summary	470
5.17	Darlington Connection	305	7.17 Computer Analysis	471
5.18	Feedback Pair	314		
5.19	The Hybrid Equivalent Model	319	CHAPTER 8: FET Amplifiers	481
5.20	Approximate Hybrid Equivalent Circuit	324	8.1 Introduction	481
5.21	Complete Hybrid Equivalent Model	330	8.2 JFET Small-Signal Model	482
5.22	Hybrid # Model	337	8.3 Fixed-Bias Configuration	489
5.23	Variations of Transistor Parameters	338	8.4 Self-Bias Configuration	492
5.24	Troubleshooting	340	8.5 Voltage-Divider Configuration	497
5.25	Practical Applications	342	8.6 Common-Gate Configuration	498
5.26	Summary	349	8.7 Source-Follower (Common-Drain) Configuration	501
5.27	Computer Analysis	352	8.8 Depletion-Type MOSFETs	505
			8.9 Enhancement-Type MOSFETs	506
CHAPT	ER 6: Field-Effect Transistors	378	8.10 E-MOSFET Drain-Feedback Configuration	507
6.1	Introduction	378	8.11 E-MOSFET Voltage-Divider Configuration	510
6.2	Construction and Characteristics of JFETs	379	8.12 Designing FET Amplifier Networks	511
6.3	Transfer Characteristics	386	8.13 Summary Table	513
6.4	Specification Sheets (JFETs)	390	8.14 Effect of R_L and $R_{\rm sig}$	516
6.5	Instrumentation	394	8.15 Cascade Configuration	518
6.6	Important Relationships	395	8.16 Troubleshooting	521
6.7	Depletion-Type MOSFET	396	8.17 Practical Applications	522
6.8	Enhancement-Type MOSFET	402	8.18 Summary	530
6.9	MOSFET Handling	409	8.19 Computer Analysis	531
6.10	VMOS and UMOS Power and MOSFETs	410	, , , , , , , , , , , , , , , , , , , ,	
6.11		411		
	MESFETs	412		
6.13	Summary Table	414		

Introduction

One of the noteworthy things about this field, as in many other areas of technology, is how little the fundamental principles change over time. Systems are incredibly smaller, current speeds of operation are truly remarkable, and new gadgets surface every day, leaving us to wonder where technology is taking us.

- The miniaturization that has occurred in recent years leaves us to wonder about its limits.
- Complete systems now appear on wafers thousands of times smaller than the single element of earlier networks.
- The first integrated circuit (IC) was developed by Jack Kilby while working at Texas Instruments in 1958.




Figure 1.1: Jack St. Clair Kilby, inventor of the integrated circuit and co-inventor of the electronic handheld calculator.

(Courtesy of Texas Instruments.)

Introduction Contd.

- □Today, the Intel® CoreTM i7 Extreme Edition Processor of Fig. 1.2 has 731 million transistors in a package that is only slightly larger than a 1.67 sq. inches.
- ☐ In 1965, Dr. Gordon E. Moore presented a paper predicting that the transistor count in a single IC chip would double every two years.
- □Now, more than 45 years, later we find that his prediction is amazingly accurate and expected to continue for the next few decades.
- ☐ Intel Core i9-11900K: 17 billion transistors
- □Samsung Galaxy S23 Ultra: 16 billion transistors
- Apple Watch Series 9: 5.6 billion transistors





Figure 1.2: Intel® Core™ i7 Extreme Edition Processor.

Semiconductor Materials: Ge, Si & GaAs

- **❖**The construction of every discrete (individual) solid-state (hard crystal structure) electronic device or integrated circuit begins with a semiconductor material of the highest quality.
- ❖Semiconductors are a special class of elements having a conductivity between that of a good conductor and that of an insulator.
- ❖In general, semiconductor materials fall into one of two classes: single-crystal and compound.
- **❖**Single-crystal semiconductors such as germanium (Ge) and silicon (Si) have a <u>repetitive crystal structure</u>, whereas compound semiconductors such as gallium arsenide (GaAs), cadmium sulfide (CdS), gallium nitride (GaN), and gallium arsenide phosphide (GaAsP) are constructed of <u>two or more semiconductor materials of different atomic structures</u>.
- **❖**The three semiconductors used most frequently in the construction of electronic devices are *Ge, Si, and GaAs.*

Semiconductor Materials: Ge, Si & GaAs Contd.

Germanium:

- In the first few decades following the <u>discovery of the diode</u> in 1939 and <u>the transistor</u> in 1947 <u>germanium was used almost exclusively</u> because it was relatively easy to find and was available in fairly large quantities.
- It was also relatively <u>easy to refine to obtain very high levels of purity</u>, an important aspect in the fabrication process.
- However, it was discovered in the early years that diodes and transistors constructed using germanium as the base material suffered from low levels of reliability due primarily to its sensitivity to changes in temperature.

Semiconductor Materials: Ge, SI & GaAs Contd.

Silicon:

- At the time, scientists were aware that another material, <u>silicon, had improved temperature sensitivities</u>, but the refining process for manufacturing silicon of very high levels of purity was still in the development stages.
- Finally, however, in 1954 the first silicon transistor was introduced, and silicon quickly became the semiconductor material of choice.
- Not only is silicon <u>less temperature sensitive</u>, but it is one of the most <u>abundant materials on earth</u>, removing any concerns about availability.


Semiconductor Materials: Ge, SI & GaAs Contd.

Gallium Arsenide:

- As time moved on, however, the field of electronics became increasingly sensitive to issues of speed.
- The result was the development of the first GaAs transistor in the early 1970s.
- This new transistor had <u>speeds of operation up to five times that of Si</u>.
- GaAs was <u>more difficult to manufacture at high levels of purity</u>, was <u>more expensive</u>, and had little design support in the early years of development.
- However, in time <u>the demand for increased speed</u> resulted in more funding for GaAs research, to the point that today it is <u>often used as the base material for new high-speed</u>, <u>very large scale integrated (VLSI) circuit designs</u>.

Covalent Bonding and Intrinsic Materials

- ➤ To fully appreciate why Si, Ge, and GaAs are the semiconductors of choice for the electronics industry requires some understanding of the atomic structure of each and how the atoms are bound together to form a crystalline structure.
- > The fundamental components of an atom are the electron, proton, and neutron.
- In the lattice structure, <u>neutrons and protons form the nucleus</u> and <u>electrons appear in fixed orbits around the nucleus</u>. The Bohr model for the three materials is provided in Fig. 1.3.



- As indicated in Fig. 1.3, <u>silicon has 14 orbiting electrons</u>, <u>germanium has 32 electrons</u>, <u>gallium has 31 electrons</u>, and <u>arsenic has 33</u> orbiting electrons (the same arsenic that is a very poisonous chemical agent).
- For germanium and silicon there are four electrons in the outermost shell, which are referred to as <u>valence electrons</u>.
- Gallium has three valence electrons and arsenic has five valence electrons.
- Atoms that have four valence electrons are called tetravalent, those with three are called trivalent, and those with five are called pentavalent.
- The term valence is used to indicate that the potential (ionization potential) required to remove any one of these electrons from the atomic structure is significantly lower than that required for any other electron in the structure.

*In a pure silicon or germanium crystal the four valence electrons of one atom form a bonding arrangement with four adjoining atoms, as shown in Fig. 1.4.

This bonding of atoms, strengthened by the sharing of electrons, is called covalent bonding.




FIG. 1.4

Covalent bonding of the silicon atom.

- **❖**Because GaAs is a compound semiconductor, there is sharing between the two different atoms, as shown in Fig. 1.5.
- **❖**Each atom, gallium or arsenic, is surrounded by atoms of the complementary type. There is still a sharing of electrons similar in structure to that of Ge and Si, but now five electrons are provided by the As atom and three by the Ga atom.




FIG. 1.5

Covalent bonding of the GaAs crystal.

- **❖**Although the covalent bond will result in a stronger bond between the valence electrons and their parent atom, <u>it is still possible for the valence electrons to absorb sufficient kinetic energy</u> from external natural causes to <u>break the covalent bond and assume the "free" state.</u>
- *The term free is applied to any electron that has separated from the fixed lattice structure and is very sensitive to any applied electric fields such as established by voltage sources or any difference in potential.
- ❖The external causes include effects such as <u>light energy in the form of photons</u> and <u>thermal energy (heat) from the surrounding medium.</u>
- **❖**At room temperature there are approximately 1.5 * 10¹⁰ free carriers in 1 cm³ of intrinsic silicon material, that is, 15,000,000,000 (15 billion) electrons in a space smaller than a small sugar cube an enormous number.

- **❖** <u>The term intrinsic is applied</u> to any semiconductor material that has been carefully <u>refined to reduce the number of impurities to a very low level</u>-essentially as pure as can be made available through modern technology.
- **The free electrons in a material due only to external causes are referred to as intrinsic carriers.** Table 1.1 compares the number of intrinsic carriers per cubic centimeter (abbreviated n_i) for Ge, Si, and GaAs.

TABLE 1.1
Intrinsic Carriers n_i

Semiconductor	Intrinsic Carriers (per cubic centimeter)
GaAs	1.7×10^{6}
Si	1.5×10^{10}
Ge	2.5×10^{13}

TABLE 1.2

Relative Mobility Factor μ_n

Semiconductor	$\mu_n (\text{cm}^2/\text{V·s})$
Si	1500
Ge	3900
GaAs	8500


- > It is interesting to note that Ge has the highest number and GaAs the lowest.
- ➤ In fact, Ge has more than twice the number as GaAs.
- ➤ The number of carriers in the intrinsic form is important, but other characteristics of the material are more significant in determining its use in the field.
- \triangleright One such factor is <u>the relative mobility (μ_n) </u> of the free carriers in the material, that is, <u>the ability of the free carriers to move throughout the material.</u>
- ➤ Table 1.2 clearly reveals that the free carriers in GaAs have <u>more than five</u> <u>times the mobility</u> of free carriers in Si, a factor that results in response times using GaAs electronic devices that can be up to five times those of the same devices made from Si.
- Note also that free carriers in Ge have <u>more than twice the mobility of</u> <u>electrons</u> in Si, a factor that results in the continued use of Ge in high-speed radio frequency applications.

- **Extremely high levels of purity are necessary because the addition of one part of impurity (of the proper type) per million in a wafer of silicon material can** <u>change that material from a relatively poor conductor to a good conductor of electricity.</u>
- *The ability to change the characteristics of a material through this process is called doping, something that germanium, silicon, and gallium arsenide readily and easily accept.
- **One** important and interesting <u>difference between semiconductors</u> and conductors is their reaction to <u>the application of heat.</u>

- For conductors, the resistance increases with an increase in heat. This is because the numbers of carriers in a conductor do not increase significantly with temperature, but their vibration pattern about a relatively fixed location makes it increasingly difficult for a sustained flow of carriers through the material.
- Materials that react in this manner are said to have a <u>positive</u> <u>temperature coefficient.</u>
- Semiconductor materials, however, exhibit an <u>increased level of</u> <u>conductivity with the application of heat</u>. As the temperature rises, an increasing number of valence electrons absorb sufficient thermal energy to break the covalent bond and to contribute to the number of free carriers.
- > Semiconductor materials have a <u>negative temperature coefficient</u>.

Energy Levels

- Within the atomic structure of each and every isolated atom there are specific energy levels associated with each shell and orbiting electron, as shown in Fig. 1.6.
- The energy levels associated with each shell will be different for every element.
- The farther an electron is from the nucleus, the higher is the energy state, and any electron that has left its parent atom has a higher energy state than any electron in the atomic structure.



Energy Levels Contd.

- An electron in the valence band of silicon must absorb more energy than one in the valence band of germanium to become a free carrier.
- Similarly, an electron in the valence band of GaAs must gain more energy than one in Si or Ge to enter conduction band.




FIG. 1.6

Energy levels: (a) discrete levels in isolated atomic structures; (b) conduction and valence bands of an insulator, a semiconductor, and a conductor.

n-Type & p-Type Materials

- **❖**The <u>characteristics of a semiconductor material can be altered</u> significantly by the <u>addition of specific impurity atoms</u> to the relatively pure semiconductor material.
- **❖**These impurities, although only <u>added at 1 part in 10 million</u>, can <u>alter the band structure sufficiently</u> to totally change the electrical properties of the material.
- **A** semiconductor material that has been <u>subjected to the doping</u> <u>process</u> is called an <u>extrinsic material</u>.
- **❖**There are two extrinsic materials of immeasurable importance to semiconductor device fabrication: <u>n -type and p -type materials.</u>

n-Type Material

- **❖**Both n -type and p -type materials are formed by <u>adding a predetermined number</u> <u>of impurity atoms</u> to a silicon base.
- **❖**An n -type material is created by introducing impurity elements that have <u>five valence electrons (pentavalent)</u>, such as antimony, arsenic, and phosphorus. (Group V elements in Periodic Table)
- **❖**The effect of such impurity elements is indicated in Fig. 1.7 (using antimony as the impurity in a silicon base).





FIG. 1.7
Antimony impurity in n-type material.

n-Type Material Contd.

- ✓ Note that the four covalent bonds are still present. There is, however, an additional fifth electron due to the impurity atom, which is unassociated with any particular covalent bond.
- ✓ This remaining electron, loosely bound to its parent (antimony) atom, is relatively free to move within the newly formed n -type material.
- ✓ Diffused impurities with five valence electrons are called <u>donor atoms.</u>
- ✓ It is important to realize that even though a <u>large number of free carriers</u> have been established in the n -type material, it is <u>still electrically neutral</u> since ideally the <u>number of positively charged protons in the nuclei is still equal to the number of free and orbiting negatively charged electrons</u> in the structure.

n-Type Material Contd.

- **❖Those** <u>free electrons due to the added</u> <u>impurity sit at this energy level</u> and have less difficulty absorbing a sufficient measure of thermal energy to move into the conduction band at room temperature.
- **❖**The result is that at room temperature, there are a large number of carriers (electrons) in the conduction level. and the material conductivity of the increases significantly.



Effect of donor impurities on the energy band structure.

p-Type Material

- **❖**The p -type material is formed by doping a pure germanium or silicon crystal with impurity atoms having three valence electrons.
- The elements most frequently used for this purpose are boron, gallium, and indium. (Group III elements in Periodic Table)
- **❖**Note that there is now an <u>insufficient</u> <u>number of electrons to complete the</u> <u>covalent bonds</u> of the newly formed lattice.




FIG. 1.9

Boron impurity in p-type material.

p-Type Material Contd.


- □The resulting vacancy is called a hole and is represented by a small circle or a plus sign, indicating the absence of a negative charge.
- □Since the resulting vacancy will readily accept a free electron:

The diffused impurities with three valence electrons are called *acceptor atoms*.

□ The resulting p -type material is <u>electrically neutral</u>, for the same reasons described for the n -type material.


Electron vs Hole Flow

The effect of the hole on conduction is shown in Fig. If a valence electron <u>acquires sufficient kinetic energy to break its covalent bond</u> and <u>fills the void created by a hole</u>, then a vacancy, or hole, will be created in the covalent bond that released the electron.



Majority & Minority Carriers

- ❖In an n-type material (Fig. a) the electron is called the majority carrier and the hole the minority carrier.
- **❖**In a p-type material the hole is the majority carrier and the electron is the minority carrier.



Thank You