USER MANUAL |

## CONTROL PANEL

SAFET

DIAGRAMS

INSTALLATION

FILTERS

CARE

TROUBLESHOOTING

PURCHASE INFO



## A) LEFT FAN:

To adjust the intensity of the left fan, push in and let out on the knob on the far LEFT side which will allow the knob to extend outwards from the control panel. Each fan has 4 speed settings. Turning the knob once clockwise will start the fan in the lowest speed setting. Continuing to turn the knob clockwise will allow the fan to advance to the highest setting. Turning counter clockwise will return the fan to the original position and stop the fan. Pushing the knob in and releasing will return the knob to the original flush mounted position.

## B) LIGHTS:

To turn on the lights, push in and let out on the knob in the CENTER which will allow the knob to extend outwards from the control panel. Turning the knob clockwise will turn on the lights in the lowest setting. Continuing to turn the knob clockwise will allow the lights to advance to the highest setting. Turning counter clockwise will return the lights to the original position and turn them off. Pushing the knob in and releasing will return the knob to the original flush mounted position.

## C) RIGHT FAN:

To adjust the intensity of the right fan, push in and let out on the knob on the far RIGHT side which will allow the knob to extend outwards from the control panel. Each fan has 4 speed settings. Turning the knob once clockwise will start the fan in the lowest speed setting. Continuing to turn the knob clockwise will allow the fan to advance to the highest setting. Turning counter clockwise will return the fan to the original position and stop the fan. Pushing the knob in and releasing will return the knob to the original flush mounted position.