CONTROL PANEL

SAFETY

DIAGRAMS

INSTALLATION

FILTERS

CARE

TROUBLESHOOTING

PURCHASE INFO

Light Fan1 Fan2 Display Fan 3 Fan 4 Power

Light: Turns LED lights on and off.

Fan 1: Adjusts fan to the lowest speed.

Fan 2: Adjusts fan to the second level speed.

Display: Displays icon for power, light fan and time. Time can be set by the following method:

Hold power button for 3 seconds until the hour display flashes.

Press "Fan 1" to increase hour. Press "Fan 2" to decrease hour.

While hour is still flashing, touch the power button to move to minutes setting

Press "Fan 1" to increase minutes. Press "Fan 2" to decrease minutes.

While minutes are still flashing touch the power button to finish setting clock.

Fan 3: Adjusts fan to the third level speed.

Fan 4: Adjusts fan to the fourth or highest level speed.

Power: Turns unit on or off and adjusts time setting.