

RoboArm X2 · Product FAQ (sample)

What payload can the X2 lift? The RoboArm X2 lifts up to 7.5 kg at full reach (850 mm).

What is the repeatability? Plus or minus 0.03 mm under ISO 9283 test conditions.

Maintenance

How often does the X2 need servicing? Every 4,000 operating hours or 12 months, whichever comes first.

Which lubricant is used? Only the sealed NW-Grease 2 cartridges; other greases void the warranty.

Warranty and support

How long is the warranty? 36 months on parts and labour, extendable to 60 months with a service plan.

Error code E-4711 means the joint-3 encoder lost calibration; run the recalibration wizard.