dim

To Study dyferent types of cabus for giving connections

STP shillded Iwisted pair
Coopial cable

Fibre Optical Cable

. UTP

Catigosy -3 10 bps data transmission de :

Cheaper day to install

a Diracly: alumpelo dos, leber - pg salop 003)

More prone to emt

Uses:

cotos; lo Base Ethuret or off the fels

Catigory -5 upto 100 mbps data fransmission

Fast Ethernet, Grégolit Ethanet

. thuckes work atvos gi is

mi: (04.91.020.020.041);

Catigory se 19698 data Hansmission

Uses: fast Ethernet

2. STP

cotegory 6 6 a 10 Gebps data transmission 10 Geb ethernet

```
88TP
 3.
       category 1 10 96 ps vata transmission
              10 GB Ethunut
     Adv: Shielded, faster than OTP
      Dosadu: Expeniue
                   new, aven shorter distance
    coaxial cable
4.
       RG1-6, RG1-59, RG1-11 Category
        10-100 mbps data transmission
         Television Network
      Digh ospeed internet connection
6. Tibre optical cable
 Single Et Multimode Category
   100 gbps data transmission
     Adv:
          high speed of Bandwidts
         Copenius
                      toine, rejudencing back to the
                       from top to bottom, one
                             A and other in B.
        organ it the order in correct, your man
     a dies and in they eleck out touchter, pentition
       to creat one hard. Itsed of confect as
     in proposer warther pury must also prisoly
```

order, to do so hold plug will all of the

facing away and board gold from facing

18/2h

Coeating Cooks Over | Stright

Required Equipments

Athernet carrier conting costs is destisfied to a gigabit support but cat's carbling works as well, over shorter distance

2 plug Shield

Step 1: To start construction, start the threading shield onto the cable

Steps: Strip approximately 1.5 cm of cable from both ends. The examping tool has round area to complete.

Step 2: After untangle the comes, 4 twisted pairs, rejevencing back to the sheet, arranging from top to bottom. One should be in arrangement A and other in B.

Step4: It the order is correct, join them in a line and in they stick out towther, jointhem to water even level. The dys aspect is placing into PITHS plug without menaging the order, to do so hold plug with all state facing away and have gold from facing upwards

Stept: push the calole right is, the notch at the end of the plug had to be gurt over calde shielden 8 tept: After the wires are correctly sitting enrich the plug, where into the cramping tool and pushdoe 8 tept: Repeat the similar isleps to create our sover cables.

288/24 PO