IIC2343 - Arquitectura de Computadores

Ejercicios Propuestos 1

Profesor: Yadran Eterovic

Ayudantes: Daniel Leal, Jessica Hormazabal, Felipe Valenzuela, Ariel Martinez, Alfonso Irarrazaval, Cristobal Herreros, José Wielandt, Tomás Rivera.

Preguntas

- 1. Utilice la ISA de la arquitectura MIPS del anexo para escribir un programa que a partir de un número K pueda guardar los subsiguientes n números en los espacios que le siguen a la ubicación de K. Considere que K y n son datos guardados en los espacios de memoria 10 y 9 respectivamente.
- 2. Modifique una ALU de un bit para que acepte operaciones lógicas, suma y resta con un tercer input. En otras palabras, si se tiene de entradas los inputs A y B, modifique la ALU con tal de aceptar un input C con el que se puedan realizar operaciones tipo A+B, A+C, entre otros. Puede utilizar todos los componentes y señales que desee.
- 3. Crea un programa en assembly, utilizando la ISA de la arquitectura MIPS, que multiplique dos números (considere signo).
- 4. Crea un programa en assembly, utilizando la ISA de la arquitectura MIPS, que eleve un número a otro (aka: a^b).
- 5. [TEÓRICO] En los lenguajes de programación de más alto nivel tenemos la capacidad de pasar parámetros a las funciones que llamamos para que ese ejecuten. Comenta: ¿cómo podríamos hacer lo mismo pero con un programa escrito en assembly?
- 6. [TEÓRICO] ¿Qué propiedades tiene el número 10_b en cualquier base b? $(b > 1, b \in Naturales)$
- 7. [TEÓRICO] ¿Cómo puedo saber cuántos "bits" necesito para representar un natural en cualquier base? ¿Y con un entero?
- 8. Asuma que t0 contiene el valor 0x00101000 ¿Cuál es el valor final de t2 después de seguir las siguientes instrucciones?

```
slt $t2, $0, $t0
bne $t2, $0, ELSE
j DONE
ELSE: addi $t2, $t2, 2
DONE:
```

Anexo

Category	Instruction	Example	Meaning	Comments
Arithmetic	add	add \$s1,\$s2,\$s3	\$s1 = \$s2 + \$s3	Three register operands
	subtract	sub \$s1,\$s2,\$s3	\$s1 = \$s2 - \$s3	Three register operands
	add immediate	addi \$s1,\$s2,100	\$s1 = \$s2 + 100	Used to add constants
Data transfer	load word	lw \$s1,100(\$s2)	\$s1 = Memory[\$s2 + 100]	Word from memory to register
	store word	sw \$s1,100(\$s2)	Memory[$$s2 + 100$] = $$s1$	Word from register to memory
	load half	Th \$s1,100(\$s2)	\$s1 = Memory[\$s2 + 100]	Halfword memory to register
	store half	sh \$s1,100(\$s2)	Memory[\$s2 + 100] = \$s1	Halfword register to memory
	load byte	lb \$s1,100(\$s2)	\$s1 = Memory[\$s2 + 100]	Byte from memory to register
	store byte	sb \$s1,100(\$s2)	Memory[$$s2 + 100$] = $$s1$	Byte from register to memory
	load upper immed.	ไนว์ \$s1,100	\$s1 = 100 * 2 ¹⁶	Loads constant in upper 16 bits
Logical	and	and \$s1,\$s2,\$s3	\$s1 = \$s2 & \$s3	Three reg. operands; bit-by-bit AND
	or	or \$s1,\$s2,\$s3	\$s1 = \$s2 \$s3	Three reg. operands; bit-by-bit OR
	nor	nor \$s1,\$s2,\$s3	\$s1 = ~ (\$s2 \$s3)	Three reg. operands; bit-by-bit NOR
	and immediate	andi \$s1,\$s2,100	\$s1 = \$s2 & 100	Bit-by-bit AND reg with constant
	or immediate	ori \$s1,\$s2,100	\$s1 = \$s2 100	Bit-by-bit OR reg with constant
	shift left logical	sll \$s1,\$s2,10	\$s1 = \$s2 << 10	Shift left by constant
	shift right logical	srl \$s1,\$s2,10	\$s1 = \$s2 >> 10	Shift right by constant
Conditional branch	branch on equal	beq \$s1,\$s2,25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch
	branch on not equal	bne \$s1,\$s2,25	if (\$s1 != \$s2) go to PC + 4 + 100	Not equal test; PC-relative
	set on less than	slt \$s1,\$s2,\$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than; for beq, bne
	set less than immediate	slti \$s1,\$s2,100	if (\$s2 < 100) \$s1 = 1; else \$s1 = 0	Compare less than constant
Uncondi- tional jump	jump	j 2500	go to 10000	Jump to target address
	jump register	jr \$ra	go to \$ra	For switch, procedure return
	jump and link	jal 2500	\$ra = PC + 4; go to 10000	For procedure call