

EXP SCALE REMOVER

CLEANER AND DESCALER

DANGER

May be corrosive to metals. Causes severe skin burns and eye damage.

KEEP OUT OF REACH OF CHILDREN

NET CONTENTS: 1 1 5 20 35 55 Gallon(s)



EXP SCALE REMOVER

SHARE

P.O. Box 245013
Milwaukee, WI 53224
(800) 776-7192
www.sharecorp.com



DANGER:

May be corrosive to metals. Causes severe skin burns and eye damage.

Keep only in original container. Do not breathe mist, spray. Wash thoroughly after handling. Wear eye protection, protective gloves. Wash contaminated clothing before reuse.

IF SWALLOWED Rinse mouth to NOT induce vomiting.
IF ONISKIN (ORH AIR): Take off immediately all contaminated clothing. Rinselskin with water/shower.
IF INHALED: Remove person to fresh air and keep comfortable for breathing.

The EVES: Drise cautiously with water for several ninktes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a doctor, a POISON CENTER.

Absorb spillage to prevent material damage.

Store locked up. Store in corrosive resistant container with a resistant inner liner.

Dispose of contents/container to comply with local/regional/national/international regulations.

For industrial and commercial use only.
For additional information, see Safety Data Sheet

NFPA® RATINGS:

Health: 3; Flammability: 0; Reactivity: 1

CONTAINS/CAS#:

Water/7732-18-5; Hydrochloric Acid/7647-01-; Tallow Alkyldiamine Ethoxylate/61790-85-0: Dve/Mixture

TRIDENT EXP SCALE REMOVER is a water tower cleaner and descaler for use in cooling towers and boilers. Its formulation dissolves and removes rust, lime, scale, corrosion, scum and mineral deposits on chillers, condensers and heat exchangers. TRIDENT EXP SCALE REMOVER is a non-flammable inhibited cleaner and descaler that does not produce toxic fumes or use dangerous solvents. Keep your cooling towers and boilers operating at peak performance by letting Share's TRIDENT EXP SCALE REMOVER dissolve and remove the damaging effects of rust, corrosion and scale.

DIRECTIONS:

Start with an initial dosage of 10 – 20% **TRIDENT EXP SCALE REMOVER** solution by estimating the total gallons of water in the system.

Cooling Towers and Chillers: Drain system, manually clean and leave open to air. Add the correct amount of TRIDENT EXP SCALE REMOVER to drop the pH between 3 – 1.5. Circulate this diluted TRIDENT EXP SCALE REMOVER by pumping through system. Maintain the pH test at a pH of 3 – 1.5 for 4 – 6 hours. Following the cleaning process, drain and flush the system to the pH of the makeup water. Refill with water, adding TRIDENT WATER TREATMENT products to guard system against scale and corrosion. Do not drain system to any surface that may be attacked by acid.

Other systems: Do not heat above 160°F.
Condensers and Heat Exchangers: Use 1 part
concentrate to 5 to 10 parts of water. Circulate solution
through system for approximately 4 hours.

Rollers: Use 1 part to 5 = 10 parts water, depending upon

Boilers: Use 1 part to 5 - 10 parts water, depending upon scale and speed required to perform the job.

WARNING: This product contains, or may contain, trace quantities of a substance(s) known to the state of California to cause cancer and/or reproductive toxicity.

(Z)

0141 060415