Installing the Arduino Software

If you are using your own computer for this activity, you must download the correct software before we can start programming

First, at:

https://www.arduino.cc/en/main/software

 Download the correct version of the Arduino Software (a.k.a. Arduino IDE) for your computer

Installing Adafruit Packages Part 2

- 1) Navigate back to the main page of the ArduinoIDE
- 2) Select 'Tools', then hover over 'Board: ', then click 'Boards Manager'
- 3) Select 'Contributed' in the top left drop down menu
- 4) Click 'Adafruit AVR Boards by Adafruit' and select 'Install'
- 5) Close and reopen ArduinoIDE to see the new installed packages



Installing Adafruit Packages

We must download the correct software before we can start programming

Installation instructions at:

https://learn.adafruit.com/adafruit-arduino-ide-setup/arduino-1-dot-6-x-ide

- 1) Open the Arduino application and either 'File' or 'Arduino' in the top left corner, then click 'Preferences'
- 2) Type 'https://www.adafruit.com/package_adafruit_index.json' into the 'Additional Board Manager' slot

Additional Boards Manager URLs: https://www.adafruit.com/package_adafruit_index.json

Setting up ArduinoIDE

Before we start programming our Arduino Trinket we must first set the AduinoIDE to match which microcontroller (tiny computer!) we are using

- 1) Click 'Tools at the top of the screen
- Hover over 'Board: ' and click on 'Adafruit Trinket (ATtiny85 @ 8 MHz)' near the bottom of the list
- Click 'Tools' at the top of the screen again
- Hover over 'Programmer' and click on 'USBtinyISP'

