







5305  سيشيو تريمنج	H6306  فورد هينج و لوك	H6307  বেনچلیر	H6308  اینسترومنت پانل	H6309  لوف کونسول و کونسول بکس
5310  فرونٹ وینڈ شیلڈ	H7301  لوف پانل	H7302  لوف تريمنج	H7401  فلاور پانل	H7402  فلاور فٹینگ
7403  دور تريمنج	H7601  دور ساید پانل	H7602  دور ساید فٹینگ	H7603  دور ساید تريمنج	H7604  دور ساید وینڈ
7801  دور پانل	H7803  دور تريمنج	H7805  دور پانل و وینڈ	H7810  دور تريمنج و دور	H8001  فرونٹ دور پانل

Chassis and transmission for Nissan Safari, 10.1991 - 08.1993 production period



Frame / Series	WG Y60 / Y60	body	W/LR (wagon standard roof)	engine	TB42E (4200 gasoline EGI)	number of doors	4D (4-door)
Manufacture period	10.1991 - 08.1993	grade	GR (Granroad)	transmission	MT (manual transmission)	ｼﾌﾄﾀﾞﾝｽ	F5 (floor shift 5-speed)

Parts groups: [Engine and fuel system](#) | [Body parts](#) | [Chassis and transmission](#) | [Electrics](#) | [Accessories](#)




Choose required parts subgroup:

A1103  マウンティング D3102  トルク コンバーターとケース D3107  オート トランスミッション フィッティング D3301  トランスファ	D3001  ｸﾞﾗｯﾁ ｳﾞｴｲｽｸ と ｶﾊﾞｰ D3103  ｵｲﾙ ｵﾝﾌﾟとｸﾞﾗｯﾁ D3201  ﾄﾗﾝｽﾐｯｼｮﾝ ｱｯｾﾝﾌﾞﾘ- D3302  ﾄﾗﾝｽﾐｯｼｮﾝ ｹｰｽ	D3003  ｸﾞﾗｯﾁ ﾏｽﾀ ﾘﾝｼﾞﾀ D3104  ﾌﾞﾗﾈﾀﾘ ｷﾞﾔ D3202  ﾄﾗﾝｽﾐｯｼｮﾝ ｹｰｽ D3303  ﾄﾗﾝｽﾐｯｼｮﾝ ｷﾞﾔ	D3004  ｸﾞﾗｯﾁ ｵﾍﾟﾚｰﾁﾝｸﾞ ｼﾘﾝﾀｰ D3105  ｺﾝﾄﾛｰﾙ ﾋﾞﾙﾌﾞ D3203  ﾄﾗﾝｽﾐｯｼｮﾝ ｷﾞﾔ D3304  ﾄﾗﾝｽﾐｯｼｮﾝ ｺﾝﾄﾛｰﾙ	D3101  ｵｰﾄﾏﾁｯｸ トﾗﾝｽﾐｯｼｮﾝ D3106  ｺﾝﾄﾛｰﾙ ﾍﾞｲﾌﾞ D3204  ｼﾌﾄ ｺﾝﾄﾛｰﾙ D3306  ﾘｱ P.T.O. AX10000Y60
---	--	---	---	---

[A1103 - engine & transmission mounting \(unit\)](#)
[D3001 - clutch disc & cover \(engine\)](#)
[D3003 - clutch master cylinder \(chassis\)](#)
[D3004 - clutch operating cylinder & piping \(unit\)](#)
[D3101 - auto transmission & transaxle assembly \(unit\)](#)
[D3102 - torque converter & case \(unit\)](#)
[D3103 - oil pump & clutch \(unit\)](#)
[D3104 - planetary gear \(unit\)](#)
[D3105 - control valve \(unit\)](#)
[D3106 - control switch \(unit\)](#)
[D3107 - auto transmission fitting \(unit\)](#)
[D3201 - transmission & transaxle assembly \(unit\)](#)
[D3202 - transmission case \(unit\)](#)
[D3203 - transmission gear \(unit\)](#)
[D3204 - shift control \(unit\)](#)
[D3301 - transfer assembly & mounting \(unit\)](#)
[D3302 - transfer case \(unit\)](#)
[D3303 - transfer gear \(unit\)](#)
[D3304 - transfer shift control \(unit\)](#)
[D3306 - rear P.T.O. \(unit\)](#)

D3307  ﾌﾛﾝﾄ ﾜｲﾝﾁ D3802  ﾘｱ ﾌｧｲﾅﾙ ﾉﾞﾗｲﾌ E4102  ﾘｱ ﾉﾞﾗｲﾌ F4001  ﾌﾛﾝﾄ ｱｸｽﾙ	D3401  ﾄﾗﾝｽﾐｯｼｮﾝ ｺﾝﾄﾛｰﾙ (MT) D3803  ﾌﾛﾝﾄ ﾉﾞﾗｲﾌ ﾉﾞﾗｲﾌ E4103  ｸﾗｯﾁ と ﾉﾞﾗｲﾌ ﾉﾞﾀﾞﾙ F4002  ﾘｱ ｱｸｽﾙ	D3402  ﾄﾗﾝｽﾌｧ ｺﾝﾄﾛｰﾙ E3601  ﾊｰｷﾝｸﾞ ﾉﾞﾗｲﾌ ｺﾝﾄﾛｰﾙ E4104  ﾌﾞﾚｰｷ ﾏｽﾀ ﾘﾝｼﾞﾀ F4003  ﾛｰﾄﾞ ﾉﾞｲｰﾙ	D3701  ﾌﾞﾛﾍﾞﾙ ﾉﾞﾗｲﾌ E3602  ｾﾝﾀｰ ﾉﾞﾗｲﾌ E4105  ﾌﾞﾚｰｷ ﾉﾞﾗｲﾌ F4801  ｽﾘｰﾁ ﾉﾞﾗｲﾌ D3801  ﾌﾛﾝﾄ ﾉﾞﾗｲﾌ E4101  ﾌﾛﾝﾄ ﾉﾞﾗｲﾌ E4106  ﾌﾞﾚｰｷ ﾉﾞﾗｲﾌ F4802  ｽﾘｰﾁ ﾉﾞﾗｲﾌ AX20000Y60
---	--	--	---

[D3307 - front winch \(chassis\)](#)
[D3401 - transmission control & linkage \(unit\)](#)
[D3402 - transfer control & linkage \(unit\)](#)
[D3701 - propeller shaft \(chassis\)](#)
[D3801 - front final drive \(unit\)](#)
[D3802 - rear final drive \(unit\)](#)
[D3803 - front drive shaft \(chassis\)](#)
[E3601 - parking brake control \(chassis\)](#)
[E3602 - center brake \(chassis\)](#)
[E4101 - front brake \(chassis\)](#)
[E4102 - rear brake \(chassis\)](#)
[E4103 - clutch & brake pedal \(chassis\)](#)
[E4104 - brake master cylinder \(chassis\)](#)
[E4105 - brake servo & servo control \(chassis\)](#)
[E4106 - brake piping \(chassis\)](#)
[F4001 - front axle \(chassis\)](#)
[F4002 - rear axle \(chassis\)](#)
[F4003 - road wheel & cap \(chassis\)](#)
[F4801 - steering gear \(chassis\)](#)
[F4802 - steering column \(chassis\)](#)

F4803  ｽﾘｰﾁ ﾉﾞﾗｲﾌ F5001  ﾌﾛｰﾑ	F4804  ｽﾘｰﾁ ﾉﾞﾗｲﾌ F5401  ﾌﾛﾝﾄ ﾉﾞﾗｲﾌ	F4805  ｽﾘｰﾁ ﾉﾞﾗｲﾌ F5402  ﾘｱ ﾉﾞﾗｲﾌ	F4806  ﾊﾞﾜ ﾉﾞﾗｲﾌ F5701  ｽﾘｰﾁ ﾉﾞﾗｲﾌ	F4807  ﾊﾞﾜ ﾉﾞﾗｲﾌ F5701  ｽﾘｰﾁ ﾉﾞﾗｲﾌ AX30000Y60
--	--	--	---	--

[F4803 - steering linkage \(chassis\)](#)
[F4804 - steering wheel \(trim\)](#)
[F4805 - steering column shell \(trim\)](#)
[F4806 - power steering bracket \(engine\)](#)
[F4807 - power steering control \(chassis\)](#)
[F5001 - frame \(chassis\)](#)
[F5401 - front suspension \(chassis\)](#)
[F5402 - rear suspension \(chassis\)](#)
[F5701 - spare tire carrier \(body\)](#)

Frame / Series	WGY60 / Y60	body	W/LR (wagon standard roof)	engine	TB42E (4200 gasoline EGI)	number of doors	4D (4-door)
Manufacture period	10.1991 - 08.1993	grade	GR (Granroad)	transmission	MT (manual transmission)	シフト・ボックス	F5 (floor shift 5-speed)

Choose required parts subgroup:

- G2201 - engine ignition system (engine)
- G2202 - distributor (engine)
- G2203 - alternator mounting (engine)
- G2204 - alternator (engine)
- G2205 - starter motor (engine)
- G2401 - wiring harness (Denso)
- G2402 - meter (Denso)
- G2403 - switch & relay (Denso)
- G2404 - relay, sensor, timer & amp. (Denso)
- G2410 - battery mounting (body)
- G2601 - head lamp (Denso)
- G2602 - front combination lamp (Denso)
- G2604 - rear combination lamp (Denso)
- G2605 - license lamp & side reflector (Denso)
- G2606 - room & inspection lamp (Denso)
- G2701 - window shield wiper (Denso)
- G2702 - window shield washer (Denso)
- G2703 - rear window wiper (Denso)
- G2704 - rear window washer (Denso)
- G2705 - head lamp cleaner (Denso)

G2715 - radio & stereo (Denso)
G2716 - clock (Denso)
G2729 - compressor bracket (engine)
G2730 - heater, cooler & air conditioner (engine room) (Denso)
G2731 - heater, cooler & air conditioner (unit) (Denso)
G2732 - heater, cooler & air conditioner (fitting) (Denso)
G2801 - engine control unit (engine)