# **Encoding Digital Data with Analog Signals**Computer Networks(CS31204)

#### **Prof. Sudip Misra**

Department of Computer Science and Engineering Indian Institute of Technology Kharagpur

Email: smisra@sit.iitkgp.ernet.in

Website: http://cse.iitkgp.ac.in/~smisra/ Research Lab: cse.iitkgp.ac.in/~smisra/swan/




### **Digital to Analog Conversion**

- Digital-to-analog conversion is the process of changing one of characteristics of an analog signal based on the information in digital data.
- Digital data needs to be carried on an analog signal.
- A carrier signal (frequency f<sub>c</sub>) performs the function of transporting the digital data in an analog waveform.

The analog carrier signal is manipulated to uniquely identify the digital data

being carried.



Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*,5E.




- Bit rate, N, is the number of bits per second (bps).
- Baud rate is the number of signal elements per second (bauds).
- In the analog transmission of digital data, the signal or baud rate is less than or equal to the bit rate.

#### S=Nx1/r bauds

Where r is the number of data bits per signal element.

#### **Types**





Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*,5E.

### **Amplitude Shift Keying**




- ASK is implemented by changing the amplitude of a carrier signal to reflect amplitude levels in the digital signal.
- For example: a digital "1" could not affect the signal, whereas a digital "0" would, by making it zero.
- The line encoding will determine the values of the analog waveform to reflect the digital data being carried.

#### **Binary Amplitude Shift Keying**



- Normally implemented using only two levels.
- Referred to as binary amplitude shift keying or on-off keying (OOK).
- The peak amplitude of one signal level is 0; the other is the same as the amplitude of the carrier frequency.





Source: B. A. Forouzan, "Data Communications and Networking," McGra Hill Forouzan Networking Series, 5E.

### Frequency Shift Keying (FSK)



The digital data stream changes the frequency of the carrier signal, f<sub>c</sub>.






### **Coherent and Non Coherent (FSK)**

- In a non-coherent FSK scheme, when we change from one frequency to the other, we do not adhere to the current phase of the signal.
- In coherent FSK, the switch from one frequency signal to the other only occurs at the same phase in the signal.

### **Phase Shift Keying**



- We vary the phase shift of the carrier signal to represent digital data.
- PSK is much more robust than ASK as it is not that vulnerable to noise, which changes amplitude of the signal.



Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*,5E.

### **Binary Phase Shift Keying**



- Binary Phase-shift keying (BPSK) is a digital modulation scheme that conveys data by changing, or modulating, two different phase s of a reference signal (the carrier wave ).
- This gives maximum phase-separation between adjacent points and thus the best immunity to corruption.
- Used in various wireless standards such as CDMA, WiMAX (16d, 16e), WLAN 11a, 11b, 11g, 11n, Satellite, DVB, Cable modem etc.


#### **Constellation Diagrams**



A constellation diagram helps us to define the amplitude and phase of a signal when we are using two carriers, one in quadrature of the other.


The X-axis represents the in-phase carrier and the Y-axis represents quadrature

carrier.



Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*, 5E.






Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*,5E.

#### **Analog to Analog Conversion**



- Analog-to-analog conversion is the representation of analog information by an analog signal.
- One may ask why we need to modulate an analog signal; it is already analog.
- Modulation is needed if the medium is bandpass in nature or if only a bandpass channel is available to us.



#### **Amplitude Modulation**




A carrier signal is modulated only in amplitude value.

The modulating signal is the envelope of the carrier.

The required bandwidth is 2B, where B is the bandwidth of the modulating


signal.



Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*,5E.




- Since on both sides of the carrier frequency f<sub>c</sub>, the spectrum is identical, we can discard one half, thus requiring a smaller bandwidth for transmission.
- The band allocation is as:




#### **Frequency Modulation**



- The modulating signal changes the freq. f<sub>c</sub> of the carrier signal.
- The bandwidth for FM is high.
- It is approx. 10x the signal frequency.
- The FM band allocation is:








Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking Series*,5E.

#### **Phase Modulation**

- The modulating signal only changes the phase of the carrier signal.
- The phase change manifests itself as a frequency change but the instantaneous frequency change is proportional to the derivative of the amplitude.
- The bandwidth is higher than for AM.



Source: B. A. Forouzan, "Data Communications and Networking," *McGraw-Hill Forouzan Networking* Series,5E.



## Thank You!!!