CC31xx HTTP Server

CC31xx HTTP Server

Overview

This sampel application demostrates the capability of CC3100 acting as a web server and allowing the end-user to communicate w/ CC3100 using a standard web browser.

For more details on CC31xx HTTP web server please refer to '<cc3100/>docs/examples/simplelink_http_web_server_user_guide.pdf'

Application details

This application configures the CC3100 into AP mode with defined SSID-NAME and uses the sample HTML pages to toggle on-board LEDs. GET and POST tokens are used to get the LEDs' status and toggle the LEDs respectively.

Client can connect to CC3100 and request for web-pages using the IP of device from any standard web browser. The HTML pages provided with the sample application needs to be downloaded on sFLASH using the 'sl_prog" utility. The authentication parameters and domain name can be changed using corresponding host-driver APIs.

Usage

• Download the 'main.html' and 'blink_led.html' on sFLASH using below commands

- Edit 'main.c' and modify the value for 'SSID_NAME'
- Build and launch the project.

```
CC3100 will come-up in AP mode \ensuremath{\mathrm{w}}/ the value set above as its SSID name
```


- Connect a client w/ CC3100 using its SSID name
- Open a web bowser on the client and enter the IP of CC3100 in the address bar

```
Default IP address is 192.168.0.1

Alternatively, 'mysimplelink.net' can also be entered for accessing the web page
```


• On the page that gets displayed, click on the 'Blink LED'

CC31xx HTTP Server



• Use LED buttons to turn ON/OFF the LEDs on the MCU board.

CC31xx HTTP Server



Limitations/Known Issues

Refer to Limitation and Known issue section of '<cc3100/>docs/examples/simplelink_http_web_server_user_guide.pdf'

Article Sources and Contributors

 $\textbf{CC31xx HTTP Server} \ \textit{Source}: \\ \textbf{http://ap-fpdsp-swapps.dal.design.ti.com/index.php?oldid=188622} \ \textit{Contributors}: A0131814, Giansway \\ \textbf{Gandard Gandard Ga$

Image Sources, Licenses and Contributors

Image:HTTP_MainPage.png Source: http://ap-fpdsp-swapps.dal.design.ti.com/index.php?title=File:HTTP_MainPage.png License: unknown Contributors: A0131814
Image:HTTP_LedPage.png Source: http://ap-fpdsp-swapps.dal.design.ti.com/index.php?title=File:HTTP_LedPage.png License: unknown Contributors: A0131814