## **CC31xx Mode Config Application**

## Overview and application details

Mode-config application configures CC3100 device, either in STA or AP mode. The application uses a compile-time switch to configure the device is either if these two modes

### **Usage**

- Define '\_\_CONFIGURE\_AP\_\_' for configuring CC3100 in AP mode. If this macro is undefined, CC3100 shall be configured in STA mode
- · Edit 'main.c' and set values for below macros:
  - 1. In STA mode, CC3100 will connect to below AP. The application assumes that the AP doesn't have the security enabled.

```
#define SSID_NAME "<ap-name>"
```

1. In AP mode, CC3100 will come-up in AP mode w/ below credentials - The security type is OPEN.

```
#define AP_SSID_NAME "CC3100_DEMO_AP"
```

· Build and run the application

#### Source Files briefly explained

i. main - Configure the station/AP mode, initialize the device and in station mode connects to AP.

#### **Limitations/Known Issues**

None

# **Article Sources and Contributors**