SEMICONDUCTOR DEVICES

Bipolar Junction Transistors: Part 1



M.B.Patil
mbpatil@ee.iitb.ac.in
www.ee.iitb.ac.in/~sequel

Department of Electrical Engineering Indian Institute of Technology Bombay





* A bipolar junction transistor (BJT) consists of two pn junction diodes connected back to back.



- * A bipolar junction transistor (BJT) consists of two pn junction diodes connected back to back.
- * A BJT is a three-terminal device; the terminals are called emitter, base, and collector.



- * A bipolar junction transistor (BJT) consists of two pn junction diodes connected back to back.
- * A BJT is a three-terminal device; the terminals are called emitter, base, and collector.
- * There are two types of BJTs: pnp and npn.





- * A bipolar junction transistor (BJT) consists of two pn junction diodes connected back to back.
- * A BJT is a three-terminal device; the terminals are called emitter, base, and collector.
- * There are two types of BJTs: pnp and npn.
- * The actual device construction is different than the above schematic diagram (to be discussed).




- * A bipolar junction transistor (BJT) consists of two pn junction diodes connected back to back.
- * A BJT is a three-terminal device; the terminals are called emitter, base, and collector.
- * There are two types of BJTs: pnp and npn.
- * The actual device construction is different than the above schematic diagram (to be discussed).
- * For the device to work as a transistor (rather than two independent diodes), the two junctions must be "close."

Basic operation







* If V_1 is varies, p(x) varies $\to I_p(W) \propto \frac{dp}{dx}(W)$ varies, i.e., by changing V_1 , I_2 can be controlled. This is the basic transistor action.




* If V_1 is varies, p(x) varies $\to I_p(W) \propto \frac{dp}{dx}(W)$ varies, i.e., by changing V_1 , I_2 can be controlled. This is the basic transistor action.





- * If V_1 is varies, p(x) varies $\to I_p(W) \propto \frac{dp}{dx}(W)$ varies, i.e., by changing V_1 , I_2 can be controlled. This is the basic transistor action.
- * If the two junctions are not sufficiently close, the device behaves like two *independent* diodes connected back-to-back, and there is no transistor action.







* In the "active" or "linear" mode, the B-E junction is under forward bias, the B-C junction is under reverse bias.







- * In the "active" or "linear" mode, the B-E junction is under forward bias, the B-C junction is under reverse bias.
- The B-E voltage (magnitude) is restricted to about 0.8 V in a low-power silicon BJT, as in a forward-biased diode.







- * In the "active" or "linear" mode, the B-E junction is under forward bias, the B-C junction is under reverse bias.
- The B-E voltage (magnitude) is restricted to about 0.8 V in a low-power silicon BJT, as in a forward-biased diode.
- * The B-C voltage (magnitude) can be much larger than the B-E voltage and is limited by breakdown phenomena.







- * In the "active" or "linear" mode, the B-E junction is under forward bias, the B-C junction is under reverse bias.
- The B-E voltage (magnitude) is restricted to about 0.8 V in a low-power silicon BJT, as in a forward-biased diode.
- * The B-C voltage (magnitude) can be much larger than the B-E voltage and is limited by breakdown phenomena.
- pnp transistor: Holes are injected from the emitter. Most of them reach the B-C depletion layer, get swept away by the field there, and get collected by the collector.







- * In the "active" or "linear" mode, the B-E junction is under forward bias, the B-C junction is under reverse bias.
- The B-E voltage (magnitude) is restricted to about 0.8 V in a low-power silicon BJT, as in a forward-biased diode.
- * The B-C voltage (magnitude) can be much larger than the B-E voltage and is limited by breakdown phenomena.
- * pnp transistor: Holes are injected from the emitter. Most of them reach the B-C depletion layer, get swept away by the field there, and get collected by the collector.
- * npn transistor: Electrons are injected from the emitter. Most of them reach the B-C depletion layer, get swept away by the field there, and get collected by the collector.













 The emitter arrow in the BJT symbol indicates the direction of the emitter current when the BJT is operating in the active mode (for both pnp and npn BJTs).







- The emitter arrow in the BJT symbol indicates the direction of the emitter current when the BJT is operating in the active mode (for both pnp and npn BJTs).
- * The collector current I_C is a fraction of the emitter current: $I_C = \alpha I_E$. For a good transistor, $\alpha \approx 1$.








- The emitter arrow in the BJT symbol indicates the direction of the emitter current when the BJT is operating in the active mode (for both pnp and npn BJTs).
- The collector current I_C is a fraction of the emitter current: I_C = αI_E.
 For a good transistor, α ≈ 1.
- * The three currents satisfy KCL, i.e., $I_E = I_C + I_B$. Substituting for I_C , we get $I_B = (1 \alpha) I_E$.


















* The "common-emitter current gain" β – a figure of merit of a BJT – is defined as $\beta = I_C/I_B$.






- * The "common-emitter current gain" β a figure of merit of a BJT is defined as $\beta = I_C/I_B$.
- * $\beta = \frac{I_C}{I_B} = \frac{\alpha I_E}{(1-\alpha)I_E} = \frac{\alpha}{1-\alpha}$.






α	1-lpha	$\beta = \alpha/(1-\alpha)$
0.9	0.1	9
0.95	0.05	19
0.99	0.01	99
0.995	0.005	199

- * The "common-emitter current gain" β a figure of merit of a BJT is defined as $\beta = I_C/I_B$.
- * $\beta = \frac{I_C}{I_B} = \frac{\alpha I_E}{(1-\alpha)I_E} = \frac{\alpha}{1-\alpha}$.





α	$1-\alpha$	$\beta = \alpha/(1-\alpha)$
0.9	0.1	9
0.95	0.05	19
0.99	0.01	99
0.995	0.005	199

- * The "common-emitter current gain" β a figure of merit of a BJT is defined as $\beta = I_C/I_B$.
- * $\beta = \frac{I_C}{I_B} = \frac{\alpha I_E}{(1-\alpha)I_E} = \frac{\alpha}{1-\alpha}$.
- * For a typical discrete low-power transistor such as BC107A, β is in the range of 100 to 200.

BJT modes of operation



Mode	B-E junction	B-C junction
Active (linear)	forward	reverse
Cutoff	reverse	reverse
Saturation	forward	forward
Inverse active	reverse	forward

BJT modes of operation



Mode	B-E junction	B-C junction
Active (linear)	forward	reverse
Cutoff	reverse	reverse
Saturation	forward	forward
Inverse active	reverse	forward


* In analog circuits, BJTs are generally biased to operate in the active mode.

BJT modes of operation




Mode	B-E junction	B-C junction
Active (linear)	forward	reverse
Cutoff	reverse	reverse
Saturation	forward	forward
Inverse active	reverse	forward


- * In analog circuits, BJTs are generally biased to operate in the active mode.
- * BJT as a switch:
 - Closed: saturation mode
 - Open: cutoff mode




* The substrate thickness is hundreds of microns whereas the *p* epi-layer and the rest of the device structure is confined to a few microns.




- * The substrate thickness is hundreds of microns whereas the *p* epi-layer and the rest of the device structure is confined to a few microns.
- * The p^+ substrate can be treated as a small resistance $R_{\rm sub}$.




- * The substrate thickness is hundreds of microns whereas the *p* epi-layer and the rest of the device structure is confined to a few microns.
- * The p^+ substrate can be treated as a small resistance $R_{\rm sub}$.
- * The "active" region of the device is only the top few microns (the p epi-layer).




- * The substrate thickness is hundreds of microns whereas the *p* epi-layer and the rest of the device structure is confined to a few microns.
- * The p^+ substrate can be treated as a small resistance $R_{\rm sub}$.
- * The "active" region of the device is only the top few microns (the p epi-layer).
- * The figure is not drawn to scale. Typically, the y and z dimensions are much larger than the p epi thickness.





- * The substrate thickness is hundreds of microns whereas the *p* epi-layer and the rest of the device structure is confined to a few microns.
- * The p^+ substrate can be treated as a small resistance R_{sub} .
- * The "active" region of the device is only the top few microns (the p epi-layer).
- * The figure is not drawn to scale. Typically, the y and z dimensions are much larger than the p epi thickness.
- * Because the contact region dimensions are much larger than the base width (~ the width of the n base region), the device can be considered to be one-dimensional in nature.





- The substrate thickness is hundreds of microns whereas the p epi-layer and the rest of the device structure is confined to a few microns.
- * The p^+ substrate can be treated as a small resistance $R_{\rm sub}$.
- * The "active" region of the device is only the top few microns (the p epi-layer).
- * The figure is not drawn to scale. Typically, the y and z dimensions are much larger than the p epi thickness.
- Because the contact region dimensions are much larger than the base width (~ the width of the n base region), the device can be considered to be one-dimensional in nature
- * A "base resistance" r_b exists between the base region and the base contact. To keep r_b small, the base contact is made close to the emitter.




















* For simplicity, we will assume the doping densities to be constant in the emitter, base, and collector regions.




* For simplicity, we will assume the doping densities to be constant in the emitter, base, and collector regions.




- * For simplicity, we will assume the doping densities to be constant in the emitter, base, and collector regions.
- * The relationship $N_a^E > N_d^B > N_a^C$, which is a consequence of the fabrication process, is also desirable from the device performance angle.







* To make an integrated circuit (IC), a large number of transistors are fabricated on a single silicon piece and interconnected as required.




- * To make an integrated circuit (IC), a large number of transistors are fabricated on a single silicon piece and interconnected as required.
- * The BJTs are isolated from each other using reverse-biased pn junctions.




- * To make an integrated circuit (IC), a large number of transistors are fabricated on a single silicon piece and interconnected as required.
- * The BJTs are isolated from each other using reverse-biased pn junctions.
- * Contacts (E, B, C) are made on the top surface for connecting to other transistors.




- * To make an integrated circuit (IC), a large number of transistors are fabricated on a single silicon piece and interconnected as required.
- * The BJTs are isolated from each other using reverse-biased pn junctions.
- * Contacts (E, B, C) are made on the top surface for connecting to other transistors.
- * An n^+ buried layer is used to provide a low-resistance path for the electron current.






Consider a pnp transistor.


* I_E has a hole component and an electron component. Of these, only the hole component contributes to I_C . We define "emitter injection efficiency" (or simply "injection efficiency") as $\gamma = \frac{I_{pE}}{I_E} = \frac{I_{pE}}{I_{nE} + I_{nE}}$.



Consider a pnp transistor.

- * I_E has a hole component and an electron component. Of these, only the hole component contributes to I_C .
 - We define "emitter injection efficiency" (or simply "injection efficiency") as $\gamma = \frac{I_{pE}}{I_E} = \frac{I_{pE}}{I_{pE} + I_{nE}}$.
- * Some of the injected holes are lost due to recombination in the neutral base region (we will ignore G-R in the B-C depletion regions).
 - We define "base transport factor" as $\alpha_T = \frac{I_{pC}}{I_{pE}}$.







Consider a pnp transistor.

- * I_E has a hole component and an electron component. Of these, only the hole component contributes to I_C . We define "emitter injection efficiency" (or simply "injection efficiency") as $\gamma = \frac{I_{pE}}{I_E} = \frac{I_{pE}}{I_{pE} + I_{pE}}$.
- * Some of the injected holes are lost due to recombination in the neutral base region (we will ignore G-R in the B-C depletion regions).

We define "base transport factor" as
$$\alpha_T = \frac{I_{pC}}{I_{pE}}$$
.




Since the C-B junction is reverse biased, the pn junction current arising because of V_{CB} is negligibly small.



Since the C-B junction is reverse biased, the pn junction current arising because of V_{CB} is negligibly small.

 \rightarrow I_C is entirely due to the holes injected by the emitter which make it to the C-B depletion boundary (x = W), i.e.,

$$I_C \approx I_{pC} = \alpha_T I_{pE} = \alpha_T (\gamma I_E) \rightarrow \alpha = \frac{I_C}{I_E} = \gamma \alpha_T.$$




Since the C-B junction is reverse biased, the pn junction current arising because of V_{CB} is negligibly small.


ightarrow I_C is entirely due to the holes injected by the emitter which make it to the C-B depletion boundary (x = W), i.e.,

$$I_C \approx I_{pC} = \alpha_T I_{pE} = \alpha_T (\gamma I_E) \rightarrow \alpha = \frac{I_C}{I_E} = \gamma \alpha_T.$$

 \rightarrow For $\alpha \approx 1$, both γ and α_T must be close to 1.




We assume that the emitter width is greater than $5 L_n$.



We assume that the emitter width is greater than $5 L_n$.

Neglecting the drift components for minority carriers in the emitter and base neutral regions, we get

$$\begin{split} D_{nE} \, \frac{d^2 \Delta n}{dx^2} - \frac{\Delta n}{\tau_{nE}} &= 0, \quad x < x_E, \text{ with} \\ \Delta n(x_E) &= n_{0E} \left[\exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right], \\ \Delta n(-\infty) &= 0. \end{split}$$



We assume that the emitter width is greater than $5 L_p$.

Neglecting the drift components for minority carriers in the emitter and base neutral regions, we get

$$D_{nE} \frac{d^2 \Delta n}{dx^2} - \frac{\Delta n}{\tau_{nE}} = 0, \quad x < x_E, \text{ with}$$


$$D_{pB} \frac{d^2 \Delta p}{dx^2} - \frac{\Delta p}{\tau_{pB}} = 0, \quad 0 < x < W, \text{ with}$$


$$\Delta n(x_E) = n_{0E} \left[\exp\left(\frac{V_{EB}}{V_T}\right) - 1 \right],$$

$$\Delta n(-\infty) = 0.$$

$$\Delta p(W) = p_{0B} \left[\exp\left(\frac{V_{CB}}{V_T}\right) - 1 \right].$$


M. B. Patil, IIT Bombay





Solution:
$$\Delta n(x) = \Delta n(x_E) e^{-(x_E - x)/L_{nE}}, \quad x < x_E,$$

$$\Delta p(x) = A e^{-x/L_{pB}} + B e^{+x/L_{pB}}, \quad 0 < x < W.$$





Solution:
$$\Delta n(x) = \Delta n(x_E) e^{-(x_E - x)/L_{nE}}, \quad x < x_E,$$

 $\Delta p(x) = A e^{-x/L_{pB}} + B e^{+x/L_{pB}}, \quad 0 < x < W.$

Using the boundary conditions (last slide), we get

$$\Delta p(x) = \Delta p(0) \frac{\sinh\left(\frac{W - x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)} + \Delta p(W) \frac{\sinh\left(\frac{x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)}$$






Solution:
$$\Delta n(x) = \Delta n(x_E) \, e^{-(x_E - x)/L_{nE}}, \quad x < x_E,$$


$$\Delta p(x) = A \, e^{-x/L_{pB}} + B \, e^{+x/L_{pB}}, \quad 0 < x < W.$$

Using the boundary conditions (last slide), we get


$$\Delta p(x) = \Delta p(0) \frac{\sinh\left(\frac{W - x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)} + \Delta p(W) \frac{\sinh\left(\frac{x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)}.$$



$$\begin{split} I_{nE} &= qAD_{nE} \, \frac{dn}{dx}(x_E) = qAD_{nE} \, \frac{d\Delta n}{dx}(x_E) \\ &= \frac{qAD_{nE}}{L_{nE}} \, \Delta n(x_E) = \frac{qAD_{nE}}{L_{nE}} \, n_{0E} \, \Big(e^{V_{EB}/V_T} - 1 \Big), \end{split}$$





$$\begin{split} I_{nE} &= qAD_{nE} \, \frac{dn}{dx}(x_E) = qAD_{nE} \, \frac{d\Delta n}{dx}(x_E) \\ &= \frac{qAD_{nE}}{L_{nE}} \, \Delta n(x_E) = \frac{qAD_{nE}}{L_{nE}} \, n_{0E} \left(e^{V_{EB}/V_T} - 1 \right), \\ I_{pE} &= -qAD_{pB} \, \frac{dp}{dx}(0) = -qAD_{pB} \, \frac{d\Delta p}{dx}(0) \\ &= \frac{qAD_{pB}}{L_{nB}} \, p_{0B} \left(e^{V_{EB}/V_T} - 1 \right) \frac{\cosh(W/L_{pB})}{\sinh(W/L_{nB})}. \end{split}$$




$$\begin{split} I_{nE} &= qAD_{nE} \frac{dn}{dx}(x_E) = qAD_{nE} \frac{d\Delta n}{dx}(x_E) \\ &= \frac{qAD_{nE}}{L_{nE}} \Delta n(x_E) = \frac{qAD_{nE}}{L_{nE}} n_{0E} \left(e^{V_{EB}/V_T} - 1 \right), \\ I_{pE} &= -qAD_{pB} \frac{dp}{dx}(0) = -qAD_{pB} \frac{d\Delta p}{dx}(0) \\ &= \frac{qAD_{pB}}{L_{pB}} p_{0B} \left(e^{V_{EB}/V_T} - 1 \right) \frac{\cosh(W/L_{pB})}{\sinh(W/L_{pB})}. \end{split}$$


$$\begin{split} \gamma &= \frac{I_{pE}}{I_{pE} + I_{nE}} = \frac{1}{1 + (I_{nE}/I_{pE})} \\ &= \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{L_{pB}}{L_{nE}} \frac{N_{dB}}{N_{aE}}\right) \frac{\sinh(W/L_B)}{\cosh(W/L_B)}}, \\ \text{since } \frac{n_{0E}}{p_{0B}} &= \frac{n_i^2}{N_{aE}} \times \frac{N_{dB}}{n_i^2} = \frac{N_{dB}}{N_{aE}}. \end{split}$$








$$\begin{split} I_{C} &\approx I_{pC} = -qAD_{pB}\,\frac{d\Delta p}{dx}(W) \\ &= \frac{qAD_{pB}}{L_{pB}}\,p_{0B}\left(e^{V_{EB}/V_{T}}-1\right)\frac{1}{\sinh(W/L_{B})}. \end{split}$$





$$E(p) \qquad B(n) \qquad C(p)$$
emitter current
$$x = 0 \qquad base \uparrow \\ x = W$$

0.2

0.4

 $\Delta p(x)/\Delta p(0)$

$$\Delta p(x) = \Delta p(0) \frac{\sinh\left(\frac{W-x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)} + \Delta p(W) \frac{\sinh\left(\frac{x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)}.$$

$$I_C pprox I_{pC} = -qAD_{pB} \frac{d\Delta p}{dx}(W)$$

$$= \frac{qAD_{pB}}{L_{pB}} p_{0B} \left(e^{V_{EB}/V_T} - 1 \right) \frac{1}{\sinh(W/L_B)}.$$

The base transport factor is (using I_{pE} from the last slide),

$$\alpha_T = \frac{I_{pC}}{I_{pE}} = \frac{1}{\cosh(W/L_{pB})}.$$




0.8


 $W/L_{pB} = 0.5$

0.6

 \times/W




$$\Delta p(x) = \Delta p(0) \frac{\sinh\left(\frac{W-x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)} + \Delta p(W) \frac{\sinh\left(\frac{x}{L_{pB}}\right)}{\sinh\left(\frac{W}{L_{pB}}\right)}.$$





0.5


х



$$\begin{split} \Delta p(x) &= \Delta p(0) \, \frac{\sinh \left(\frac{W-x}{L_{\rho B}} \right)}{\sinh \left(\frac{W}{L_{\rho B}} \right)} + \Delta p(W) \, \frac{\sinh \left(\frac{x}{L_{\rho B}} \right)}{\sinh \left(\frac{W}{L_{\rho B}} \right)}. \\ \alpha_T &= \frac{I_{\rho C}}{I_{\rho E}} = \frac{1}{\cosh (W/L_{\rho B})} \approx \frac{1}{1 + \frac{1}{2} \left(\frac{W}{L_{\rho B}} \right)^2}. \end{split}$$










$$\begin{split} \Delta p(x) &= \Delta p(0) \, \frac{\sinh \left(\frac{W-x}{L_{pB}}\right)}{\sinh \left(\frac{W}{L_{pB}}\right)} + \Delta p(W) \, \frac{\sinh \left(\frac{x}{L_{pB}}\right)}{\sinh \left(\frac{W}{L_{pB}}\right)}. \\ \alpha_T &= \frac{I_{pC}}{I_{pE}} = \frac{1}{\cosh(W/L_{pB})} \approx \frac{1}{1 + \frac{1}{2} \left(\frac{W}{L_{pB}}\right)^2}. \end{split}$$

Remark: $\alpha_T \to 1$ if the base width W is made small compared to L_{pB} .






$$\gamma = \frac{\textit{I}_{\textit{pE}}}{\textit{I}_{\textit{pE}} + \textit{I}_{\textit{nE}}} = \frac{1}{1 + \left(\textit{I}_{\textit{nE}}/\textit{I}_{\textit{pE}}\right)} = \frac{1}{1 + \left(\frac{\textit{D}_{\textit{nE}}}{\textit{D}_{\textit{pB}}} \, \frac{\textit{L}_{\textit{pB}}}{\textit{L}_{\textit{nE}}} \, \frac{\textit{N}_{\textit{dB}}}{\textit{N}_{\textit{aE}}}\right) \frac{\sinh(\textit{W}/\textit{L}_{\textit{B}})}{\cosh(\textit{W}/\textit{L}_{\textit{B}})}}$$




0.5


Х




$$\gamma = \frac{I_{pE}}{I_{pE} + I_{nE}} = \frac{1}{1 + (I_{nE}/I_{pE})} = \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{L_{pB}}{N_{aE}} \frac{N_{dB}}{N_{aE}}\right) \frac{\sinh(W/L_B)}{\cosh(W/L_B)}}$$

$$\approx \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{L_{pB}}{L_{nE}} \frac{N_{dB}}{N_{aE}}\right) \frac{W/L_{pB}}{1 + \frac{1}{2}(W/L_{pB})^2}}$$










$$\gamma = \frac{I_{pE}}{I_{pE} + I_{nE}} = \frac{1}{1 + (I_{nE}/I_{pE})} = \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{L_{pB}}{N_{aE}} \frac{N_{dB}}{N_{aE}}\right) \frac{\sinh(W/L_B)}{\cosh(W/L_B)} }$$

$$\approx \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{L_{pB}}{L_{nE}} \frac{N_{dB}}{N_{aE}}\right) \frac{W/L_{pB}}{1 + \frac{1}{2}(W/L_{pB})^2} }$$


$$\approx \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{W}{N_{aE}} \frac{N_{dB}}{N_{aE}}\right) }$$








$$\gamma pprox rac{1}{1 + \left(rac{D_{nE}}{D_{pB}} rac{W}{L_{nE}} rac{N_{dB}}{N_{aE}}
ight)}$$
 .




M. B. Patil, IIT Bombay




$$\gamma pprox rac{1}{1 + \left(rac{D_{nE}}{D_{pB}} rac{W}{L_{nE}} rac{N_{dB}}{N_{aE}}
ight)}.$$

* $\gamma \rightarrow 1$ if $N_{aE} \gg N_{dB}$.





M. B. Patil, IIT Bombay



$$\gamma pprox rac{1}{1 + \left(rac{D_{nE}}{D_{pB}} rac{W}{L_{nE}} rac{N_{dB}}{N_{aE}}
ight)}.$$

- * $\gamma \rightarrow 1$ if $N_{aE} \gg N_{dB}$.
- * It is now clear why a higher doping density in the emitter region (compared to the base doping density) is desirable.






Consider a pnp BJT with $N_{aE}=10^{18}$ cm $^{-3}$, $N_{dB}=5\times10^{16}$ cm $^{-3}$, $N_{aC}=10^{15}$ cm $^{-3}$, and with a base width $W=2~\mu m$ ($T=300~{\rm K}$).


(a) Calculate α_T , γ , α , and β , using the following parameters.

$$\begin{split} &\mu_{nE} = 250\,\mathrm{cm^2/V\text{-s}},\; \mu_{pB} = 500\,\mathrm{cm^2/V\text{-s}},\; \mu_{nC} = 1500\,\mathrm{cm^2/V\text{-s}},\\ &\tau_{nE} = 0.2\,\mathrm{\mu s},\; \tau_{pB} = 1\,\mathrm{\mu s},\; \tau_{nC} = 1\,\mathrm{\mu s}. \end{split}$$



Consider a pnp BJT with $N_{aE}=10^{18}$ cm $^{-3}$, $N_{dB}=5\times10^{16}$ cm $^{-3}$, $N_{aC}=10^{15}$ cm $^{-3}$, and with a base width $W=2~\mu m$ ($T=300~{\rm K}$).

- (a) Calculate α_T , γ , α , and β , using the following parameters. $\mu_{nE}=250\,\mathrm{cm^2/V}\text{-s},\ \mu_{pB}=500\,\mathrm{cm^2/V}\text{-s},\ \mu_{nC}=1500\,\mathrm{cm^2/V}\text{-s},$ $\tau_{nE}=0.2\,\mathrm{\mu s},\ \tau_{nB}=1\,\mathrm{\mu s},\ \tau_{nC}=1\,\mathrm{\mu s}.$
- (b) Repeat (a) for the BJT operating in the reverse active mode.



Solution:

The minority carrier diffusion lengths are


$$\mathit{L_{nE}} = \sqrt{\mathit{D_{nE}}\tau_{nE}} = \sqrt{\mathit{V_T}\mu_{nE}\tau_{nE}} = \sqrt{0.0258 \times 250 \times 0.2 \times 10^{-6}} = 1.14 \times 10^{-3}\,\mathrm{cm} = 11.4\,\mu\mathrm{m}.$$

$$L_{pB} = \sqrt{D_{pB}\tau_{pB}} = \sqrt{V_T\mu_{pB}\tau_{pB}} = \sqrt{0.0258\times500\times1\times10^{-6}} = 3.59\times10^{-3}\,\mathrm{cm} = 35.9\,\mu\mathrm{m}.$$


$$L_{nC} = \sqrt{D_{nC}\tau_{nC}} = \sqrt{V_T\mu_{nC}\tau_{nC}} = \sqrt{0.0258\times1500\times1\times10^{-6}} = 6.22\times10^{-3}\,\mathrm{cm} = 62.2\,\mu\mathrm{m}.$$

Note that $L_{pB} \gg W$ (2 μ m).


M. B. Patil, IIT Bombay




$$\text{(a)} \quad \frac{D_{nE}}{D_{pB}} \, \frac{W}{L_{nE}} \, \frac{N_{dB}}{N_{aE}} = \frac{\mu_{nE}}{\mu_{pB}} \, \frac{W}{L_{nE}} \, \frac{N_{dB}}{N_{aE}} = \frac{250}{500} \, \frac{2 \times 10^{-4}}{1.14 \times 10^{-3}} \, \frac{5 \times 10^{16}}{10^{18}} \, = 4.386 \times 10^{-3}.$$




(a)
$$\begin{split} \frac{D_{nE}}{D_{pB}} \, \frac{W}{L_{nE}} \, \frac{N_{dB}}{N_{aE}} &= \frac{\mu_{nE}}{\mu_{pB}} \, \frac{W}{L_{nE}} \, \frac{N_{dB}}{N_{aE}} = \frac{250}{500} \, \frac{2 \times 10^{-4}}{1.14 \times 10^{-3}} \, \frac{5 \times 10^{16}}{10^{18}} &= 4.386 \times 10^{-3}. \\ \gamma &= \frac{1}{1 + 4.386 \times 10^{-3}} = 0.9956. \end{split}$$



(a)
$$\begin{split} \frac{D_{nE}}{D_{pB}} & \frac{W}{L_{nE}} \frac{N_{dB}}{N_{aE}} = \frac{\mu_{nE}}{\mu_{pB}} \frac{W}{L_{nE}} \frac{N_{dB}}{N_{aE}} = \frac{250}{500} \frac{2 \times 10^{-4}}{1.14 \times 10^{-3}} \frac{5 \times 10^{16}}{10^{18}} = 4.386 \times 10^{-3}. \\ & \gamma = \frac{1}{1 + 4.386 \times 10^{-3}} = 0.9956. \\ & \alpha_T = \frac{1}{1 + \frac{1}{2}(W/L_{pB})^2} = \frac{1}{1 + \frac{1}{2}(2.0/35.9)^2} = 0.9985. \end{split}$$



(a)
$$\begin{split} \frac{D_{nE}}{D_{pB}} & \frac{W}{L_{nE}} \frac{N_{dB}}{N_{aE}} = \frac{\mu_{nE}}{\mu_{pB}} \frac{W}{L_{nE}} \frac{N_{dB}}{N_{aE}} = \frac{250}{500} \frac{2 \times 10^{-4}}{1.14 \times 10^{-3}} \frac{5 \times 10^{16}}{10^{18}} = 4.386 \times 10^{-3}. \\ & \gamma = \frac{1}{1 + 4.386 \times 10^{-3}} = 0.9956. \\ & \alpha_T = \frac{1}{1 + \frac{1}{2} (W/L_{pB})^2} = \frac{1}{1 + \frac{1}{2} (2.0/35.9)^2} = 0.9985. \\ & \alpha = \gamma \alpha_T = 0.9940 \rightarrow \beta = \frac{\alpha}{1 - \alpha} = 166. \end{split}$$



(b) With
$$E \leftrightarrow C$$
.

$$\frac{D_{nE}}{D_{pB}} \frac{W}{L_{nE}} \frac{N_{dB}}{N_{aE}} \rightarrow \frac{D_{nC}}{D_{pB}} \frac{W}{L_{nC}} \frac{N_{dB}}{N_{aC}} = \frac{\mu_{nC}}{\mu_{pB}} \frac{W}{L_{nC}} \frac{N_{dB}}{N_{aC}} = \frac{1500}{500} \frac{2 \times 10^{-4}}{6.22 \times 10^{-3}} \frac{5 \times 10^{16}}{10^{15}} = 4.823.$$


$$\gamma = \frac{1}{1 + 4.823} = 0.1717, \ \alpha_T = \frac{1}{1 + \frac{1}{2}(2/35.9)^2} = 0.9985.$$

 $\rightarrow \alpha = \gamma \alpha_T = 0.1714 \rightarrow \beta = 0.2$, a disaster.


Conclusion: $N_{aE} \gg N_{dB}$ is crucial.

(Note that we have treated W as a constant, but it would vary with bias conditions.)


 γ with $W \ll L_{pB}$




 γ with $W << \mathit{L}_{\mathit{pB}}$



 γ with $W << L_{\it pB}$



 γ with $W << L_{\it pB}$




$$I_{nE} = -q A D_{nE} \frac{d}{dx} \left[n_{0E} \exp\left(\frac{V_{EB}}{V_T}\right) \exp\left(-\frac{x_n^E - x}{L_{nE}}\right) \right] \text{ at } x = x_n^E$$

$$= q A D_{nE} n_{0E} \exp\left(\frac{V_{EB}}{V_T}\right) \times \frac{1}{L_{nE}}$$

$$I_{pE} \approx q A D_{pB} p_{0B} \exp\left(\frac{V_{EB}}{V_T}\right) \times \frac{1}{W}$$

 γ with $\mathit{W} << \mathit{L}_{\mathit{pB}}$




$$\begin{split} I_{nE} &= -q \, A \, D_{nE} \, \frac{d}{dx} \left[n_{0E} \exp \left(\frac{V_{EB}}{V_T} \right) \exp \left(-\frac{x_n^E - x}{L_{nE}} \right) \right] \text{ at } x = x_n^E \\ &= q \, A \, D_{nE} \, n_{0E} \exp \left(\frac{V_{EB}}{V_T} \right) \times \frac{1}{L_{nE}} \end{split}$$

$$I_{pE} pprox q \, A \, D_{pB} \, p_{0B} \exp \left(rac{V_{EB}}{V_T}
ight) imes rac{1}{W}$$

$$\frac{I_{nE}}{I_{pE}} \approx \frac{D_{nE}}{D_{pB}} \, \frac{n_{0E}}{p_{0B}} \, \frac{W}{L_{nE}}$$

 γ with $W << \mathit{L}_{\mathit{pB}}$




$$I_{nE} = -q A D_{nE} \frac{d}{dx} \left[n_{0E} \exp\left(\frac{V_{EB}}{V_T}\right) \exp\left(-\frac{x_n^E - x}{L_{nE}}\right) \right] \text{ at } x = x_n^E$$

$$= q A D_{nE} n_{0E} \exp\left(\frac{V_{EB}}{V_T}\right) \times \frac{1}{L_{nE}}$$

$$I_{pE} \approx q A D_{pB} p_{0B} \exp\left(\frac{V_{EB}}{V_T}\right) \times \frac{1}{W}$$

$$\frac{I_{nE}}{I_{pE}} \approx \frac{D_{nE}}{D_{pB}} \frac{n_{0E}}{p_{0B}} \frac{W}{L_{nE}} = \frac{D_{nE}}{D_{pB}} \frac{n_i^2}{N_{aE}} \frac{N_{dB}}{n_i^2} \frac{W}{L_{nE}}$$

 γ with $W << L_{\it pB}$




$$\begin{split} I_{nE} &= -q \, A \, D_{nE} \, \frac{d}{dx} \left[n_{0E} \exp \left(\frac{V_{EB}}{V_T} \right) \exp \left(-\frac{x_n^E - x}{L_{nE}} \right) \right] \text{ at } x = x_n^E \\ &= q \, A \, D_{nE} \, n_{0E} \exp \left(\frac{V_{EB}}{V_T} \right) \times \frac{1}{L_{nE}} \end{split}$$


$$I_{pE} pprox q \, A \, D_{pB} \, p_{0B} \exp \left(rac{V_{EB}}{V_T}
ight) imes rac{1}{W}$$

$$\frac{I_{nE}}{I_{pE}} \approx \frac{D_{nE}}{D_{pB}} \, \frac{n_{0E}}{p_{0B}} \, \frac{W}{L_{nE}} = \frac{D_{nE}}{D_{pB}} \, \frac{n_i^2}{N_{aE}} \, \frac{N_{dB}}{n_i^2} \, \frac{W}{L_{nE}} = \frac{D_{nE}}{D_{pB}} \, \frac{N_{dB}}{N_{aE}} \, \frac{W}{L_{nE}}.$$

 γ with $W \ll L_{pB}$










$$\frac{I_{nE}}{I_{pE}} \approx \frac{D_{nE}}{D_{pB}} \, \frac{N_{dB}}{N_{aE}} \, \frac{W}{L_{nE}}$$


 γ with $W << L_{\it pB}$







$$\begin{split} &\frac{I_{nE}}{I_{pE}} \approx \frac{D_{nE}}{D_{pB}} \frac{N_{dB}}{N_{aE}} \frac{W}{L_{nE}} \\ &\rightarrow \gamma = \frac{I_{pE}}{I_{pE} + I_{nE}} = \frac{1}{1 + \frac{I_{nE}}{I_{pE}}} \approx \frac{1}{1 + \left(\frac{D_{nE}}{D_{pB}} \frac{W}{L_{nE}} \frac{N_{dB}}{N_{aE}}\right)}. \end{split}$$





When
$$W \ll L_{pB}$$
, $\Delta p(x)$ is linear.
$$\alpha_T = \frac{I_{pC}}{I_{pE}} = \frac{I_{pC}}{I_{pC} + I_{pB}} = \frac{1}{1 + \frac{I_{pB}}{I_{pC}}}.$$







$$\alpha_T = \frac{I_{pC}}{I_{pE}} = \frac{I_{pC}}{I_{pC} + I_{pB}} = \frac{1}{1 + \frac{I_{pB}}{I_{pC}}}.$$

$$I_{pC} = -q A D_{pB} \frac{dp}{dx}(W) \approx q A D_{pB} \frac{\Delta p(0)}{W}.$$

$$I_{pC} = -q A D_{pB} \frac{dp}{dx}(W) \approx q A D_{pB} \frac{\Delta p(0)}{W}$$







$$\alpha_T = \frac{I_{pC}}{I_{pE}} = \frac{I_{pC}}{I_{pC} + I_{pB}} = \frac{1}{1 + \frac{I_{pB}}{I_{pC}}}.$$

$$I_{pC} = -q A D_{pB} \frac{dp}{dx}(W) \approx q A D_{pB} \frac{\Delta p(0)}{W}.$$

$$I_{pB} = rac{Q_p}{ au_{pB}} = rac{q A rac{1}{2} \Delta p(0) W}{ au_{pB}}$$





$$\alpha_T = \frac{I_{pC}}{I_{pE}} = \frac{I_{pC}}{I_{pC} + I_{pB}} = \frac{1}{1 + \frac{I_{pB}}{I_{pC}}}.$$

$$I_{pC} = -q A D_{pB} \frac{dp}{dx}(W) \approx q A D_{pB} \frac{\Delta p(0)}{W}.$$

$$I_{pB} = rac{Q_p}{ au_{pB}} = rac{q A rac{1}{2} \Delta p(0) W}{ au_{pB}}
ightarrow lpha_T pprox rac{1}{1 + rac{1}{2} \left(rac{W}{L_{pB}}
ight)^2}.$$





Bipolar junction transistors: Ebers-Moll model

* We have considered a BJT in the active mode (B-E junction under forward bias, B-C junction under reverse bias) and obtained α .

* We have considered a BJT in the active mode (B-E junction under forward bias, B-C junction under reverse bias) and obtained α .


The BJT can now be replaced with its equivalent circuit.






* We have considered a BJT in the active mode (B-E junction under forward bias, B-C junction under reverse bias) and obtained α .

The BJT can now be replaced with its equivalent circuit.




* A generalised model valid in all modes can be obtained by removing the conditions of a forward bias across the *E-B* junction and a reverse bias across the *C-B* junction → Ebers-Moll model.





* Boundary conditions:




Ebers-Moll model: Outline of derivation for a pnp BJT

* Boundary conditions:

$$\Delta n(x_E) = n_{0E} \left[\exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right]$$

$$\Delta n(-\infty) = 0$$



Fbers-Moll model: Outline of derivation for a pnp BJT

Boundary conditions:


$$\Delta n(x_E) = n_{0E} \left[\exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right]$$

$$\Delta n(-\infty) = 0$$

$$\Delta p(0) = p_{0B} \left[\exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right]$$

$$\Delta p(0) = p_{0B} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - \Delta p(W) \right] = p_{0B} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - \frac{V_{CB}}{V_T} \right]$$

$$\Delta p(W) = p_{0B} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - 1 \right]$$



Outline of derivation for a pnp BJT

Boundary conditions:

Fbers-Moll model:

$$\Delta n(x_E) = n_{0E} \left[\exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right]$$

$$\Delta n(-\infty) = 0$$

$$\Delta p(0) = p_{0B} \left[\exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right]$$

$$\Delta p(0) = p_{0B} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - 1 \right]$$


$$\Delta p(W) = p_{0B} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - 1 \right]$$

$$\Delta n(x_C) = n_{0C} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - 1 \right]$$

$$\Delta n(x_C) = n_{0C} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - 1 \right]$$

$$\Delta n(x_C) = n_{0C} \left[\exp \left(\frac{V_{CB}}{V_T} \right) - \right]$$





forward active


saturation

reverse active

cutoff


M. B. Patil. IIT Bombay

 $\Delta n(\infty) = 0$



Ebers-Moll model: Outline of derivation for a pnp BJT

 Solve the minority-carrier continuity equations in the neutral emitter, base, and collector regions.



Ebers-Moll model: Outline of derivation for a pnp BJT


- Solve the minority-carrier continuity equations in the neutral emitter, base, and collector regions.
- * From the solutions, obtain the following currents.

$$I_{nE}(x_E) = qAD_{nE} \frac{dn}{dx}(x_E).$$


$$I_{pB}(0) = -qAD_{pB} \frac{dp}{dx}(0).$$

$$I_{pB}(W) = -qAD_{pB}\frac{dp}{dx}(W).$$

$$I_{nC}(x_C) = qAD_{nC} \frac{dn}{dx}(x_C).$$



M. B. Patil, IIT Bombay




Ebers-Moll model: Outline of derivation for a pnp BJT

* Obtain the terminal currents, ignoring G-R in the depletion regions.


$$I_E = I_{nE}(x_E) + I_{pB}(0).$$

$$I_C = I_{nC}(x_C) + I_{pB}(W).$$

$$I_B = I_E - I_C$$
.




Bipolar junction transistors: Ebers-Moll model



pnp transistor

$$\begin{split} I_E' &= I_{ES} \left[exp \left(\frac{V_{EB}}{V_T} \right) - 1 \right] \\ I_C' &= I_{CS} \left[exp \left(\frac{V_{CB}}{V_T} \right) - 1 \right] \end{split}$$






npn transistor

$$I_E' = I_{ES} \left[exp \left(\frac{V_{BE}}{V_T} \right) - 1 \right]$$


$$I_{C}' = I_{CS} \left[exp \left(\frac{V_{BC}}{V_{T}} \right) - 1 \right]$$


Bipolar junction transistors: Ebers-Moll model




* Current directions are assigned such that I_C , I_E , I_B are all positive if the BJT operates in the active mode.

 $I'_{C} = I_{CS} \left[exp \left(\frac{V_{BC}}{V_{T}} \right) - 1 \right]$







* The Ebers-Moll model can be interpreted as two transistors connected in parallel, each acting in the active mode.




- * The Ebers-Moll model can be interpreted as two transistors connected in parallel, each acting in the active mode.
- * The forward transistor is represented by the *E-B* diode and the corresponding dependent source (the upper branches), and the reverse transistor by the *C-B* diode and the corresponding dependent source (the lower branches).





* The model has four parameters: I_{ES} , I_{CS} , α_F , α_R (F for forward, R for reverse) which can be related to the geometry (base width, device area) and material parameters (doping densities, diffusion coefficients, lifetimes) of the transistor. ¹

¹R.F. Pierret, Semiconductor Device Fundamentals. New Delhi: Pearson Education, 1996.



- * The model has four parameters: I_{ES} , I_{CS} , α_F , α_R (F for forward, R for reverse) which can be related to the geometry (base width, device area) and material parameters (doping densities, diffusion coefficients, lifetimes) of the transistor.¹
- * With the assumptions we have made, $\alpha_F I_{ES} = \alpha_R I_{CS}$.

¹R.F. Pierret, Semiconductor Device Fundamentals. New Delhi: Pearson Education, 1996.

* Assumptions made:

- * Assumptions made:
 - Low-level injection

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths
 - No generation/recombination in the depletion regions

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths
 - No generation/recombination in the depletion regions
 - Constant width (W) of the neutral base region, independent of bias voltages

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths
 - No generation/recombination in the depletion regions
 - Constant width (W) of the neutral base region, independent of bias voltages
- * In practice, the above assumptions do not hold, e.g., as we have seen, the doping densities are not uniform.

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths
 - No generation/recombination in the depletion regions
 - Constant width (W) of the neutral base region, independent of bias voltages
- * In practice, the above assumptions do not hold, e.g., as we have seen, the doping densities are not uniform.
 - Furthermore, several details about the device such as lifetimes, mobilities, and base width, are not known.

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths
 - No generation/recombination in the depletion regions
 - Constant width (W) of the neutral base region, independent of bias voltages
- * In practice, the above assumptions do not hold, e.g., as we have seen, the doping densities are not uniform.
 - Furthermore, several details about the device such as lifetimes, mobilities, and base width, are not known.
- * The Ebers-Moll model can still be used as a "phenomenological" description of the device if model parameters are suitably extracted using measured data.

- * Assumptions made:
 - Low-level injection
 - Uniform doping densities, non-degenerate carrier statistics
 - One-dimensional device, with the emitter and collector regions much longer than the respective minority carrier diffusion lengths
 - No generation/recombination in the depletion regions
 - Constant width (W) of the neutral base region, independent of bias voltages
- * In practice, the above assumptions do not hold, e.g., as we have seen, the doping densities are not uniform.
 - Furthermore, several details about the device such as lifetimes, mobilities, and base width, are not known.
- * The Ebers-Moll model can still be used as a "phenomenological" description of the device if model parameters are suitably extracted using measured data.
- More advanced BJT models are available (e.g., the SPICE model²) and are used for circuit simulation.


²P. Antognetti and G. Massobrio, Semiconductor Device Modeling with SPICE. New York: McGraw-Hill, 1988.

pnp transistor




npn transistor







* Unlike the diode (where there is only one current and one voltage), the BJT has three currents and three voltages.




- * Unlike the diode (where there is only one current and one voltage), the BJT has three currents and three voltages.
- * The current-voltage relationship is described in the form of a "family" of curves, with a current selected as the *y* variable, a voltage as the *x* variable, and a third variable as a quantity to be held constant for each *I-V* curve.




- * Unlike the diode (where there is only one current and one voltage), the BJT has three currents and three voltages.
- * The current-voltage relationship is described in the form of a "family" of curves, with a current selected as the *y* variable, a voltage as the *x* variable, and a third variable as a quantity to be held constant for each *I-V* curve.
- * Two descriptions, which are related to the "common-base" and "common-emitter" configurations, are commonly used.







- * In the active region (where I_C is constant for a given I_B), the B-C junction is reverse biased.
 - \rightarrow $I_C' \approx 0 \rightarrow I_C = \alpha_F I_E = \beta I_B$, irrespective of V_{CE} .




- * In the active region (where I_C is constant for a given I_B), the B-C junction is reverse biased.
 - $\rightarrow I_C' \approx 0 \rightarrow I_C = \alpha_F I_E = \beta I_B$, irrespective of V_{CE} .
- * When V_{BC} becomes greater than about 0.4 V, I_C' becomes significant, and $I_C = \alpha_F I_E' I_C'$ decreases $\rightarrow I_C < \beta I_B$.




- * In the active region (where I_C is constant for a given I_B), the B-C junction is reverse biased.
 - $\rightarrow I_C' \approx 0 \rightarrow I_C = \alpha_E I_E = \beta I_B$, irrespective of V_{CE} .
- * When V_{BC} becomes greater than about 0.4 V, I_C' becomes significant, and $I_C = \alpha_F I_F' I_C'$ decreases $\rightarrow I_C < \beta I_B$.
- * In the active region (e.g., $V_{CE} = 1 \, \text{V}$), V_{BE} is nearly constant ($\sim 0.65 \, \text{V}$).




- * In the active region (where I_C is constant for a given I_B), the B-C junction is reverse biased. $\rightarrow I_C' \approx 0 \rightarrow I_C = \alpha_E I_E = \beta I_B$, irrespective of V_{CE} .
- * When V_{BC} becomes greater than about 0.4 V, I_C' becomes significant, and $I_C = \alpha_F I_E' I_C'$ decreases $\to I_C < \beta I_B$.
- * In the active region (e.g., $V_{CE} = 1 \, \text{V}$), V_{BE} is nearly constant ($\sim 0.65 \, \text{V}$).
- * In the saturtion region, V_{CE} is 0.2 V or smaller. This is generally true for all low-power BJTs.







* Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1 \text{ V (active region)}$:




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1 \text{ V (active region)}$: $V_{BC} = V_{BF} - V_{CF} \approx 0.7 - 1 = -0.3 \text{ V}$




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1 \text{ V (active region)}$: $V_{BC} = V_{BE} - V_{CE} \approx 0.7 - 1 = -0.3 \text{ V} \rightarrow I_C' \approx 0$




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE}=1$ V (active region): $V_{BC}=V_{BE}-V_{CE}\approx 0.7-1=-0.3$ V \rightarrow $I_C'\approx 0$ \rightarrow $I_B=I_E'-\alpha_FI_E'$




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - V_{CE} = 1 V (active region): $V_{BC} = V_{BE} V_{CE} \approx 0.7 1 = -0.3 \, \text{V} \rightarrow I_C' \approx 0 \rightarrow I_B = I_E' \alpha_F I_E' \approx (1 \alpha_F) \, I_{ES} e^{V_{BE}/V_T}.$




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1$ V (active region): $V_{BC} = V_{BE} V_{CE} \approx 0.7 1 = -0.3 \text{ V} \rightarrow I_C' \approx 0 \rightarrow I_B = I_E' \alpha_F I_E' \approx (1 \alpha_F) I_{ES} e^{V_{BE}/V_T}.$
 - $V_{CE} = 0 \text{ V}$ (saturation region):



- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1$ V (active region): $V_{BC} = V_{BE} - V_{CE} \approx 0.7 - 1 = -0.3$ V $\rightarrow I_C' \approx 0 \rightarrow I_B = I_F' - \alpha_F I_E' \approx (1 - \alpha_F) I_{ES} e^{V_{BE}/V_T}$.
 - $V_{CE} = 0 \text{ V}$ (saturation region): $V_{BC} = V_{BE} - V_{CE} = V_{BE}$




- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1$ V (active region): $V_{BC} = V_{BE} V_{CE} \approx 0.7 1 = -0.3 \text{ V} \rightarrow I_C' \approx 0 \rightarrow I_B = I_E' \alpha_F I_E' \approx (1 \alpha_F) I_{ES} e^{V_{BE}/V_T}.$
 - $V_{CE} = 0$ V (saturation region): $V_{BC} = V_{BE} - V_{CE} = V_{BE} \rightarrow I_C'$ is comparable to I_E' .



- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1 \text{ V}$ (active region): $V_{BC} = V_{BE} - V_{CE} \approx 0.7 - 1 = -0.3 \text{ V} \rightarrow I_C' \approx 0 \rightarrow I_B = I_E' - \alpha_E I_E' \approx (1 - \alpha_E) I_{ES} e^{V_{BE}/V_T}$.
 - $V_{CE} = 0 \text{ V}$ (saturation region):

$$V_{BC}=V_{BE}-V_{CE}=V_{BE}
ightarrow I_C'$$
 is comparable to I_E' .

$$\rightarrow I_B = (1 - \alpha_F)I'_E + (1 - \alpha_R)I'_C$$



- * Comparison of I_B versus V_{BE} for $V_{CE} = 0 \text{ V}$ and $V_{CE} = 1 \text{ V}$:
 - $V_{CE} = 1 \text{ V (active region)}$:

$$V_{BC} = V_{BE} - V_{CE} \approx 0.7 - 1 = -0.3 \,\text{V} \rightarrow I_C' \approx 0 \rightarrow I_B = I_E' - \alpha_F I_E' \approx (1 - \alpha_F) \,I_{ES} e^{V_{BE}/V_T}$$

- $V_{CE} = 0 \text{ V}$ (saturation region):

$$V_{BC} = V_{BE} - V_{CE} = V_{BE} \rightarrow I_C'$$
 is comparable to I_E' .

$$\rightarrow$$
 $I_B = (1 - \alpha_F)I'_E + (1 - \alpha_R)I'_C \rightarrow I_B$ - V_{BE} curve shifts left.