
SEMICONDUCTOR DEVICES


Carrier Transport: Part 2





M.B.Patil
mbpatil@ee.iitb.ac.in
www.ee.iitb.ac.in/~sequel

Department of Electrical Engineering Indian Institute of Technology Bombay












* The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.




- * The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:




- * The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:
 - band structure of the semiconductor




- * The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:
 - band structure of the semiconductor
 - presence of light of an appropriate wavelength




- The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:
 - band structure of the semiconductor
 - presence of light of an appropriate wavelength
 - defects and impurity atoms in the semiconductor




- * The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:
 - band structure of the semiconductor
 - presence of light of an appropriate wavelength
 - defects and impurity atoms in the semiconductor
 - electron and hole densities




- The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:
 - band structure of the semiconductor
 - presence of light of an appropriate wavelength
 - defects and impurity atoms in the semiconductor
 - electron and hole densities
 - temperature




- * The processes of generation and recombination of electron-hole pairs (EHPs) take place continuously.
- * The rates of generation and recombination depend on several factors:
 - band structure of the semiconductor
 - presence of light of an appropriate wavelength
 - defects and impurity atoms in the semiconductor
 - electron and hole densities
 - temperature
- * Some of these processes, with very small rates, may be completely ineffective, while others may be dominant.







* Direct recombination




- * Direct recombination
 - An electron from the conduction band combines directly with a hole in the valence band, thus destroying an EHP.




- * Direct recombination
 - An electron from the conduction band combines directly with a hole in the valence band, thus destroying an EHP.
 - The energy lost by the electron may be transferred to a photon (light) in "radiatve" recombination or to a phonon (lattice vibration) in "non-radiative" recombination.



- * Direct recombination
 - An electron from the conduction band combines directly with a hole in the valence band, thus destroying an EHP.
 - The energy lost by the electron may be transferred to a photon (light) in "radiatve" recombination or to a phonon (lattice vibration) in "non-radiative" recombination.
- * Direct generation



- * Direct recombination
 - An electron from the conduction band combines directly with a hole in the valence band, thus destroying an EHP.
 - The energy lost by the electron may be transferred to a photon (light) in "radiatve" recombination or to a phonon (lattice vibration) in "non-radiative" recombination.
- * Direct generation
 - An electron from the valence band goes directly to the conduction band, thus generating an EHP.




* Direct recombination


- An electron from the conduction band combines directly with a hole in the valence band, thus destroying an EHP.
- The energy lost by the electron may be transferred to a photon (light) in "radiatve" recombination or to a phonon (lattice vibration) in "non-radiative" recombination.

* Direct generation


- An electron from the valence band goes directly to the conduction band, thus generating an EHP.
- The energy required for the transition may be supplied by a photon (photo-generation) or a phonon (thermal generation).




- * Direct recombination
 - An electron from the conduction band combines directly with a hole in the valence band, thus destroying an EHP.
 - The energy lost by the electron may be transferred to a photon (light) in "radiatve" recombination or to a phonon (lattice vibration) in "non-radiative" recombination.
- * Direct generation
 - An electron from the valence band goes directly to the conduction band, thus generating an EHP.
 - The energy required for the transition may be supplied by a photon (photo-generation) or a phonon (thermal generation).
- * Since particles from both condution and valence bands are simultaneously involved, the above processes are called "band-to-band" G-R.




* In indirect G-R, the transitions from the conduction band to the valence band (and *vice versa*) take place through a "G-R centre," with an energy level E_T located in the forbidden gap.



- * In indirect G-R, the transitions from the conduction band to the valence band (and vice versa) take place through a "G-R centre," with an energy level E_T located in the forbidden gap.
- * The G-R centre could be due to a defect in the crystal or an impurity atom.




- * In indirect G-R, the transitions from the conduction band to the valence band (and *vice versa*) take place through a "G-R centre," with an energy level E_T located in the forbidden gap.
- * The G-R centre could be due to a defect in the crystal or an impurity atom.
- * Recombination or generation takes place in two steps.




- * In indirect G-R, the transitions from the conduction band to the valence band (and *vice versa*) take place through a "G-R centre," with an energy level E_T located in the forbidden gap.
- * The G-R centre could be due to a defect in the crystal or an impurity atom.
- * Recombination or generation takes place in two steps.

 (For some centres, it is more likely that an electron trapped from the conduction band will be released back to the conduction band; such a centre is called an electron trap.)




- * In indirect G-R, the transitions from the conduction band to the valence band (and vice versa) take place through a "G-R centre," with an energy level E_T located in the forbidden gap.
- * The G-R centre could be due to a defect in the crystal or an impurity atom.
- Recombination or generation takes place in two steps.
 (For some centres, it is more likely that an electron trapped from the conduction band will be released back to the conduction band; such a centre is called an electron trap.)
- * Indirect G-R processes are particularly efficient when E_T lies close to the middle of the band gap.

G-R with three particles




* In auger recombination, an electron from the conduction band recombines with a hole in the valence band, and its energy is transferred to another electron in the conduction band.

G-R with three particles




- * In auger recombination, an electron from the conduction band recombines with a hole in the valence band, and its energy is transferred to another electron in the conduction band
- * In the reverse process of impact ionisation, a high-energy electron loses its energy $(> E_g)$ but remains in the conduction band, and the energy is used by a valence band electron to make a transition to the conduction band, thus generating an EHP.


G-R with three particles




- * In auger recombination, an electron from the conduction band recombines with a hole in the valence band, and its energy is transferred to another electron in the conduction band
- * In the reverse process of impact ionisation, a high-energy electron loses its energy ($> E_g$) but remains in the conduction band, and the energy is used by a valence band electron to make a transition to the conduction band, thus generating an EHP.




* In silicon, the dominant non-radiative G-R process is that involving a G-R centre.




- * In silicon, the dominant non-radiative G-R process is that involving a G-R centre.
- * The *net* rate of recombination per unit volume is given by the Shockley–Read–Hall (SRH) formula, $R-G=\frac{n\,p-n_i^2}{\tau_p(n+n_1)+\tau_n(p+p_1)}$.




- * In silicon, the dominant non-radiative G-R process is that involving a G-R centre.
- * The *net* rate of recombination per unit volume is given by the Shockley–Read–Hall (SRH) formula, $R-G=\frac{n\,p-n_i^2}{\tau_p(n+n_1)+\tau_n(p+p_1)}$.
- * τ_n is called the electron lifetime. τ_p is called the hole lifetime.






- * In silicon, the dominant non-radiative G-R process is that involving a G-R centre.
- * The *net* rate of recombination per unit volume is given by the Shockley–Read–Hall (SRH) formula, $R-G=\frac{n\,p-n_i^2}{\tau_p(n+n_1)+\tau_n(p+p_1)}$.
- * τ_n is called the electron lifetime. τ_p is called the hole lifetime.
- * The parameters n_1 and p_1 depend on E_T and are given by $n_1 = n_i e^{(E_T E_i)/kT}, \quad p_1 = n_i e^{(E_i E_T)/kT}.$



- * In silicon, the dominant non-radiative G-R process is that involving a G-R centre.
- * The *net* rate of recombination per unit volume is given by the Shockley–Read–Hall (SRH) formula, $R-G=\frac{n\,p-n_i^2}{\tau_p(n+n_1)+\tau_n(p+p_1)}$.
- * τ_n is called the electron lifetime. τ_p is called the hole lifetime.
- * The parameters n_1 and p_1 depend on E_T and are given by $n_1 = n_i e^{(E_T E_i)/kT}$, $p_1 = n_i e^{(E_i E_T)/kT}$.
- * Since the most effective G-R centres have $E_T \approx E_i$, n_1 and p_1 are generally much smaller than the majority carrier density in a doped semiconductor.

$$R-G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}.$$


Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0=10^{16}\,\mathrm{cm}^{-3}$, $p_0=10^4\,\mathrm{cm}^{-3}$.



$$R-G=\frac{n\,p-n_i^2}{\tau_p(n+n_1)+\tau_n(p+p_1)}.$$

Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0=10^{16}\,\mathrm{cm}^{-3}$, $p_0=10^4\,\mathrm{cm}^{-3}$.

Suppose that additional carriers are created in the semiconductor (e.g., by shining light on the sample), giving rise to "excess concentrations" $\Delta p = \Delta n = 10^{12} \, \mathrm{cm}^{-3}$.




$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}.$$

Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0 = 10^{16}$ cm⁻³, $p_0 = 10^4$ cm⁻³.

Suppose that additional carriers are created in the semiconductor (e.g., by shining light on the sample), giving rise to "excess concentrations" $\Delta p = \Delta n = 10^{12} \, \mathrm{cm}^{-3}$.

The total concentrations are $n = n_0 + \Delta n$ and $p = p_0 + \Delta p$,



$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}.$$


Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0 = 10^{16}$ cm⁻³, $p_0 = 10^4$ cm⁻³.

Suppose that additional carriers are created in the semiconductor (e.g., by shining light on the sample), giving rise to "excess concentrations" $\Delta p = \Delta n = 10^{12} \, \mathrm{cm}^{-3}$.

The total concentrations are $n = n_0 + \Delta n$ and $p = p_0 + \Delta p$,

Applying the SRH formula, we get

$$R - G = \frac{(n_0 + \Delta n)(p_0 + \Delta p) - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$



Recombination

$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}.$$


Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0 = 10^{16}$ cm⁻³, $p_0 = 10^4$ cm⁻³.


Suppose that additional carriers are created in the semiconductor (e.g., by shining light on the sample), giving rise to "excess concentrations" $\Delta p = \Delta n = 10^{12} \, \mathrm{cm}^{-3}$.

The total concentrations are $n = n_0 + \Delta n$ and $p = p_0 + \Delta p$,

Applying the SRH formula, we get

$$R - G = \frac{(n_0 + \Delta n)(p_0 + \Delta p) - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$
$$= \frac{p_0 \Delta n + n_0 \Delta p + \Delta n \Delta p}{\tau_p(n + n_1) + \tau_n(p + p_1)} \quad \because n_0 p_0 = n_i^2$$





$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}.$$

Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0=10^{16}\,\mathrm{cm}^{-3}$, $p_0=10^4\,\mathrm{cm}^{-3}$.

Suppose that additional carriers are created in the semiconductor (e.g., by shining light on the sample), giving rise to "excess concentrations" $\Delta p = \Delta n = 10^{12} \, \mathrm{cm}^{-3}$.


The total concentrations are $n = n_0 + \Delta n$ and $p = p_0 + \Delta p$,

Applying the SRH formula, we get

$$R - G = \frac{(n_0 + \Delta n)(p_0 + \Delta p) - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$

$$= \frac{p_0 \Delta n + n_0 \Delta p + \Delta n \Delta p}{\tau_p(n + n_1) + \tau_n(p + p_1)} \quad \because n_0 p_0 = n_i^2$$

$$\approx \frac{p_0 \Delta n + n_0 \Delta p}{\tau_p(n_0 + \Delta n)} \quad \because n_1 \ll n_0, \ p + p_1 \ll n_0$$



$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}.$$

Let us consider a semiconductor in which electrons are the majority carriers, with the equilibrium values of n and p given by $n_0 = 10^{16}$ cm⁻³, $p_0 = 10^4$ cm⁻³.

Suppose that additional carriers are created in the semiconductor (e.g., by shining light on the sample), giving rise to "excess concentrations" $\Delta p = \Delta n = 10^{12} \, \mathrm{cm}^{-3}$.

The total concentrations are $n = n_0 + \Delta n$ and $p = p_0 + \Delta p$,


Applying the SRH formula, we get

$$R - G = \frac{(n_0 + \Delta n)(p_0 + \Delta p) - n_i^2}{\tau_p(n+n_1) + \tau_n(p+p_1)}$$


$$= \frac{p_0\Delta n + n_0\Delta p + \Delta n\Delta p}{\tau_p(n+n_1) + \tau_n(p+p_1)} \quad \because n_0 p_0 = n_i^2$$

$$\approx \frac{p_0\Delta n + n_0\Delta p}{\tau_p(n_0 + \Delta n)} \quad \because n_1 \ll n_0, \ p+p_1 \ll n_0$$

$$\approx \frac{n_0\Delta p}{\tau_p p_0} = \frac{\Delta p}{\tau_0}.$$




$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$
$$\approx \frac{\Delta p}{\tau_p} \quad (p_0 \ll n_0, \ \Delta n = \Delta p \ll n_0)$$



$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$
$$\approx \frac{\Delta p}{\tau_p} \quad (p_0 \ll n_0, \ \Delta n = \Delta p \ll n_0)$$

Similarly,
$$R-G pprox rac{\Delta n}{ au_n}$$
 if $n_0 \ll p_0, \ \Delta n = \Delta p \ll p_0.$





$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$
$$\approx \frac{\Delta p}{\tau_p} \quad (p_0 \ll n_0, \ \Delta n = \Delta p \ll n_0)$$

Similarly,
$$R - G \approx \frac{\Delta n}{\tau_n}$$
 if $n_0 \ll p_0$, $\Delta n = \Delta p \ll p_0$.

In conclusion,

* If the excess carrier densities Δn and Δp are small compared to the majority carrier density, the net recombination rate is governed by the minority carrier lifetime.







$$R - G = \frac{n p - n_i^2}{\tau_p(n + n_1) + \tau_n(p + p_1)}$$
$$\approx \frac{\Delta p}{\tau_p} \quad (p_0 \ll n_0, \ \Delta n = \Delta p \ll n_0)$$


Similarly,
$$R-G pprox rac{\Delta n}{ au_n}$$
 if $n_0 \ll p_0, \ \Delta n = \Delta p \ll p_0.$

In conclusion,


- * If the excess carrier densities Δn and Δp are small compared to the majority carrier density, the net recombination rate is governed by the minority carrier lifetime.
- * We will find this result useful in our discussion of diodes and bipolar junction transistors.








Two processes can change the number of electrons and holes in the box:




Two processes can change the number of electrons and holes in the box:

- carrier transport governed by \mathcal{F}_n and \mathcal{F}_p



Two processes can change the number of electrons and holes in the box:

- carrier transport governed by \mathcal{F}_n and \mathcal{F}_p
- generation and recombination of EHPs




Two processes can change the number of electrons and holes in the box:

- carrier transport governed by \mathcal{F}_n and \mathcal{F}_p
- generation and recombination of EHPs

The continuity equations serve to relate these phenomena.


Assume that there are no variations of n, p, ψ in the y and z directions. $\to \mathcal{F}_n$ and \mathcal{F}_p in the y and z directions are zero.



Assume that there are no variations of n, p, ψ in the y and z directions. $\to \mathcal{F}_n$ and \mathcal{F}_p in the y and z directions are zero.

The number of electrons in the box can change because of the following factors.


* Flux \mathcal{F}_n (if positive) brings electrons into the box at the rate $\mathcal{F}_n \times A$.



Assume that there are no variations of n, p, ψ in the y and z directions. $\to \mathcal{F}_n$ and \mathcal{F}_p in the y and z directions are zero.

The number of electrons in the box can change because of the following factors.


- * Flux \mathcal{F}_n (if positive) brings electrons into the box at the rate $\mathcal{F}_n \times A$.
- * Flux $\mathcal{F}_n(x+\Delta x)$ removes electrons from the box at the rate $\mathcal{F}_n(x+\Delta x) \times A$.



Assume that there are no variations of n, p, ψ in the y and z directions. $\to \mathcal{F}_n$ and \mathcal{F}_p in the y and z directions are zero.

The number of electrons in the box can change because of the following factors.

- * Flux \mathcal{F}_n (if positive) brings electrons into the box at the rate $\mathcal{F}_n \times A$.
- * Flux $\mathcal{F}_n(x + \Delta x)$ removes electrons from the box at the rate $\mathcal{F}_n(x + \Delta x) \times A$.
- * EHPs disappear from the box due to recombination at the rate (R-G)(x) ($A\Delta x$) (assuming Δx to be small).




Assume that there are no variations of n, p, ψ in the y and z directions. $\to \mathcal{F}_n$ and \mathcal{F}_p in the y and z directions are zero.

The number of electrons in the box can change because of the following factors.

- * Flux \mathcal{F}_n (if positive) brings electrons into the box at the rate $\mathcal{F}_n \times A$.
- * Flux $\mathcal{F}_n(x+\Delta x)$ removes electrons from the box at the rate $\mathcal{F}_n(x+\Delta x) \times A$.
- * EHPs disappear from the box due to recombination at the rate (R-G)(x) ($A\Delta x$) (assuming Δx to be small).

We can now relate the above factors to $\frac{\partial n}{\partial t}$:

$$(A \Delta x) \frac{\partial n}{\partial t} = \mathcal{F}_n(x) A - \mathcal{F}_n(x + \Delta x) A - (R - G) A \Delta x$$



Assume that there are no variations of n, p, ψ in the y and z directions. $\to \mathcal{F}_n$ and \mathcal{F}_p in the y and z directions are zero.


The number of electrons in the box can change because of the following factors.

- * Flux \mathcal{F}_n (if positive) brings electrons into the box at the rate $\mathcal{F}_n \times A$.
- * Flux $\mathcal{F}_n(x+\Delta x)$ removes electrons from the box at the rate $\mathcal{F}_n(x+\Delta x) \times A$.
- * EHPs disappear from the box due to recombination at the rate (R-G)(x) ($A\Delta x$) (assuming Δx to be small).


We can now relate the above factors to $\frac{\partial n}{\partial t}$:

$$(A \Delta x) \frac{\partial n}{\partial t} = \mathcal{F}_n(x) A - \mathcal{F}_n(x + \Delta x) A - (R - G) A \Delta x$$

$$\rightarrow \frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$




$$\frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$



$$\frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$

In the limit $\Delta x \rightarrow 0$, we get

$$\frac{\partial n}{\partial t} = -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G).$$




$$\frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$

In the limit $\Delta x \rightarrow 0$, we get

$$\frac{\partial n}{\partial t} = -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G).$$

Similarly, for holes,

$$\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} - (R - G).$$



$$\frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$


In the limit $\Delta x \rightarrow 0$, we get

$$\frac{\partial n}{\partial t} = -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G).$$

Similarly, for holes,

$$\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} - (R - G).$$

These equations are called the "continuity equations" for electrons and holes.



$$\frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$

In the limit $\Delta x \rightarrow 0$, we get

$$\frac{\partial n}{\partial t} = -\,\frac{\partial \mathcal{F}_n}{\partial x} - (R-G). \label{eq:delta_t}$$


Similarly, for holes,

$$\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} - (R - G).$$

These equations are called the "continuity equations" for electrons and holes.

We can rewrite the continuity equations in terms of the current densities

$$J_n = -q\mathcal{F}_n, \ J_p = +q\mathcal{F}_n$$
:



$$\frac{\partial n}{\partial t} = -\frac{\mathcal{F}_n(x + \Delta x) - \mathcal{F}_n(x)}{\Delta x} - (R - G).$$

In the limit $\Delta x \rightarrow 0$, we get

$$\frac{\partial n}{\partial t} = -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G).$$

Similarly, for holes,


$$\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} - (R - G).$$

These equations are called the "continuity equations" for electrons and holes.

We can rewrite the continuity equations in terms of the current densities

$$J_n = -q\mathcal{F}_n, \ J_p = +q\mathcal{F}_n$$
:

$$\frac{\partial n}{\partial t} = \frac{1}{q} \frac{\partial J_n}{\partial x} - (R - G), \quad \frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - (R - G).$$



A semiconductor device simulator solves the following coupled differential equations in a self-consistent manner:

$$\text{Poisson's equation:} \qquad \frac{\partial \mathcal{E}}{\partial \mathbf{x}} = \frac{\rho}{\epsilon} \quad \rightarrow \quad \frac{\partial^2 \psi}{\partial \mathbf{x}^2} = -\,\frac{\rho}{\epsilon},$$

A semiconductor device simulator solves the following coupled differential equations in a self-consistent manner:

Poisson's equation:
$$\frac{\partial \mathcal{E}}{\partial \mathbf{x}} = \frac{\rho}{\epsilon} \quad \rightarrow \quad \frac{\partial^2 \psi}{\partial \mathbf{x}^2} = -\,\frac{\rho}{\epsilon},$$

Continuity equation (n):
$$\frac{\partial n}{\partial t} = \frac{1}{q} \, \frac{\partial J_n}{\partial x} - (R - G),$$

A semiconductor device simulator solves the following coupled differential equations in a self-consistent manner:

Poisson's equation:
$$\frac{\partial \mathcal{E}}{\partial \mathbf{x}} = \frac{\rho}{\epsilon} \quad \rightarrow \quad \frac{\partial^2 \psi}{\partial \mathbf{x}^2} = -\frac{\rho}{\epsilon},$$

Continuity equation (n):
$$\frac{\partial n}{\partial t} = \frac{1}{q} \, \frac{\partial J_n}{\partial x} - (R - G),$$

$$\mbox{Continuity equation (p):} \quad \frac{\partial p}{\partial t} = -\frac{1}{q}\,\frac{\partial J_p}{\partial x} - (R-G),$$

A semiconductor device simulator solves the following coupled differential equations in a self-consistent manner:

Poisson's equation:
$$\frac{\partial \mathcal{E}}{\partial \mathbf{x}} = \frac{\rho}{\epsilon} \quad \rightarrow \quad \frac{\partial^2 \psi}{\partial \mathbf{x}^2} = -\,\frac{\rho}{\epsilon},$$

Continuity equation (n):
$$\frac{\partial n}{\partial t} = \frac{1}{q} \frac{\partial J_n}{\partial x} - (R - G),$$

$$\mbox{Continuity equation (p):} \quad \frac{\partial p}{\partial t} = -\frac{1}{q}\,\frac{\partial J_p}{\partial x} - (R-G),$$

with appropriate expressions substituted for ρ , J_n , J_p , (R-G), and with suitable boundary conditions.

A semiconductor device simulator solves the following coupled differential equations in a self-consistent manner:

Poisson's equation:
$$\frac{\partial \mathcal{E}}{\partial \mathbf{x}} = \frac{\rho}{\epsilon} \quad \rightarrow \quad \frac{\partial^2 \psi}{\partial \mathbf{x}^2} = -\frac{\rho}{\epsilon},$$

Continuity equation (n):
$$\frac{\partial n}{\partial t} = \frac{1}{q} \frac{\partial J_n}{\partial x} - (R - G),$$

Continuity equation (p):
$$\frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - (R - G),$$

with appropriate expressions substituted for ρ , J_n , J_p , (R-G), and with suitable boundary conditions.

The general problem is very complex and needs to be solved numerically.

A semiconductor device simulator solves the following coupled differential equations in a self-consistent manner:

Poisson's equation:
$$\frac{\partial \mathcal{E}}{\partial x} = \frac{\rho}{\epsilon} \quad \rightarrow \quad \frac{\partial^2 \psi}{\partial x^2} = -\frac{\rho}{\epsilon},$$


Continuity equation (n):
$$\frac{\partial n}{\partial t} = \frac{1}{a} \frac{\partial J_n}{\partial x} - (R - G),$$


Continuity equation (p):
$$\frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - (R-G),$$

with appropriate expressions substituted for ρ , J_n , J_ρ , (R-G), and with suitable boundary conditions.

The general problem is very complex and needs to be solved numerically.

However, we can gain significant insight by considering examples which represent situations in real semiconductor devices.






$$\label{eq:lambda} \begin{split} L = & \, 50 \, \mu \mathrm{m} \\ \mathrm{N_d} = & \, 5 \times 10^{17} \, \mathrm{cm}^{-3} \end{split}$$


 $T\,{=}\,300\,K\,\left(n_{i}\,{=}\,10^{10}\,cm^{-3}\right)$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1\frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \text{ cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E}=1\,\mathrm{kV/cm}$$
, $J\approx J_n^{\mathrm{drift}}=3.2\times 10^4\,\mathrm{A/cm^2}$ ($J_p^{\mathrm{drift}}\approx 0$, assuming p to be negligibly small).






$$\begin{split} L &= 50 \, \mu \text{m} \\ N_{\text{d}} &= 5 \times 10^{17} \, \text{cm}^{-3} \\ T &= 300 \, \text{K} \, \left(n_{\text{i}} = 10^{10} \, \text{cm}^{-3} \right) \end{split}$$


(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E} = 1 \, \text{kV/cm}$$
, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \, \text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).

* Poisson's equation:
$$\psi(x) = -\mathcal{E}x = (\text{constant})x \to \frac{d^2\psi}{dx^2} = 0$$
,






$$\begin{split} & L = 50~\mu\text{m} \\ & N_d = 5 \times 10^{17}~\text{cm}^{-3} \\ & T = 300~\text{K}~\left(\text{n}_i = 10^{10}~\text{cm}^{-3}\right) \end{split}$$


(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E} = 1 \,\text{kV/cm}$$
, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \,\text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).

* Poisson's equation:
$$\psi(x) = -\mathcal{E}x = (\text{constant}) x \to \frac{d^2 \psi}{dx^2} = 0$$
, i.e., $\rho = q(N_d^+ - n + p)$ must be zero, which is satisfied by our solution.






$$\label{eq:lambda} \begin{split} L = & \, 50 \, \mu \mathrm{m} \\ \mathrm{N_d} = & \, 5 \times 10^{17} \, \mathrm{cm}^{-3} \end{split}$$


 $T\,{=}\,300\,K\,\left(n_{i}\,{=}\,10^{10}\,cm^{-3}\right)$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1\frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \text{ cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E}=1\,\mathrm{kV/cm}$$
, $J\approx J_n^{\mathrm{drift}}=3.2\times 10^4\,\mathrm{A/cm^2}$ ($J_p^{\mathrm{drift}}\approx 0$, assuming p to be negligibly small).






$$L = 50 \, \mu m$$


$$N_d = 5 \times 10^{17} \, cm^{-3}$$

$$T = 300 \, K \, (n_i = 10^{10} \, cm^{-3})$$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{kV}{cm}$$
, i.e., $\psi(x) = -\mathcal{E}x + \text{constant}$, say $\psi(x) = -\mathcal{E}x$.

- (b) $n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$
- (c) $\mathcal{E} = 1 \, \text{kV/cm}$, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \, \text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).
 - * Continuity equation (electrons): Since this is a DC ("steady-state" situation), $\frac{\partial n}{\partial t} = 0 \rightarrow \frac{1}{q} \frac{\partial J_n}{\partial x} = R G$.







$$\begin{split} & L = 50 ~\mu\text{m} \\ & N_d = 5 \times 10^{17} ~\text{cm}^{-3} \\ & T = 300 ~\text{K} ~ \left(n_i = 10^{10} ~\text{cm}^{-3} \right) \end{split}$$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{kV}{cm}$$
, i.e., $\psi(x) = -\mathcal{E}x + \text{constant}$, say $\psi(x) = -\mathcal{E}x$.

- (b) $n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$
- (c) $\mathcal{E} = 1 \,\text{kV/cm}$, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \,\text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).
 - * Continuity equation (electrons): Since this is a DC ("steady-state" situation), $\frac{\partial n}{\partial t} = 0 \rightarrow \frac{1}{q} \frac{\partial J_n}{\partial x} = R G$. Since J_n is constant in our solution, R - G must be zero.







$$L = 50 \,\mu\text{m}$$

 $N_d = 5 \times 10^{17} \,\text{cm}^{-3}$
 $T = 300 \,\text{K} \, (n_i = 10^{10} \,\text{cm}^{-3})$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

- (b) $n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$
- (c) $\mathcal{E} = 1 \,\text{kV/cm}$, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \,\text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).






$$\begin{split} L &= 50 \, \mu m \\ N_d &= 5 \times 10^{17} \, \text{cm}^{-3} \\ T &= 300 \, \text{K} \, \left(n_i = 10^{10} \, \text{cm}^{-3} \right) \end{split}$$


Solution:

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

- (b) $n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$
- (c) $\mathcal{E} = 1 \, \text{kV/cm}$, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \, \text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).

We see that p is indeed negligibly small.





$$L = 50 \,\mu\text{m}$$


$$N_d = 5 \times 10^{17} \,\text{cm}^{-3}$$

$$T = 300 \,\text{K} \, \left(n_i = 10^{10} \,\text{cm}^{-3} \right)$$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1\frac{\mathsf{kV}}{\mathsf{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \mathsf{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \text{ cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E} = 1 \, \text{kV/cm}$$
, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \, \text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).





(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{kV}{cm}$$
, i.e., $\psi(x) = -\mathcal{E}x + \text{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E} = 1 \,\text{kV/cm}$$
, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \,\text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).

* Continuity equation (holes):
$$\frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - R - G$$
.





$$L = 50 \, \mu m$$

$$N_d = 5 \times 10^{17} \, cm^{-3}$$


$$T = 300 \, K \, (n_i = 10^{10} \, cm^{-3})$$

(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{\text{kV}}{\text{cm}}$$
, i.e., $\psi(x) = -\mathcal{E}x + \text{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L.$$

(c)
$$\mathcal{E}=1\,\mathrm{kV/cm},\ J\approx J_n^\mathrm{drift}=3.2\times 10^4\,\mathrm{A/cm^2}$$
 ($J_p^\mathrm{drift}\approx 0$, assuming p to be negligibly small).

* Continuity equation (holes):
$$\frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - R - G$$
.
Since $R - G = 0$ and $\frac{\partial p}{\partial t} = 0$, $\frac{\partial J_p}{\partial x} = 0$, i.e., $J_p = \text{constant}$.



(a)
$$\mathcal{E} = -\frac{d\psi}{dx} = -1 \frac{kV}{cm}$$
, i.e., $\psi(x) = -\mathcal{E}x + \text{constant}$, say $\psi(x) = -\mathcal{E}x$.

(b)
$$n \approx N_d = 5 \times 10^{17} \, \text{cm}^{-3} \text{ for } 0 < x < L$$

(c)
$$\mathcal{E} = 1 \, \text{kV/cm}$$
, $J \approx J_n^{\text{drift}} = 3.2 \times 10^4 \, \text{A/cm}^2$ ($J_p^{\text{drift}} \approx 0$, assuming p to be negligibly small).


* Continuity equation (holes):
$$\frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - R - G$$
.

Since $R - G = 0$ and $\frac{\partial p}{\partial t} = 0$, $\frac{\partial J_p}{\partial x} = 0$, i.e., $J_p = \text{constant}$.

$$\frac{J_p}{J_n} \approx \frac{J_p^{\text{drift}}}{J_n^{\text{drift}}} = \frac{\mu_p}{\mu_n} \frac{p_0}{n_0} = \frac{\mu_p}{\mu_n} \frac{n_i^2}{n_0^2} = \frac{\mu_p}{\mu_n} \left(\frac{10^{10}}{5 \times 10^{17}}\right)^2 = \frac{\mu_p}{\mu_n} \times 4 \times 10^{-16}$$
, really small!

Consider an *n*-type silicon sample with $N_d=10^{17}\,{\rm cm}^{-3}$. Light is (continuously) incident on its surface, resulting in an optical generation rate shown in the figure.

(We are assuming here that the light is entirely absorbed in a very thin region near the semiconductor surface (x=0) and does not penetrate deeper.)






Consider an *n*-type silicon sample with $N_d=10^{17}\,{\rm cm}^{-3}$. Light is (continuously) incident on its surface, resulting in an optical generation rate shown in the figure.

(We are assuming here that the light is entirely absorbed in a very thin region near the semiconductor surface (x=0) and does not penetrate deeper.)

Assume that, as a result of the incident light, the excess minority carrier concentration (i.e., $p - p_0$) at x = 0 is maintained at $\Delta p_1 = 10^{10}$ cm⁻³.







Consider an *n*-type silicon sample with $N_d=10^{17}\,{\rm cm}^{-3}$. Light is (continuously) incident on its surface, resulting in an optical generation rate shown in the figure.

(We are assuming here that the light is entirely absorbed in a very thin region near the semiconductor surface (x=0) and does not penetrate deeper.)


Assume that, as a result of the incident light, the excess minority carrier concentration (i.e., $p-p_0$) at x=0 is maintained at $\Delta p_1=10^{10}\,\mathrm{cm}^{-3}$.

Solve the continuity equation for holes and obtain $\Delta p(x)$. (T = 300 K)







* Since only one end of the semiconductor is perturbed, we expect a region with a deviation from equilibrium conditions. We do not know at this point the extent of this region.









- * Since only one end of the semiconductor is perturbed, we expect a region with a deviation from equilibrium conditions. We do not know at this point the extent of this region.
- * We expect $p(x \to \infty) = p_0$, i.e., $\Delta p(x \to \infty) \equiv p(x \to \infty) p_0 = 0$.









- * Since only one end of the semiconductor is perturbed, we expect a region with a deviation from equilibrium conditions. We do not know at this point the extent of this region.
- * We expect $p(x \to \infty) = p_0$, i.e., $\Delta p(x \to \infty) \equiv p(x \to \infty) p_0 = 0$.
- * At the surface (x=0), EHPs are continuously generated; therefre, we expect some excess hole concentration there, i.e., $p(0)=p_0+\Delta p_1$.









- * Since only one end of the semiconductor is perturbed, we expect a region with a deviation from equilibrium conditions. We do not know at this point the extent of this region.
- * We expect $p(x \to \infty) = p_0$, i.e., $\Delta p(x \to \infty) \equiv p(x \to \infty) p_0 = 0$.
- * At the surface (x=0), EHPs are continuously generated; therefre, we expect some excess hole concentration there, i.e., $p(0) = p_0 + \Delta p_1$.
- * We assume steady-state situation in which all quantities have settled to their steady-state forms, not varying with time.









* Continuity equation for holes: $\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} - (R - G) = 0.$









- * Continuity equation for holes: $\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} (R G) = 0.$
- * In steady state, the number of holes generated at x = 0 per second is equal to the total number of holes lost per second due to recombination.









- * Continuity equation for holes: $\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} (R G) = 0.$
- * In steady state, the number of holes generated at x = 0 per second is equal to the total number of holes lost per second due to recombination.
- * Because of diffusion and recombination, the excess hole concentration decreases from Δp_1 at x=0 to 0 at $x=\infty$.








- * Continuity equation for holes: $\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} (R G) = 0.$
- * In steady state, the number of holes generated at x = 0 per second is equal to the total number of holes lost per second due to recombination.
- * Because of diffusion and recombination, the excess hole concentration decreases from Δp_1 at x=0 to 0 at $x=\infty$.
- * Since $\Delta p_1(=10^{10}\,{\rm cm}^{-3})\ll n_0(=10^{17}\,{\rm cm}^{-3})$, we can approximate (R-G) with $\Delta p/ au_p$.









- * Continuity equation for holes: $\frac{\partial p}{\partial t} = -\frac{\partial \mathcal{F}_p}{\partial x} (R G) = 0.$
- * In steady state, the number of holes generated at x = 0 per second is equal to the total number of holes lost per second due to recombination.
- * Because of diffusion and recombination, the excess hole concentration decreases from Δp_1 at x=0 to 0 at $x=\infty$.
- * Since $\Delta p_1 (=10^{10} \, \mathrm{cm}^{-3}) \ll n_0 (=10^{17} \, \mathrm{cm}^{-3})$, we can approximate (R-G) with $\Delta p/ au_p$.
- * Let us assume that $J_p^{\text{drift}} \ll J_p^{\text{diff}}$ (to be verified later)


$$\to \mathcal{F}_{p} \approx \mathcal{F}_{p}^{\text{diff}} = -D_{p} \frac{\partial p}{\partial x} = -D_{p} \frac{\partial (p_{0} + \Delta p)}{\partial x} = -D_{p} \frac{\partial \Delta p}{\partial x}.$$








$$-\frac{\partial \mathcal{F}_p}{\partial x} - (R-G) = 0 \rightarrow -\frac{\partial}{\partial x} \left(-D_p \, \frac{\partial \Delta p}{\partial x} \right) - \, \frac{\Delta p}{\tau_p} = 0.$$







$$\begin{split} &-\frac{\partial \mathcal{F}_p}{\partial x} - (R - G) = 0 \to -\frac{\partial}{\partial x} \left(-D_p \, \frac{\partial \Delta p}{\partial x} \right) - \, \frac{\Delta p}{\tau_p} = 0. \\ &\to \frac{\partial^2 \Delta p}{\partial x^2} - \, \frac{\Delta p}{D_p \tau_p} = 0. \end{split}$$








$$\begin{split} &-\frac{\partial \mathcal{F}_{p}}{\partial x}-(R-G)=0\rightarrow -\frac{\partial}{\partial x}\left(-D_{p}\,\frac{\partial \Delta p}{\partial x}\right)-\frac{\Delta p}{\tau_{p}}=0.\\ &\rightarrow\frac{\partial^{2}\Delta p}{\partial x^{2}}-\frac{\Delta p}{D_{p}\tau_{p}}=0. \end{split}$$

The quantity $\sqrt{D_p au_p}$ has units of $\sqrt{\frac{\mathrm{cm}^2}{\mathrm{s}} \times \mathrm{s}} = \mathrm{cm}$ and is called the "hole diffusion length" L_p — also, in this case, the "minority carrier diffusion length" since holes are the minority carriers.








$$-\frac{\partial \mathcal{F}_{p}}{\partial x} - (R - G) = 0 \to -\frac{\partial}{\partial x} \left(-D_{p} \frac{\partial \Delta p}{\partial x} \right) - \frac{\Delta p}{\tau_{p}} = 0.$$

$$\to \frac{\partial^{2} \Delta p}{\partial x^{2}} - \frac{\Delta p}{D_{p} \tau_{p}} = 0.$$

The quantity $\sqrt{D_p\tau_p}$ has units of $\sqrt{\frac{\mathrm{cm}^2}{\mathrm{s}}\times\mathrm{s}}=\mathrm{cm}$ and is called the "hole diffusion length" L_p — also, in this case, the "minority carrier diffusion length" since holes are the minority carriers.

With this definition, we have

$$\frac{\partial^2 \Delta p}{\partial x^2} = \frac{\Delta p}{L_p^2} \ \to \ \Delta p(x) = A e^{-x/L_p} + B e^{x/L_p}.$$







$$-\frac{\partial \mathcal{F}_{p}}{\partial x} - (R - G) = 0 \to -\frac{\partial}{\partial x} \left(-D_{p} \frac{\partial \Delta p}{\partial x} \right) - \frac{\Delta p}{\tau_{p}} = 0.$$

$$\to \frac{\partial^{2} \Delta p}{\partial x^{2}} - \frac{\Delta p}{D_{p} \tau_{p}} = 0.$$


The quantity $\sqrt{D_p \tau_p}$ has units of $\sqrt{\frac{\text{cm}^2}{\text{s}} \times \text{s}} = \text{cm}$ and is called the "hole diffusion length" L_p — also, in this case, the "minority carrier diffusion length" since holes are the minority carriers.

With this definition, we have


$$\frac{\partial^2 \Delta p}{\partial x^2} = \frac{\Delta p}{L_p^2} \ \to \ \Delta p(x) = A e^{-x/L_p} + B e^{x/L_p}.$$

Using the boundary conditions, i.e., $\Delta p(0) = \Delta p_1$, $\Delta p(\infty) = 0$, we get

$$\Delta p(x) = \Delta p_1 e^{-x/L_p}$$







$$\begin{split} &-\frac{\partial \mathcal{F}_p}{\partial x} - (R - G) = 0 \to -\frac{\partial}{\partial x} \left(-D_p \, \frac{\partial \Delta p}{\partial x} \right) - \, \frac{\Delta p}{\tau_p} = 0. \\ &\to \frac{\partial^2 \Delta p}{\partial x^2} - \, \frac{\Delta p}{D_p \tau_p} = 0. \end{split}$$

The quantity $\sqrt{D_p \tau_p}$ has units of $\sqrt{\frac{\text{cm}^2}{\text{s}} \times \text{s}} = \text{cm}$ and is called the "hole diffusion length" L_p — also, in this case, the "minority carrier diffusion length" since holes are the minority carriers.

With this definition, we have


$$\frac{\partial^2 \Delta p}{\partial x^2} = \frac{\Delta p}{L_p^2} \rightarrow \Delta p(x) = A e^{-x/L_p} + B e^{x/L_p}.$$

Using the boundary conditions, i.e., $\Delta p(0) = \Delta p_1$, $\Delta p(\infty) = 0$, we get

$$\Delta p(x) = \Delta p_1 e^{-x/L_p}$$

Note:

* Our solution is valid provided J_p^{drift} is small compared to J_p^{diff} .







$$-\frac{\partial \mathcal{F}_{p}}{\partial x} - (R - G) = 0 \to -\frac{\partial}{\partial x} \left(-D_{p} \frac{\partial \Delta p}{\partial x} \right) - \frac{\Delta p}{\tau_{p}} = 0.$$

$$\to \frac{\partial^{2} \Delta p}{\partial x^{2}} - \frac{\Delta p}{D_{p} \tau_{p}} = 0.$$

The quantity $\sqrt{D_p \tau_p}$ has units of $\sqrt{\frac{\text{cm}^2}{\text{s}} \times \text{s}} = \text{cm}$ and is called the "hole diffusion length" L_p — also, in this case, the "minority carrier diffusion length" since holes are the minority carriers.

With this definition, we have


$$\frac{\partial^2 \Delta p}{\partial x^2} = \frac{\Delta p}{L_p^2} \rightarrow \Delta p(x) = A e^{-x/L_p} + B e^{x/L_p}.$$

Using the boundary conditions, i.e., $\Delta p(0) = \Delta p_1$, $\Delta p(\infty) = 0$, we get


$$\Delta p(x) = \Delta p_1 e^{-x/L_p}$$


Note:


- * Our solution is valid provided J_p^{drift} is small compared to J_p^{diff} .
- We could not have solved the continuity equations for electrons as easily since J_n^{drift} cannot be ignored; even a small electric field causes a significant J_n^{drift} because n is large.














* The analytical solution $\Delta p = \Delta p_1 e^{-x/L_p}$ matches very well with the numerical solution.




- * The analytical solution $\Delta p = \Delta p_1 e^{-x/L_p}$ matches very well with the numerical solution.
- * J_p^{drift} is negligibly small, as we had assumed.







*
$$L_p = \sqrt{D_p \tau_p} = \sqrt{\mu_p \ V_T \tau_p} = \sqrt{500 \ \frac{\text{cm}^2}{\text{V-s}}} \times 0.0258 \ \text{V} \times 10 \times 10^{-9} \ \text{s} = 3.6 \times 10^{-4} \ \text{cm} = 3.6 \ \mu\text{m}.$$




*
$$L_p = \sqrt{D_p \tau_p} = \sqrt{\mu_p \ V_T \tau_p} = \sqrt{500 \ \frac{\text{cm}^2}{\text{V}_{-\text{S}}}} \times 0.0258 \ \text{V} \times 10 \times 10^{-9} \ \text{s} = 3.6 \times 10^{-4} \ \text{cm} = 3.6 \ \mu\text{m}.$$


We expect the length of the perturbed region to be about 5 L_p or 18 μ m.






* The condition $\Delta p \ll n$ (in general, the excess minority carrier concentration being much smaller than the majority carrier concentration) is called "low-level injection," i.e., injection of a small number of minority carriers in a sea of majority carriers.







* The electron density is essentially constant $(=n_0)$, but there is a small change in n with respect to x which gives rise to a non-zero J_n^{diff} . $\Delta n(x) \approx \Delta p(x)$ (not shown).




- * The electron density is essentially constant $(=n_0)$, but there is a small change in n with respect to x which gives rise to a non-zero J_n^{diff} . $\Delta n(x) \approx \Delta p(x)$ (not shown).
- * The electric field is very small, but it is sufficient to cause a significant J_n^{drift} because n is large.







* The total current $J = J_n + J_p$ is zero throughout since we have an open-circuit condition.




- * The total current $J = J_n + J_p$ is zero throughout since we have an open-circuit condition.
- * The voltage drop ($\int \mathcal{E} dx$ in magnitude) is very small.




- * The total current $J = J_n + J_p$ is zero throughout since we have an open-circuit condition.
- * The voltage drop ($\int \mathcal{E} dx$ in magnitude) is very small.
- * To summarise, $\Delta p \ll n_0$, $J_p \approx J_p^{\text{diff}}$, $\Delta n(x) \approx \Delta p(x) \rightarrow \text{charge neutrality} \rightarrow \text{small } \mathcal{E}$, and $J^{\text{total}} = 0$.







* Suppose $G_{\rm opt}$ is increased such that $\Delta p_1 = 6 \times 10^{16} \, {\rm cm}^{-3}$. $\Delta p(0)$ is now comparable to the majority carrier density, and we have a high-level injection situation.




- * Suppose G_{opt} is increased such that $\Delta p_1 = 6 \times 10^{16} \, \text{cm}^{-3}$. $\Delta p(0)$ is now comparable to the majority carrier density, and we have a high-level injection situation.
- * J_{ρ}^{drift} is comparable to J_{ρ}^{diff} with high-level injection \to We would not be able to solve the continuity equation for holes analytically.






* Charge neutrality is still maintained almost perfectly because $\Delta n \approx \Delta p \to \Delta n + n_0 \approx \Delta p + N_d^+ \to n \approx p + N_d^+$ (since p_0 is small.)



- * Charge neutrality is still maintained almost perfectly because $\Delta n \approx \Delta p \to \Delta n + n_0 \approx \Delta p + N_d^+ \to n \approx p + N_d^+ \mbox{ (since } p_0 \mbox{ is small.)}$
- * $J^{\text{total}} = J_n + J_p$ remains equal to zero even with high-level injection.


Example

Consider a *p*-type silicon sample with $N_a=5\times 10^{17}\,\mathrm{cm^{-3}}$ at $T=300\,\mathrm{K}$. When it is illuminated uniformly with light of a certain wavelength, there is uniform generation throughout the sample at the rate of G_0 /cm³-s, where G_0 depends on the intensity of the incident light.



Consider a p-type silicon sample with $N_a=5\times 10^{17}\,\mathrm{cm}^{-3}$ at $T=300\,\mathrm{K}$. When it is illuminated uniformly with light of a certain wavelength, there is uniform generation throughout the sample at the rate of G_0/cm^3 -s, where G_0 depends on the intensity of the incident light.


For the excitations shown as Case 1 and Case 2, how does the excess electron concentration $\Delta n = n - n_0$ vary with time?




Consider a p-type silicon sample with $N_a=5\times 10^{17}\,\mathrm{cm}^{-3}$ at $T=300\,\mathrm{K}$. When it is illuminated uniformly with light of a certain wavelength, there is uniform generation throughout the sample at the rate of G_0/cm^3 -s, where G_0 depends on the intensity of the incident light.

For the excitations shown as Case 1 and Case 2, how does the excess electron concentration $\Delta n=n-n_0$ vary with time?

Note: The condition of uniform generation holds if the thickness of the sample h is much smaller than $1/\alpha$, where α is the absorption coefficient of silicon at the wavelength of the incident light.




$$\frac{\partial n}{\partial t} = -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G)_{SRH} + G_{opt}$$






$$\begin{aligned} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G)_{\text{SRH}} + G_{\text{opt}} \\ &= -(R - G)_{\text{SRH}} + G_0 \quad \because \text{ there is no variation in space} \end{aligned}$$






$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} + G_{\text{opt}} \\ &= -(R-G)_{\text{SRH}} + G_0 \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n} + G_0, \quad \text{assuming low-level injection} \end{split}$$






$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} + G_{\text{opt}} \\ &= -(R-G)_{\text{SRH}} + G_0 \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n} + G_0, \quad \text{assuming low-level injection} \\ &\therefore \quad \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n} + G_0. \end{split}$$




$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\mathsf{SRH}} + G_{\mathsf{opt}} \\ &= -(R-G)_{\mathsf{SRH}} + G_0 \quad \because \mathsf{there} \mathsf{ is no variation in space} \\ &= -\frac{\Delta n}{\tau_n} + G_0, \quad \mathsf{assuming low-level injection} \\ &\therefore \quad \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n} + G_0. \\ &\therefore \quad \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = G_0. \end{split}$$



Continuity equation for the minority carriers (electrons) for t>0 is,

$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} + G_{\text{opt}} \\ &= -(R-G)_{\text{SRH}} + G_0 \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n} + G_0, \quad \text{assuming low-level injection} \\ &\therefore \quad \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n} + G_0. \\ &\therefore \quad \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = G_0. \end{split}$$

Homogeneous solution: $\Delta n^{(h)} = A e^{-t/\tau_n}$.



Continuity equation for the minority carriers (electrons) for t>0 is,


$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{SRH} + G_{opt} \\ &= -(R-G)_{SRH} + G_0 \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n} + G_0, \quad \text{assuming low-level injection} \\ &\therefore \quad \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n} + G_0. \\ &\therefore \quad \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = G_0. \end{split}$$

Homogeneous solution: $\Delta n^{(h)} = A e^{-t/\tau_n}$.

Particular solution: $\Delta n^{(p)} = G_0 \tau_n$.

Continuity equation for the minority carriers (electrons) for t>0 is,

$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} + G_{\text{opt}} \\ &= -(R-G)_{\text{SRH}} + G_0 \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n} + G_0, \quad \text{assuming low-level injection} \\ &\therefore \quad \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n} + G_0. \end{split}$$



Homogeneous solution: $\Delta n^{(h)} = A e^{-t/\tau_n}$.


Particular solution: $\Delta n^{(p)} = G_0 \tau_n$.

 $\therefore \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_c} = G_0.$

$$\rightarrow \Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$

$$\Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$

At
$$t=0^-$$
, $G_{\mathrm{opt}}=0
ightarrow \Delta n=0$.






$$\Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$

At
$$t = 0^-$$
, $G_{\text{opt}} = 0 \rightarrow \Delta n = 0$.

 $\Delta n(0^+) = \Delta n(0^-)$ since Δn cannot change suddenly (that would require an infinite electron flux or an infinite G-R rate).






$$\Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$

At
$$t = 0^-$$
, $G_{\text{opt}} = 0 \rightarrow \Delta n = 0$.

 $\Delta n(0^+) = \Delta n(0^-)$ since Δn cannot change suddenly (that would require an infinite electron flux or an infinite G-R rate).

Using
$$\Delta n(0^+) = 0$$
, we get $A = -G_0 \tau_n$, and

$$\Delta n(t) = G_0 au_n \left(1 - e^{-t/ au_n}
ight)$$






$$\Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$


At
$$t = 0^-$$
, $G_{\text{opt}} = 0 \rightarrow \Delta n = 0$.


 $\Delta n(0^+) = \Delta n(0^-)$ since Δn cannot change suddenly (that would require an infinite electron flux or an infinite G-R rate).

Using
$$\Delta n(0^+) = 0$$
, we get $A = -G_0 \tau_n$, and

$$\Delta n(t) = G_0 au_n \left(1 - e^{-t/ au_n}
ight)$$







$$\Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$


At
$$t = 0^-$$
, $G_{\text{opt}} = 0 \rightarrow \Delta n = 0$.

 $\Delta n(0^+) = \Delta n(0^-)$ since Δn cannot change suddenly (that would require an infinite electron flux or an infinite G-R rate).


Using
$$\Delta n(0^+) = 0$$
, we get $A = -G_0 \tau_n$, and

$$\Delta n(t) = G_0 \tau_n \left(1 - e^{-t/\tau_n}\right)$$

In steady state, as $t \to \infty$, the rate of optical generation must be equal to the rate of net thermal recombination.







$$\Delta n(t) = A e^{-t/\tau_n} + G_0 \tau_n, \quad t > 0.$$

At
$$t = 0^-$$
, $G_{\text{opt}} = 0 \rightarrow \Delta n = 0$.

 $\Delta n(0^+) = \Delta n(0^-)$ since Δn cannot change suddenly (that would require an infinite electron flux or an infinite G-R rate).

Using
$$\Delta n(0^+) = 0$$
, we get $A = -G_0 \tau_n$, and


$$\Delta n(t) = G_0 \tau_n \left(1 - e^{-t/\tau_n}\right)$$

In steady state, as $t\to\infty$, the rate of optical generation must be equal to the rate of net thermal recombination.


$$ightarrow$$
 $G_0=rac{\Delta n}{ au_n}
ightarrow \Delta n=G_0 au_n$, as predicted by the above equation.








$$\frac{\partial n}{\partial t} = -\frac{\partial \mathcal{F}_n}{\partial x} - (R - G)_{SRH}$$
 (Note: no G_{opt} term here)




$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} \quad \text{(Note: no G_{opt} term here)} \\ &= -(R-G)_{\text{SRH}} \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n}, \quad \text{assuming low-level injection} \end{split}$$



$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} \quad \text{(Note: no } G_{\text{opt}} \text{ term here)} \\ &= -(R-G)_{\text{SRH}} \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n}, \quad \text{assuming low-level injection} \end{split}$$

$$\therefore \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n}.$$

$$\therefore \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = 0.$$



Continuity equation for the minority carriers (electrons) for t > 0 is,

$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} \quad \text{(Note: no G_{opt} term here)} \\ &= -(R-G)_{\text{SRH}} \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n}, \quad \text{assuming low-level injection} \end{split}$$


$$\therefore \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n}.$$

$$\therefore \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = 0.$$

Homogeneous solution: $\Delta n^{(h)} = A' e^{-t/\tau_n}$.

Particular solution: $\Delta n^{(p)} = 0$.

$$\to \ \Delta n(t) = A' \, e^{-t/\tau_n}, \quad t>0.$$



Continuity equation for the minority carriers (electrons) for t > 0 is,

$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} \quad \text{(Note: no G_{opt} term here)} \\ &= -(R-G)_{\text{SRH}} \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n}, \quad \text{assuming low-level injection} \end{split}$$

$$\therefore \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n}.$$

$$\therefore \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = 0.$$


Homogeneous solution: $\Delta n^{(h)} = A' e^{-t/\tau_n}$.

Particular solution: $\Delta n^{(p)} = 0$.

$$\rightarrow \Delta n(t) = A' e^{-t/\tau_n}, \quad t > 0.$$

We assume that, at $t = 0^-$, we have a steady-state situation, with

$$\Delta \textit{n}(0^-) = \textit{G}_0\tau_n \rightarrow \Delta \textit{n}(0^+) = \textit{G}_0\tau_n \rightarrow \textit{A}' = \textit{G}_0\tau_n.$$



Continuity equation for the minority carriers (electrons) for t > 0 is,

$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} \quad \text{(Note: no G_{opt} term here)} \\ &= -(R-G)_{\text{SRH}} \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n}, \quad \text{assuming low-level injection} \end{split}$$

$$\therefore \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n}.$$

$$\therefore \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = 0.$$

Homogeneous solution: $\Delta n^{(h)} = A' e^{-t/\tau_n}$


Particular solution: $\Delta n^{(p)} = 0$.

$$\rightarrow \Delta n(t) = A' e^{-t/\tau_n}, \quad t > 0.$$

We assume that, at $t = 0^-$, we have a steady-state situation, with

$$\Delta n(0^-) = G_0 \tau_n \to \Delta n(0^+) = G_0 \tau_n \to A' = G_0 \tau_n.$$

$$ightarrow \Delta n(t) = G_0 au_n e^{-t/ au_n}$$
.



Continuity equation for the minority carriers (electrons) for t > 0 is,

$$\begin{split} \frac{\partial n}{\partial t} &= -\frac{\partial \mathcal{F}_n}{\partial x} - (R-G)_{\text{SRH}} \quad \text{(Note: no G_{opt} term here)} \\ &= -(R-G)_{\text{SRH}} \quad \because \text{ there is no variation in space} \\ &= -\frac{\Delta n}{\tau_n}, \quad \text{assuming low-level injection} \end{split}$$

$$\therefore \frac{\partial (n_0 + \Delta n)}{\partial t} = -\frac{\Delta n}{\tau_n}.$$

$$\therefore \frac{\partial \Delta n}{\partial t} + \frac{\Delta n}{\tau_n} = 0.$$

Homogeneous solution: $\Delta n^{(h)} = A' e^{-t/\tau_n}$.

Particular solution: $\Delta n^{(p)} = 0$.

$$\rightarrow \Delta n(t) = A' e^{-t/\tau_n}, \quad t > 0.$$

We assume that, at $t = 0^-$, we have a steady-state situation, with

$$\Delta n(0^-) = G_0 \tau_n \rightarrow \Delta n(0^+) = G_0 \tau_n \rightarrow A' = G_0 \tau_n.$$

$$\rightarrow \Delta n(t) = G_0 \tau_n e^{-t/\tau_n}$$
.

