SEMICONDUCTOR DEVICES

p-n Junctions: Part 4



M.B.Patil
mbpatil@ee.iitb.ac.in
www.ee.iitb.ac.in/~sequel

Department of Electrical Engineering Indian Institute of Technology Bombay

$$I = qA\left(\frac{D_{p}p_{n0}}{L_{p}} + \frac{D_{n}n_{p0}}{L_{n}}\right)\left(e^{V_{a}/V_{T}} - 1\right)$$

$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \end{split}$$

$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$

$$\begin{split} I &= qA \left(\frac{D_\rho p_{n0}}{L_\rho} + \frac{D_n n_{\rho0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_\rho n_i^2}{N_d \sqrt{D_\rho \tau_\rho}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_\rho}{\tau_\rho}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$

Different materials (T = 300 K):

$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$

Different materials ($T = 300 \,\mathrm{K}$):

Semiconductor	N_c (cm ⁻³)	N_{ν} (cm ⁻³)	E_g (eV)	n_i (cm ⁻³)
Ge	1.04×10^{19}	$6.0 imes 10^{18}$	0.664	2.33×10^{13}
Si	$2.8 imes 10^{19}$	$1.04 imes 10^{19}$	1.12	1.02×10^{10}
GaAs	$4.7 imes 10^{17}$	$7.0 imes 10^{18}$	1.424	$2.1 imes 10^6$

$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$


Different materials ($T = 300 \,\mathrm{K}$):

Semiconductor	N_c (cm ⁻³)	N_{ν} (cm ⁻³)	E_g (eV)	n_i (cm ⁻³)
Ge	1.04×10^{19}	$6.0 imes 10^{18}$	0.664	2.33×10^{13}
Si	$2.8 imes 10^{19}$	$1.04 imes 10^{19}$	1.12	$1.02 imes 10^{10}$
GaAs	4.7×10^{17}	$7.0 imes 10^{18}$	1.424	$2.1 imes 10^6$

$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$

Different materials (T = 300 K):


Semiconductor	N_c (cm ⁻³)	N_{v} (cm ⁻³)	E_g (eV)	n_i (cm ⁻³)
Ge	1.04×10^{19}	$6.0 imes 10^{18}$	0.664	2.33×10^{13}
Si	$2.8 imes 10^{19}$	$1.04 imes 10^{19}$	1.12	$1.02 imes 10^{10}$
GaAs	$4.7 imes 10^{17}$	$7.0 imes 10^{18}$	1.424	$2.1 imes 10^6$



$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$

Different materials ($T = 300 \,\mathrm{K}$):


Semiconductor	N_c (cm ⁻³)	N_{v} (cm ⁻³)	E_g (eV)	n_i (cm ⁻³)
Ge	1.04×10^{19}	$6.0 imes 10^{18}$	0.664	2.33×10^{13}
Si	$2.8 imes 10^{19}$	$1.04 imes 10^{19}$	1.12	$1.02 imes 10^{10}$
GaAs	$4.7 imes 10^{17}$	$7.0 imes 10^{18}$	1.424	$2.1 imes 10^6$



$$\begin{split} I &= qA \left(\frac{D_p p_{n0}}{L_p} + \frac{D_n n_{p0}}{L_n} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{D_p n_i^2}{N_d \sqrt{D_p \tau_p}} + \frac{D_n n_i^2}{N_a \sqrt{D_n \tau_n}} \right) \left(e^{V_a/V_T} - 1 \right) \\ &= qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right) \left(e^{V_a/V_T} - 1 \right). \end{split}$$

Different materials ($T = 300 \,\mathrm{K}$):

Semiconductor	N_c (cm ⁻³)	N_{ν} (cm ⁻³)	E_g (eV)	n_i (cm ⁻³)
Ge	1.04×10^{19}	$6.0 imes 10^{18}$	0.664	2.33×10^{13}
Si	$2.8 imes 10^{19}$	$1.04 imes 10^{19}$	1.12	$1.02 imes 10^{10}$
GaAs	$4.7 imes 10^{17}$	$7.0 imes 10^{18}$	1.424	$2.1 imes 10^6$



 $I = I_s \left(e^{V_a/V_T} - 1 \right)$, where

–
$$1)$$
, where

The temperature dependence of I_s comes

mainly from $n_i(T)$.

$$p^2 \sqrt{D}$$
 p^2

 $I_s = qA\left(rac{n_i^2}{N_d}\sqrt{rac{D_p}{ au_p}} + rac{n_i^2}{N_a}\sqrt{rac{D_n}{ au_n}}
ight).$

$$\sqrt{D_{-}}$$
 n_{-}^2























 $I = I_s (e^{V_a/V_T} - 1)$, where

$$\frac{1}{n^2}$$

The temperature dependence of I_s comes

 $n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$

where $N_c \propto T^{3/2}$, $N_V \propto T^{3/2}$.

mainly from $n_i(T)$.

$$I_{s} = qA \left(\frac{n_{i}^{2}}{N_{d}} \sqrt{\frac{D_{p}}{\tau_{p}}} + \frac{n_{i}^{2}}{N_{a}} \sqrt{\frac{D_{n}}{\tau_{n}}} \right).$$



 $I = I_s (e^{V_a/V_T} - 1)$, where

$$I_s = qA\left(rac{n_i^2}{N_d}\sqrt{rac{D_p}{ au_p}} + rac{n_i^2}{N_a}\sqrt{rac{D_n}{ au_n}}
ight).$$

The temperature dependence of I_s comes

 $n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$

with $E_g(0) = 1.17 \text{ eV}$, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

where $N_c \propto T^{3/2}$, $N_V \propto T^{3/2}$.

mainly from $n_i(T)$.

 $E_g(T)$ for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T \perp \beta}$ (eV),

Temperature dependence
$$I = I_s (e^{V_a/V_T} - 1), \text{ where}$$

$$I_s = qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right).$$

 $I_s = qA\left(\frac{n_i^2}{N_d}\sqrt{\frac{D_p}{\tau_D}} + \frac{n_i^2}{N_a}\sqrt{\frac{D_n}{\tau_D}}\right).$ 1.08 150 200 250 300 350 400 T(K)

 $E_g(T)$ for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T \perp \beta}$ (eV),

 $I = I_s (e^{V_a/V_T} - 1)$, where

$$E_{\mathcal{B}}(T)$$
 for silicon is given by $E_{\mathcal{B}}(T) = E_{\mathcal{B}}(0) - \frac{\Delta T}{T+\beta}$ (eV), with $E_{\mathcal{B}}(0) = 1.17$ eV, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

 $I = I_s (e^{V_a/V_T} - 1)$, where

$$\frac{n_i^2}{N_i} \sqrt{\frac{D_n}{D_n}}$$

with $E_g(0) = 1.17 \text{ eV}$, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

 $I_s = qA\left(\frac{n_i^2}{N_d}\sqrt{\frac{D_p}{\tau_D}} + \frac{n_i^2}{N_a}\sqrt{\frac{D_n}{\tau_D}}\right).$ The temperature dependence of I_s comes 1.08 mainly from $n_i(T)$. 150 200 250

300 350 400 T(K)

$$s(T) = \sqrt{N_c(T)N_V(T)} \epsilon$$

$$n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$$

where $N_c \propto T^{3/2}$, $N_v \propto T^{3/2}$.

$$E_g(T)$$
 for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T + \beta}$ (eV),

As
$$T$$
 increases, $E_g/2kT$ decreases, and n_i increases substantially because of the exponential function $\to I$ increases.

1.16

the exponential function $\rightarrow I$ increases.

Temperature dependence 10^{14} 1.16 $I = I_s (e^{V_a/V_T} - 1)$, where 10^{10} $n_i (cm^{-3})$ $I_s = qA\left(\frac{n_i^2}{N_A}\sqrt{\frac{D_p}{T_p}} + \frac{n_i^2}{N_a}\sqrt{\frac{D_n}{T_p}}\right).$ 10^{6} The temperature dependence of I_s comes 1.08 mainly from $n_i(T)$. 250 300 350 400 200 250 300 150 200 150 350 400

T(K)

T(K)

where
$$N_c \propto T^{3/2}$$
, $N_v \propto T^{3/2}$.

 $n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$

$$E_g(T)$$
 for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T + \beta}$ (eV),

with
$$E_{\sigma}(0) = 1.17 \,\text{eV}$$
, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

As T increases, $E_{\alpha}/2kT$ decreases, and n_i increases substantially because of the exponential function $\rightarrow I$ increases.

 $I = I_s (e^{V_a/V_T} - 1)$, where

$$I_s = qA\left(\frac{n_i^2}{N_d}\sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a}\sqrt{\frac{D_n}{\tau_n}}\right).$$

The temperature dependence of I_s comes mainly from $n_i(T)$.


$$n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$$


where $N_c \propto T^{3/2}$. $N_v \propto T^{3/2}$.

$$E_g(T)$$
 for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T + \beta}$ (eV),

with $E_g(0) = 1.17 \text{ eV}$, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

As T increases, $E_g/2kT$ decreases, and n_i increases substantially because of the exponential function $\rightarrow I$ increases.





 $I = I_s (e^{V_a/V_T} - 1)$, where

$$I_s = qA \left(\frac{n_i^2}{N_d} \sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a} \sqrt{\frac{D_n}{\tau_n}} \right).$$

The temperature dependence of I_s comes mainly from $n_i(T)$.


$$n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$$


where $N_c \propto T^{3/2}$. $N_v \propto T^{3/2}$.

$$E_g(T)$$
 for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T + \beta}$ (eV),

with $E_g(0) = 1.17 \text{ eV}$, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

As T increases, $E_g/2kT$ decreases, and n_i increases substantially because of the exponential function $\to I$ increases.





$$I = I_s (e^{V_a/V_T} - 1)$$
, where

$$I_s = qA\left(\frac{n_i^2}{N_d}\sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a}\sqrt{\frac{D_n}{\tau_n}}\right).$$

The temperature dependence of I_s comes mainly from $n_i(T)$.


$$n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$$

where $N_c \propto T^{3/2}$. $N_V \propto T^{3/2}$.

$$E_g(T)$$
 for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T + \beta}$ (eV),

with $E_g(0) = 1.17 \,\text{eV}$, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.

As T increases, $E_g/2kT$ decreases, and n_i increases substantially because of the exponential function $\to I$ increases.



$$I = I_s (e^{V_a/V_T} - 1)$$
, where

$$I_s = qA\left(\frac{n_i^2}{N_d}\sqrt{\frac{D_p}{\tau_p}} + \frac{n_i^2}{N_a}\sqrt{\frac{D_n}{\tau_n}}\right).$$

The temperature dependence of I_s comes mainly from $n_i(T)$.

1.16 2 1.08 1.08 1.00 200 250 300 350 400 T(K)

$$n_i(T) = \sqrt{N_c(T)N_v(T)} \exp\left(-\frac{E_g(T)}{2kT}\right),$$


where $N_c \propto T^{3/2}$, $N_V \propto T^{3/2}$.

$$E_g(T)$$
 for silicon is given by $E_g(T) = E_g(0) - \frac{\alpha T^2}{T + \beta}$ (eV),


with $E_g(0) = 1.17 \text{ eV}$, $\alpha = 4.73 \times 10^{-4}$, $\beta = 636$.


As T increases, $E_g/2kT$ decreases, and n_i increases substantially because of the exponential function $\to I$ increases.

For silicon, the I-V curve shifts by about $-2\,\mathrm{mV}/^\circ\mathrm{C}$ as the temperature is increased.












* A real diode cannot withstand indefinitely large reverse voltages and "breaks down" at some point as V_R is increased.



- * A real diode cannot withstand indefinitely large reverse voltages and "breaks down" at some point as V_B is increased.
- * Reverse breakdown can be due to
 - impact ionisation (avalanche breakdown)
 - tunneling (Zener breakdown)




Consider spherical objects srarting down from the top.




Consider spherical objects srarting down from the top.

* When an objects hits a tree, it loses some of its kinetic energy and starts downhill again with a reduced kinetic energy.




Consider spherical objects srarting down from the top.

- * When an objects hits a tree, it loses some of its kinetic energy and starts downhill again with a reduced kinetic energy.
- * There could be a "lucky" object which does not encounter a collision and therefore gains a higher kinetic energy as compared to other objects.



Consider spherical objects srarting down from the top.


- * When an objects hits a tree, it loses some of its kinetic energy and starts downhill again with a reduced kinetic energy.
- * There could be a "lucky" object which does not encounter a collision and therefore gains a higher kinetic energy as compared to other objects.
- * The slope plays a crucial role. Higher the slope, higher is the probablity that an object will gain a high kinetic energy.




Consider spherical objects srarting down from the top.

- * When an objects hits a tree, it loses some of its kinetic energy and starts downhill again with a reduced kinetic energy.
- * There could be a "lucky" object which does not encounter a collision and therefore gains a higher kinetic energy as compared to other objects.
- * The slope plays a crucial role. Higher the slope, higher is the probablity that an object will gain a high kinetic energy.


With this situation in mind, let us look at carrier transport in a semiconductor.




* If an electron moves some distance without scattering, it gains an energy E with respect to E_c at that location. This energy can be thought of as the kinetic energy of the electron.



- * If an electron moves some distance without scattering, it gains an energy E with respect to E_c at that location. This energy can be thought of as the kinetic energy of the electron.
- * Because of scattering events (phonons, impurity ions, etc.), an electron keeps losing the energy gained from the electric field, and it is constrained to stay near E_c .




- * If an electron moves some distance without scattering, it gains an energy E with respect to E_c at that location. This energy can be thought of as the kinetic energy of the electron.
- * Because of scattering events (phonons, impurity ions, etc.), an electron keeps losing the energy gained from the electric field, and it is constrained to stay near E_c .




- * If an electron moves some distance without scattering, it gains an energy E with respect to E_c at that location. This energy can be thought of as the kinetic energy of the electron.
- * Because of scattering events (phonons, impurity ions, etc.), an electron keeps losing the energy gained from the electric field, and it is constrained to stay near E_c .


(Note: For simplicity, we have not discussed the changes in the electron momentum in the other two directions.)




* A "lucky" electron which undergoes fewer scattering events can gain substantial energy.




- * A "lucky" electron which undergoes fewer scattering events can gain substantial energy.
- * When E exceeds E_g (or $1.5\,E_g$ for some semiconductors), impact ionisation can occur.



- * A "lucky" electron which undergoes fewer scattering events can gain substantial energy.
- * When E exceeds E_g (or $1.5 E_g$ for some semiconductors), impact ionisation can occur.




- * A "lucky" electron which undergoes fewer scattering events can gain substantial energy.
- * When E exceeds E_g (or $1.5 E_g$ for some semiconductors), impact ionisation can occur.
- * Impact ionisation: The energy lost by an electron in the conduction band is used by an electron in the valence band to make a transition to the conduction band.



- * A "lucky" electron which undergoes fewer scattering events can gain substantial energy.
- * When E exceeds E_g (or 1.5 E_g for some semiconductors), impact ionisation can occur.
- * Impact ionisation: The energy lost by an electron in the conduction band is used by an electron in the valence band to make a transition to the conduction band.

Before impact ionisation: one electron

After impact ionisation: two electrons and one hole





- * A "lucky" electron which undergoes fewer scattering events can gain substantial energy.
- * When E exceeds E_g (or 1.5 E_g for some semiconductors), impact ionisation can occur.
- * Impact ionisation: The energy lost by an electron in the conduction band is used by an electron in the valence band to make a transition to the conduction band.


Before impact ionisation: one electron

After impact ionisation: two electrons and one hole


* The key requirement for impact ionisation to occur is a high electric field.









* Impact ionisation can be caused by a high-energy electron or a high-energy hole.







* A lucky electron gains energy, causes impact ionisation and gives rise to two electrons and one hole.



- * A lucky electron gains energy, causes impact ionisation and gives rise to two electrons and one hole.
- * Each of these carriers can potentially cause impact ionisation because of the high electric field (if they travel without scattering) \rightarrow "avalanche" multiplication.




- * A lucky electron gains energy, causes impact ionisation and gives rise to two electrons and one hole.
- * Each of these carriers can potentially cause impact ionisation because of the high electric field (if they travel without scattering) \rightarrow "avalanche" multiplication.
- * The avalanche multiplication process is obviously very complicated, but it can be characterised in a simple manner by a "critical field" \mathcal{E}_c if the electric field in the device exceeds \mathcal{E}_c , we can expect avalanche multiplication, leading to large currents.



- * A lucky electron gains energy, causes impact ionisation and gives rise to two electrons and one hole.
- * Each of these carriers can potentially cause impact ionisation because of the high electric field (if they travel without scattering) \rightarrow "avalanche" multiplication.
- * The avalanche multiplication process is obviously very complicated, but it can be characterised in a simple manner by a "critical field" \mathcal{E}_c if the electric field in the device exceeds \mathcal{E}_c , we can expect avalanche multiplication, leading to large currents.
- * For Ge, Si, and GaAs, the critical field at room temperature is about 100, 300, and 400 kV/cm, respectively.

For a p^+n silicon diode, estimate the doping density required on the n side for a breakdown voltage of 50 V, given that $\mathcal{E}_c = 250 \, \mathrm{kV/cm}$.


For a p^+n silicon diode, estimate the doping density required on the n side for a breakdown voltage of 50 V, given that $\mathcal{E}_c = 250 \, \mathrm{kV/cm}$.



For a p^+n silicon diode, estimate the doping density required on the n side for a breakdown voltage of 50 V, given that $\mathcal{E}_c = 250 \, \text{kV/cm}$.

Solution: The maximum electric field occurs at the junction and is given by

$$\mathcal{E}_m = rac{2(V_{\mathrm{bi}} + V_R)}{W} = rac{2(V_{\mathrm{bi}} + V_R)}{\sqrt{rac{2\epsilon}{q} rac{N_a + N_d}{N_a N_d} \left(V_{\mathrm{bi}} + V_R
ight)}} pprox \sqrt{rac{2qN_d(V_{\mathrm{bi}} + V_R)}{\epsilon}}.$$




For a p^+n silicon diode, estimate the doping density required on the n side for a breakdown voltage of 50 V, given that $\mathcal{E}_c = 250 \,\mathrm{kV/cm}$.

Solution: The maximum electric field occurs at the junction and is given by

$$\mathcal{E}_{m} = \frac{2(V_{\text{bi}} + V_{R})}{W} = \frac{2(V_{\text{bi}} + V_{R})}{\sqrt{\frac{2\epsilon}{q} \frac{N_{a} + N_{d}}{N_{a}N_{d}} (V_{\text{bi}} + V_{R})}} \approx \sqrt{\frac{2qN_{d}(V_{\text{bi}} + V_{R})}{\epsilon}}.$$

Since $V_R \gg V_{\rm bi}$ (which is less than 1 V), we get

$$N_d = \frac{\epsilon \, \mathcal{E}_m^2}{2 q V_R} = \frac{\epsilon \, \mathcal{E}_c^2}{2 q V_R} = \frac{11.7 \times 8.85 \times 10^{-14} \times (2.5 \times 10^5)^2}{2 \times 1.6 \times 10^{-19} \times 50} = 4 \times 10^{15} \, \text{cm}^{-3}.$$



For a p^+n silicon diode, estimate the doping density required on the n side for a breakdown voltage of 50 V, given that $\mathcal{E}_c = 250 \,\mathrm{kV/cm}$.


Solution: The maximum electric field occurs at the junction and is given by

$$\mathcal{E}_{m} = \frac{2(V_{\text{bi}} + V_{R})}{W} = \frac{2(V_{\text{bi}} + V_{R})}{\sqrt{\frac{2\epsilon}{q} \frac{N_{a} + N_{d}}{N_{a}N_{d}} (V_{\text{bi}} + V_{R})}} \approx \sqrt{\frac{2qN_{d}(V_{\text{bi}} + V_{R})}{\epsilon}}.$$


Since $V_R \gg V_{\rm bi}$ (which is less than 1 V), we get

$$N_d = \frac{\epsilon \, \mathcal{E}_m^2}{2qV_R} = \frac{\epsilon \, \mathcal{E}_c^2}{2qV_R} = \frac{11.7 \times 8.85 \times 10^{-14} \times (2.5 \times 10^5)^2}{2 \times 1.6 \times 10^{-19} \times 50} = 4 \times 10^{15} \, \mathrm{cm}^{-3}.$$


Units:
$$\frac{F}{cm} \left(\frac{V}{cm} \right)^2 \frac{1}{C} \frac{1}{V} = \frac{C}{V \cdot cm} \left(\frac{V}{cm} \right)^2 \frac{1}{C} \frac{1}{V} = \frac{1}{cm^3}$$
.



Zener breakdown




Zener breakdown




* Another mechanism which can cause reverse breakdown of a *pn* junction is quantum-mechanical tunneling.

Zener breakdown




- * Another mechanism which can cause reverse breakdown of a *pn* junction is quantum-mechanical tunneling.
- * For a significant tunneling current,
 - The barrier width (L) must be small, typically few nanometers.
 - There must be a large number of electrons on one side and a large number of available states on the other side.




- * Another mechanism which can cause reverse breakdown of a *pn* junction is quantum-mechanical tunneling.
- * For a significant tunneling current,
 - The barrier width (L) must be small, typically few nanometers.
 - There must be a large number of electrons on one side and a large number of available states on the other side.
- * With these points in mind, let us now look at a reverse-biased *pn* junction.


Eν




* The depletion width is given by $W=\sqrt{rac{2\epsilon}{q}\left(rac{1}{N_a}+rac{1}{N_d}
ight)(V_{
m bi}+V_R)}$.



- * The depletion width is given by $W = \sqrt{rac{2\epsilon}{q}\left(rac{1}{N_a} + rac{1}{N_d}
 ight)\left(V_{\mathrm{bi}} + V_R
 ight)}$.
- * As the reverse bias is increased, the barrier becomes thinner.





- * The depletion width is given by $W=\sqrt{rac{2\epsilon}{q}\left(rac{1}{N_{ extsf{a}}}+rac{1}{N_{ extsf{d}}}
 ight)}\left(V_{ extsf{bi}}+V_{ extsf{R}}
 ight).$
- * As the reverse bias is increased, the barrier becomes thinner.
- * There is a large number of electrons in the valence band on the *p* side and a large number of states (vacancies) in the conduction band on the *n* side.




- * The depletion width is given by $W=\sqrt{rac{2\epsilon}{q}}\left(rac{1}{N_{a}}+rac{1}{N_{d}}
 ight)\left(V_{\mathrm{bi}}+V_{R}
 ight).$
- * As the reverse bias is increased, the barrier becomes thinner.
- * There is a large number of electrons in the valence band on the *p* side and a large number of states (vacancies) in the conduction band on the *n* side.
- * Relatively large doping densities are required to ensure that the barrier is sufficiently thin for tunneling to occur.








* Silicon diodes with breakdown voltage $V_{\rm BR}$ ranging from a few volts to a thousand volts are commercially available.



- * Silicon diodes with breakdown voltage $V_{\rm BR}$ ranging from a few volts to a thousand volts are commercially available.
- * In diodes with $V_{\rm BR} < 5\,\rm V$, the breakdown is generally due to tunnelling; for higher values of $V_{\rm BR}$, it is due to avalanche multiplication.



- * Silicon diodes with breakdown voltage $V_{\rm BR}$ ranging from a few volts to a thousand volts are commercially available.
- * In diodes with $V_{\rm BR}$ < 5 V, the breakdown is generally due to tunnelling; for higher values of $V_{\rm BR}$, it is due to avalanche multiplication.
- * In some diodes (with $V_{\rm BR} \simeq 5\,{\rm V}$), it is possible that both mechanisms are active simultaneously.






* The pn junctions we have considered so far are called "homojunctions," i.e., junctions between similar (same) semiconductors on the p and n sides.




- * The pn junctions we have considered so far are called "homojunctions," i.e., junctions between similar (same) semiconductors on the p and n sides.
- * In a pn "heterojunction," two different semiconductors A and B are involved, where A is doped p-type, and B is doped n-type.




- * The pn junctions we have considered so far are called "homojunctions," i.e., junctions between similar (same) semiconductors on the p and n sides.
- * In a pn "heterojunction," two different semiconductors A and B are involved, where A is doped p-type, and B is doped n-type.
- * The two semiconductors must be lattice-matched, i.e., they must have the same lattice constant to avoid dislocations and device degradation.




* Because A and B are different semiconductors, there are discontinuities in the band edges (ΔE_c and ΔE_v).



- * Because A and B are different semiconductors, there are discontinuities in the band edges (ΔE_c and ΔE_v).
- * Depending on the material properties of A and B, different signs for ΔE_c and ΔE_v are possible.




- * Because A and B are different semiconductors, there are discontinuities in the band edges (ΔE_c and ΔE_v).
- * Depending on the material properties of A and B, different signs for ΔE_c and ΔE_v are possible.




- * Because A and B are different semiconductors, there are discontinuities in the band edges (ΔE_c and ΔE_v).
- * Depending on the material properties of A and B, different signs for ΔE_c and ΔE_v are possible.

Heterojunctions




- * Because A and B are different semiconductors, there are discontinuities in the band edges (ΔE_c and ΔE_v).
- * Depending on the material properties of A and B, different signs for ΔE_c and ΔE_v are possible.

Heterojunctions




- * Because A and B are different semiconductors, there are discontinuities in the band edges (ΔE_c and ΔE_v).
- * Depending on the material properties of A and B, different signs for ΔE_c and ΔE_v are possible.


(The bands are shown to be flat for simplicity. In practice, there will be some band bending due to the presence of an electric field.)



Consider a heterojunction between $n\text{-Al}_{0.3}\text{Ga}_{0.7}\text{As}$ and p-GaAs (which are lattice matched at 300 K).




The doping densities are such that the Fermi levels in the isolated materials are $E_F = E_c - 0.2\,\mathrm{eV}$ and $E_F = E_v + 0.3\,\mathrm{eV}$ on the n and p sides, respectively.



The doping densities are such that the Fermi levels in the isolated materials are $E_F = E_c - 0.2\,\mathrm{eV}$ and $E_F = E_v + 0.3\,\mathrm{eV}$ on the n and p sides, respectively.


At the junction, E_c for Al_{0.3}Ga_{0.7}As is higher than E_c for GaAs by $\Delta E_c = 0.27 \, \text{eV}$, and E_v for Al_{0.3}Ga_{0.7}As is lower than E_v for GaAs by $\Delta E_c = 0.13 \, \text{eV}$.



The doping densities are such that the Fermi levels in the isolated materials are $E_F = E_c - 0.2 \, \text{eV}$ and $E_F = E_v + 0.3 \, \text{eV}$ on the n and p sides, respectively.

At the junction, E_c for Al_{0.3}Ga_{0.7}As is higher than E_c for GaAs by $\Delta E_c = 0.27\,\mathrm{eV}$, and E_v for Al_{0.3}Ga_{0.7}As is lower than E_v for GaAs by $\Delta E_c = 0.13\,\mathrm{eV}$.

The energy gaps of $Al_{0.3}Ga_{0.7}As$ and GaAs are $1.82\,eV$ and $1.42\,eV$, respectively.




The doping densities are such that the Fermi levels in the isolated materials are $E_F=E_c-0.2\,\mathrm{eV}$ and $E_F=E_v+0.3\,\mathrm{eV}$ on the n and p sides, respectively.


At the junction, E_c for Al_{0.3}Ga_{0.7}As is higher than E_c for GaAs by $\Delta E_c = 0.27\,\mathrm{eV}$, and E_v for Al_{0.3}Ga_{0.7}As is lower than E_v for GaAs by $\Delta E_c = 0.13\,\mathrm{eV}$.

The energy gaps of Al_{0.3}Ga_{0.7}As and GaAs are 1.82 eV and 1.42 eV, respectively.


Sketch the band diagram of the pn junction in equilibrium.

Example







Example




* In equilibrium, the Fermi level must be constant.




* In equilibrium, the Fermi level must be constant.







* The electric field must be continuous except at the interface (x_j) [where $\epsilon(0^-)\mathcal{E}(0^-)=\epsilon(0^+)\mathcal{E}(0^+)$]. We assume that there is no surface charge at the interface.



- * The electric field must be continuous except at the interface (x_j) [where $\epsilon(0^-)\mathcal{E}(0^-)=\epsilon(0^+)\mathcal{E}(0^+)$]. We assume that there is no surface charge at the interface.
- * $E_c(0^-) E_c(0^+) = 0.27 \text{ eV}, E_v(0^+) E_c(0^-) = 0.13 \text{ eV (given)}.$





- * The electric field must be continuous except at the interface (x_j) [where $\epsilon(0^-)\mathcal{E}(0^-)=\epsilon(0^+)\mathcal{E}(0^+)$]. We assume that there is no surface charge at the interface.
- * $E_c(0^-) E_c(0^+) = 0.27 \text{ eV}, E_v(0^+) E_c(0^-) = 0.13 \text{ eV (given)}.$
- * $E_c(x) = -q\psi + \text{constant}$, $E_v(x) = E_c(x) E_g(x)$, where $E_g(x) = 1.82 \, \text{eV}$ for x < 0 and $E_g(x) = 1.42 \, \text{eV}$ for x > 0.



- * The electric field must be continuous except at the interface (x_j) [where $\epsilon(0^-)\mathcal{E}(0^-)=\epsilon(0^+)\mathcal{E}(0^+)$]. We assume that there is no surface charge at the interface.
- * $E_c(0^-) E_c(0^+) = 0.27 \text{ eV}, E_v(0^+) E_c(0^-) = 0.13 \text{ eV (given)}.$
- * $E_c(x) = -q\psi + \text{constant}$, $E_v(x) = E_c(x) E_g(x)$, where $E_g(x) = 1.82 \, \text{eV}$ for x < 0 and $E_g(x) = 1.42 \, \text{eV}$ for x > 0.
- The charge density variation is similar to that of a pn homojunction

 → the potential variation is also similar in the two cases.








*
$$E_c(0^-) - E_c(0^+) = 0.27 \text{ eV}, E_v(0^+) - E_c(0^-) = 0.13 \text{ eV (given)}.$$

*
$$E_c(x) = -q\psi + \text{constant}$$
, $E_v(x) = E_c(x) - E_g(x)$, where $E_g(x) = 1.82 \, \text{eV}$ for $x < 0$ and $E_g(x) = 1.42 \, \text{eV}$ for $x > 0$.


The charge density variation is similar to that of a pn homojunction
 → the potential variation is also similar in the two cases.









* The spike (discontinuity) ΔE_c is useful for fabricating high electron mobility transistors (HEMT).





- * The spike (discontinuity) ΔE_c is useful for fabricating high electron mobility transistors (HEMT).
- * If the heterojunction is graded, with semiconductor A changing over to semiconductor B gradually (say, over a few hundred angstroms), the discontinuities in E_c and E_v can be smoothed out.







- * The spike (discontinuity) ΔE_c is useful for fabricating high electron mobility transistors (HEMT).
- * If the heterojunction is graded, with semiconductor A changing over to semiconductor B gradually (say, over a few hundred angstroms), the discontinuities in E_c and E_v can be smoothed out.






- * The spike (discontinuity) ΔE_c is useful for fabricating high electron mobility transistors (HEMT).
- * If the heterojunction is graded, with semiconductor A changing over to semiconductor B gradually (say, over a few hundred angstroms), the discontinuities in E_c and E_v can be smoothed out.
- * The behaviour of a pn heterojunction is generally quite similar to that of a pn homojunction:







- st The spike (discontinuity) ΔE_c is useful for fabricating high electron mobility transistors (HEMT).
- * If the heterojunction is graded, with semiconductor A changing over to semiconductor B gradually (say, over a few hundred angstroms), the discontinuities in E_c and E_v can be smoothed out.
- * The behaviour of a pn heterojunction is generally quite similar to that of a pn homojunction:


 With forward bias, the depletion region shrinks. The current increases exponentially with forward bias.






- * The spike (discontinuity) ΔE_c is useful for fabricating high electron mobility transistors (HEMT).
- * If the heterojunction is graded, with semiconductor A changing over to semiconductor B gradually (say, over a few hundred angstroms), the discontinuities in E_c and E_v can be smoothed out.
- * The behaviour of a pn heterojunction is generally quite similar to that of a pn homojunction: With forward bias, the depletion region shrinks. The current increases exponentially with forward bias. With reverse bias, the depletion region expands. The current is negligibly small.






* Graded heterojunctions are used to fabricate heterojunction bipolar transistors (HBT) in which a high current gain and a small device resistance are simultaneously made possible because of different semiconductors used for the emitter and base regoins of the device.




Metal-semiconductor (M-S) junctions serve two important purposes in semiconductor devices:




Metal-semiconductor (M-S) junctions serve two important purposes in semiconductor devices:

* A metallic contact to a semiconductor device serves as the interface of the device with the external circuit. In this case, the M-S junction must be *ohmic*, i.e., it should be able to conduct a reasonably large current *in either direction* with a very small voltage drop across the junction.




Metal-semiconductor (M-S) junctions serve two important purposes in semiconductor devices:

* A metallic contact to a semiconductor device serves as the interface of the device with the external circuit. In this case, the M-S junction must be *ohmic*, i.e., it should be able to conduct a reasonably large current *in either direction* with a very small voltage drop across the junction.




Metal-semiconductor (M-S) junctions serve two important purposes in semiconductor devices:

- * A metallic contact to a semiconductor device serves as the interface of the device with the external circuit. In this case, the M-S junction must be *ohmic*, i.e., it should be able to conduct a reasonably large current *in either direction* with a very small voltage drop across the junction.
- * A rectifying M-S junction plays a key role in the operation of some semiconductor devices like the MESFET (Metal-Semiconductor Field-Effect Transistor). As the name implies, a rectifying M-S junction (also called a "Schottky contact") conducts well in one direction but blocks current in the other direction.



Metal-semiconductor (M-S) junctions serve two important purposes in semiconductor devices:

- * A metallic contact to a semiconductor device serves as the interface of the device with the external circuit. In this case, the M-S junction must be *ohmic*, i.e., it should be able to conduct a reasonably large current *in either direction* with a very small voltage drop across the junction.
- * A rectifying M-S junction plays a key role in the operation of some semiconductor devices like the MESFET (Metal-Semiconductor Field-Effect Transistor). As the name implies, a rectifying M-S junction (also called a "Schottky contact") conducts well in one direction but blocks current in the other direction.



Metal-semiconductor (M-S) junctions serve two important purposes in semiconductor devices:

- * A metallic contact to a semiconductor device serves as the interface of the device with the external circuit. In this case, the M-S junction must be *ohmic*, i.e., it should be able to conduct a reasonably large current *in either direction* with a very small voltage drop across the junction.
- * A rectifying M-S junction plays a key role in the operation of some semiconductor devices like the MESFET (Metal-Semiconductor Field-Effect Transistor). As the name implies, a rectifying M-S junction (also called a "Schottky contact") conducts well in one direction but blocks current in the other direction.


What decides whether a given M-S junction is ohmic or rectifying?

metal semiconductor


metal semiconductor

The band diagram of a metal-semiconductor junction is determined by


- metal work function ϕ_m (difference between the "vacuum level" and the Fermi level)




– metal work function $\phi_{\it m}$ (difference between the "vacuum level" and the Fermi level)




- metal work function ϕ_m (difference between the "vacuum level" and the Fermi level)
- electron affinity χ_s of the semiconductor (difference between the conduction band edge E_c and the vacuum level)



- metal work function ϕ_m (difference between the "vacuum level" and the Fermi level)
- electron affinity χ_s of the semiconductor (difference between the conduction band edge E_c and the vacuum level)





- metal work function ϕ_m (difference between the "vacuum level" and the Fermi level)
- electron affinity χ_s of the semiconductor (difference between the conduction band edge E_c and the vacuum level)
- doping density in the semiconductor (which sets the equilibrium Fermi level in the semiconductor)





The band diagram of a metal-semiconductor junction is determined by


- metal work function ϕ_m (difference between the "vacuum level" and the Fermi level)
- electron affinity χ_s of the semiconductor (difference between the conduction band edge E_c and the vacuum level)
- doping density in the semiconductor (which sets the equilibrium Fermi level in the semiconductor)
- additional electron states within the band gap at the interface
 (We will ignore this effect, i.e., we will assume the M-S interface to be perfect.)

















* There is a substantial barrier $qV_{\rm bi}=q\phi_{\it m}-q\phi_{\it s}$ to electron flow from S to M.




- * There is a substantial barrier $qV_{\rm bi}=q\phi_m-q\phi_s$ to electron flow from S to M.
- * In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\phi_m-q\chi_s$.




- * There is a substantial barrier $qV_{\rm bi}=q\phi_m-q\phi_s$ to electron flow from S to M.
- * In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\phi_m-q\chi_s$.
- * If a positive voltage is applied to the metal (w.r.t. the semiconductor), the barrier to electron flow from S to M reduces → current can flow.




- * There is a substantial barrier $qV_{\rm bi}=q\phi_m-q\phi_s$ to electron flow from S to M.
- * In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\phi_m-q\chi_s$.
- * If a positive voltage is applied to the metal (w.r.t. the semiconductor), the barrier to electron flow from S to M reduces → current can flow.
- * If a negative voltage is applied to the metal, the barrier increases \rightarrow negligible current flow.





- * There is a substantial barrier $qV_{\rm bi}=q\phi_m-q\phi_s$ to electron flow from S to M.
- * In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\phi_m-q\chi_s$.
- * If a positive voltage is applied to the metal (w.r.t. the semiconductor), the barrier to electron flow from S to M reduces → current can flow.
- * If a negative voltage is applied to the metal, the barrier increases → negligible current flow.
- * This condition leads to a rectifying contact.




- * There is a substantial barrier $qV_{\rm bi}=q\phi_m-q\phi_s$ to electron flow from S to M.
- * In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\phi_m-q\chi_s$.
- * If a positive voltage is applied to the metal (w.r.t. the semiconductor), the barrier to electron flow from S to M reduces → current can flow.
- * If a negative voltage is applied to the metal, the barrier increases → negligible current flow.
- * This condition leads to a rectifying contact.












* There is a no barrier to electron flow from S to M \rightarrow ohmic contact.




* There is a no barrier to electron flow from S to M \rightarrow ohmic contact.




- * There is a no barrier to electron flow from S to M \rightarrow ohmic contact.
- * In real semiconductors, there are significant departures from the ideal situation we have described.



- * There is a no barrier to electron flow from S to M \rightarrow ohmic contact.
- * In real semiconductors, there are significant departures from the ideal situation we have described.
 - At the M-S interface, the semiconductor crystal structure gets abruptly terminated, which results in incomplete ("dangling") covalent bonds or, in terms of the band picture, electron states within the forbidden gap.



- * There is a no barrier to electron flow from S to M \rightarrow ohmic contact.
- * In real semiconductors, there are significant departures from the ideal situation we have described.
 - At the M-S interface, the semiconductor crystal structure gets abruptly terminated, which results in incomplete ("dangling") covalent bonds or, in terms of the band picture, electron states within the forbidden gap.
 - There may be a thin ($\sim 10\,\text{Å}$) oxide layer between the metal and the semiconductor.




- * There is a no barrier to electron flow from S to M \rightarrow ohmic contact.
- * In real semiconductors, there are significant departures from the ideal situation we have described.
 - At the M-S interface, the semiconductor crystal structure gets abruptly terminated, which results in incomplete ("dangling") covalent bonds or, in terms of the band picture, electron states within the forbidden gap.
 - There may be a thin ($\sim 10\,\text{Å}$) oxide layer between the metal and the semiconductor.

Because of these complications, the barrier heights get modified. However, the qualitative picture remains valid as long as the actual experimentally measured barrier heights are used.


M. B. Patil. IIT Bombay

$\emph{p}\text{-type}$ semiconductor, $\phi_{\emph{m}}<\phi_{\emph{s}}$






p-type semiconductor, $\phi_{\it m} < \phi_{\it s}$




p-type semiconductor, $\phi_{\it m} < \phi_{\it s}$





* There is a substantial barrier $qV_{\rm bi}=q\phi_s-q\phi_m$ to hole flow from S to M. In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\chi_s+E_g-q\phi_m$, and the contact is therefore rectifying.

$\emph{p}\text{-type}$ semiconductor, $\phi_{\emph{m}}<\phi_{\emph{s}}$




* There is a substantial barrier $qV_{\rm bi}=q\phi_s-q\phi_m$ to hole flow from S to M. In the opposite direction (from M to S), there is also a substantial barrier $q\phi_B=q\chi_s+E_g-q\phi_m$, and the contact is therefore rectifying.






 $\emph{p}\text{-type}$ semiconductor, $\phi_{\emph{m}}>\phi_{\emph{s}}$




* There is a no barrier to hole flow from S to M \rightarrow ohmic contact.

$\emph{p}\text{-type}$ semiconductor, $\phi_{\emph{m}}>\phi_{\emph{s}}$



* There is a no barrier to hole flow from S to M \rightarrow ohmic contact.




* The *I-V* behaviour of a rectifying M-S junction is similar to that of a *pn* junction: Under forward bias, a large current flows with a small applied voltage. Under reverse bias, there is virtually no current flow.


- * The *I-V* behaviour of a rectifying M-S junction is similar to that of a *pn* junction: Under forward bias, a large current flows with a small applied voltage. Under reverse bias, there is virtually no current flow.
- * The mechanisms of current conduction in a rectifying M-S junction is very different.

- * The *I-V* behaviour of a rectifying M-S junction is similar to that of a *pn* junction: Under forward bias, a large current flows with a small applied voltage. Under reverse bias, there is virtually no current flow.
- * The mechanisms of current conduction in a rectifying M-S junction is very different.
- * In a pn junction, the current is due to injection of minority carriers (e.g., injection of electrons from the n side to the p side).

- * The *I-V* behaviour of a rectifying M-S junction is similar to that of a *pn* junction: Under forward bias, a large current flows with a small applied voltage. Under reverse bias, there is virtually no current flow.
- * The mechanisms of current conduction in a rectifying M-S junction is very different.
- * In a pn junction, the current is due to injection of minority carriers (e.g., injection of electrons from the n side to the p side).
- In an M-S junction, minority carriers play no role in current conduction, and it is the injection of the majority carriers from semiconductor to metal which determines the current.




Consider a M-S junction in equilibrium.



Consider a M-S junction in equilibrium.


* Close to the M-S interface, there is a depletion region, and for x>W, there is a charge-neutral region with a large number of electrons (majority carriers).



Consider a M-S junction in equilibrium.


- * Close to the M-S interface, there is a depletion region, and for x > W, there is a charge-neutral region with a large number of electrons (majority carriers).
- * The electron flow from S to M is determined by how many electrons can surmount the barrier $qV_{\rm bi}$. This current is called the "thermionic emission" current and is given by $J_{S \to M} = A^*T^2 \, e^{-\phi_B/V_T}$.


where A^* is the Richardson's constant (with units of A/cm²K²).




Consider a M-S junction in equilibrium.

- * Close to the M-S interface, there is a depletion region, and for x > W, there is a charge-neutral region with a large number of electrons (majority carriers).
- * The electron flow from S to M is determined by how many electrons can surmount the barrier $qV_{\rm bi}$. This current is called the "thermionic emission" current and is given by $J_{S\to M}=A^*T^2\,e^{-\phi_B/V_T},$ where A^* is the Richardson's constant (with units of A/cm²K²).
- * In equilibrium, there is an equal and opposite current density, $J_{M\to S}=-J_{S\to M}=-A^*T^2\,e^{-\phi_B/V_T}$, resulting in a net current density J=0.









With a forward voltage, the barrier to electron flow from S to M decreases by V_F while that for M to S remains the same, and the net current density is

$$\begin{split} J &= J_{S \to M} - J_{M \to S} = A^* \, T^2 \left[e^{-(\phi_B - V_F)/V_T} - e^{-\phi_B/V_T} \right] \\ &= A^* \, T^2 e^{-\phi_B/V_T} \left[e^{V_F/V_T} - 1 \right]. \end{split}$$



With a forward voltage, the barrier to electron flow from S to M decreases by V_F while that for M to S remains the same, and the net current density is


$$\begin{split} J &= J_{S \to M} - J_{M \to S} = A^* \, T^2 \left[e^{-(\phi_B - V_F)/V_T} - e^{-\phi_B/V_T} \right] \\ &= A^* \, T^2 e^{-\phi_B/V_T} \left[e^{V_F/V_T} - 1 \right]. \end{split}$$



With a forward voltage, the barrier to electron flow from S to M decreases by V_F while that for M to S remains the same, and the net current density is

$$\begin{split} J &= J_{S \to M} - J_{M \to S} = A^* T^2 \left[e^{-(\phi_B - V_F)/V_T} - e^{-\phi_B/V_T} \right] \\ &= A^* T^2 e^{-\phi_B/V_T} \left[e^{V_F/V_T} - 1 \right]. \end{split}$$

With a reverse bias, the S \to M barrier increases by V_R , and the above equation holds with, $V_F \to -V_R$.



With a forward voltage, the barrier to electron flow from S to M decreases by V_F while that for M to S remains the same, and the net current density is

$$\begin{split} J &= J_{S \to M} - J_{M \to S} = A^* \, T^2 \left[e^{-(\phi_B - V_F)/V_T} - e^{-\phi_B/V_T} \right] \\ &= A^* T^2 e^{-\phi_B/V_T} \left[e^{V_F/V_T} - 1 \right]. \end{split}$$

With a reverse bias, the S \to M barrier increases by V_R , and the above equation holds with, $V_F \to -V_R$. In summary, $J=J_s\left[e^{V/V_T}-1\right]$, where $J_s=A^*T^2\,e^{-\phi_B/V_T}$.

* For both pn and rectifying M-S junctions, we have $J = J_s \left(e^{V_a/V_T} - 1 \right)$.

- * For both pn and rectifying M-S junctions, we have $J = J_s \left(e^{V_a/V_T} 1 \right)$.
- * For a pn junction, $J_s = q \left(\frac{D_n n_{p0}}{L_n} + \frac{D_p p_{n0}}{L_p} \right)$ involves minority carrier densities and lifetimes.

- * For both pn and rectifying M-S junctions, we have $J=J_s\left(e^{V_a/V_T}-1\right)$.
- * For a pn junction, $J_s = q \left(\frac{D_n n_{p0}}{L_n} + \frac{D_p p_{n0}}{L_p} \right)$ involves minority carrier densities and lifetimes.
- * For a M-S junction, current conduction is dominated by thermionic emission of majority carriers. (In addition, there can be a tunnelling component of the current called "thermionic field emission." 1)


¹M. Shur, *Physics of Semiconductor Devices*. New Delhi: Prentice-Hall India, 1990.

- * For both pn and rectifying M-S junctions, we have $J=J_s\left(e^{V_a/V_T}-1\right)$.
- * For a pn junction, $J_s = q \left(\frac{D_n n_{p0}}{L_n} + \frac{D_p p_{n0}}{L_p} \right)$ involves minority carrier densities and lifetimes.
- * For a M-S junction, current conduction is dominated by thermionic emission of majority carriers. (In addition, there can be a tunnelling component of the current called "thermionic field emission." 1)
- * As we will see, turn-off of a pn diode involves removal of the excess minority carrier charge, a slow process governed by the lifetime of the minority carriers. In Schottky diodes, there is no such requirement, and therefore they can be turned off much faster.


¹M. Shur, *Physics of Semiconductor Devices*. New Delhi: Prentice-Hall India, 1990.

- * For both pn and rectifying M-S junctions, we have $J=J_s\left(e^{V_a/V_T}-1\right)$.
- * For a pn junction, $J_s = q \left(\frac{D_n n_{p0}}{L_n} + \frac{D_p p_{n0}}{L_p} \right)$ involves minority carrier densities and lifetimes.
- * For a M-S junction, current conduction is dominated by thermionic emission of majority carriers. (In addition, there can be a tunnelling component of the current called "thermionic field emission." 1)
- * As we will see, turn-off of a pn diode involves removal of the excess minority carrier charge, a slow process governed by the lifetime of the minority carriers. In Schottky diodes, there is no such requirement, and therefore they can be turned off much faster.
- Remark: The process of thermionic emission also takes place in a p-n junction, but it can be ignored.


¹M. Shur, *Physics of Semiconductor Devices*. New Delhi: Prentice-Hall India, 1990.




* The contact in (a) is rectifying because of the potential barrier.




- * The contact in (a) is rectifying because of the potential barrier.
- If the doping density is increased, the barrier width (depletion region width) decreases, and tunneling of electrons becomes possible even with a small applied voltage (of either polarity)




- * The contact in (a) is rectifying because of the potential barrier.
- If the doping density is increased, the barrier width (depletion region width) decreases, and tunneling of electrons becomes possible even with a small applied voltage (of either polarity)




- * The contact in (a) is rectifying because of the potential barrier.
- * If the doping density is increased, the barrier width (depletion region width) decreases, and tunneling of electrons becomes possible even with a small applied voltage (of either polarity)



- * The contact in (a) is rectifying because of the potential barrier.
- * If the doping density is increased, the barrier width (depletion region width) decreases, and tunneling of electrons becomes possible even with a small applied voltage (of either polarity) → an ohmic contact.





* In many practical situations, ohmic contacts are required to be made to an *n*-type or *p*-type semiconductor region with a moderate doping density, and a metal which will form an ohmic contact is either not available or is not technologically convenient.

semiconductor semiconductor Practical ohmic contacts p^+ n metal metal (b)

(a)

- * In many practical situations, ohmic contacts are required to be made to an n-type or p-type semiconductor region with a moderate doping density, and a metal which will form an ohmic contact is either not available or is not technologically convenient.
- * In such cases, a heavily doped region (of the same type) is first created, forming an n^+n or p^+p junction.

Practical ohmic contacts semiconductor n+ n metal metal E_E E_V

(a)

* In many practical situations, ohmic contacts are required to be made to an *n*-type or *p*-type semiconductor region with a moderate doping density, and a metal which will form an ohmic contact is either not available or is not technologically convenient.

(b)

- * In such cases, a heavily doped region (of the same type) is first created, forming an n^+n or p^+p junction.
- * These n^+n or p^+p junctions are essentially ohmic since a large number of majority carriers (of the same type) are available for conduction on both sides of the junction.


Practical ohmic contacts semiconductor n+ n metal metal E_c E_c E_v


(a)

* In many practical situations, ohmic contacts are required to be made to an *n*-type or *p*-type semiconductor region with a moderate doping density, and a metal which will form an ohmic contact is either not available or is not technologically convenient.


(b)


- * In such cases, a heavily doped region (of the same type) is first created, forming an n^+n or p^+p junction.
- * These n^+n or p^+p junctions are essentially ohmic since a large number of majority carriers (of the same type) are available for conduction on both sides of the junction.
- * Next, metal is deposited to make a metal- p^+ or metal- p^+ junction, which is ohmic irrespective of the barrier ϕ_B because of tunnelling. In this manner, the objective of making a low-resistance metallic contact is achieved. (In practice, metallic contacts also need to be "alloyed" by subjecting them to temperatures of $\sim 450\,^{\circ}\mathrm{C}$ for a few minutes.)







* Equilibrium: The net voltage drop is zero; the voltage drop ($V_{\rm bi}$) across the depletion region is equal and opposite to the sum of the other voltage drops.





* Forward bias: The voltage drops across the M-S junctions, the n^+ -n junction, and the p^+ -p junction remain the same as in equilibrium; the applied forward voltage appears across the depletion region $(V_{\rm bi} \rightarrow V_{\rm bi} - V_a)$.





* Reverse bias: The voltage drops across the M-S junctions, the n^+ -n junction, and the p^+ -p junction remain the same as in equilibrium; the applied reverse voltage appears across the depletion region ($V_{\rm bi} \rightarrow V_{\rm bi} + V_R$).