Work Instruction: Fan tray sub-assembly

Product: Nova-1 fan tray

Document: WI-NV1-FAN-001 Revision: A Date: 2026-10-12

General notes

> CAUTION: ESD sensitive. Wear a grounded wrist strap for all steps.

Use only parts from labelled bins. If the code on a bin does not match this document, stop and ask.

Parts list

Item	Part number	Description	Qty
1	C-61003	Fan 60 x 60 x 15 mm, 24 V	1
2	AF-7045-M3-25-A2	Pan head screw M3 x 25, Phillips	4
3	100-0311	Lock nut M3, nylon insert	4
4	100-0313	Plain washer M3, nylon	4
5	100-0999	Fan finger guard 60 mm	1
6	C-62002	Protective earth wire, M4 ring terminal	1
7	SCR-TX-36	Pan head screw M3 x 6, Torx	1
8	C-62003	Cable tie 100 x 2.5 mm	2

Step 1: Prepare the fan

Tools: ESD mat, side cutter

1. Take the fan (C-61003) from its bag.
2. Find the airflow arrow on the side of the fan housing.

Check: The airflow arrow points into the chassis.

Step 2: Fit the finger guard

Place the finger guard 100-0999 x1 on the outlet side of the fan.

> NOTE: The open side of the guard faces away from the fan.

Step 3: Fasten the fan to the bracket

Tools: PH1 screwdriver; torque driver

1. Fit 4 x AF-7045-M3-25-A2 through the guard, the fan and the bracket.
2. Fit a nylon washer 100-0313 x4 under each nut.
3. Fit 4 x 100-0311 lock nuts and tighten to 0.5 N·m.

> WARNING: Do not overtighten: the fan housing cracks above 0.6 N·m.

Check: The fan turns freely by hand.

Step 4: Earth the bracket

Tools: T10 driver, torque driver

Fit the earth wire C-62002 x1 with 1 x SCR-TX-36 and tighten to 0.8 N·m.

Verify the ring terminal does not turn.

Step 5: Dress the cable

1. Route the fan cable along the bracket edge.
2. Secure it with 2 x C-62003 and cut the tails flush.

Check: No cable touches the fan blades.