


GENESIS INSTRUCTIONS



CAUTION


- Small parts are contained. Children under 5 years old should not use without supervision.
- Take care not to drop the Genesis as heavy impacts may cause internal damage.
- Do not overcharge the battery as this may result in reduced battery life.
- Always unplug the charger when not in use.
- The Genesis is not suitable in damp or wet locations. Do NOT immerse in water.
- Store the Genesis in a cool, dry place when not in use.
- Do not place on or near heat sources.
- Do not cover your chosen shade and Genesis in any way when in use as this may cause overheating.
- Battery life is approximately 2 years.
- This Genesis is powered with lithium batteries and must ONLY be charged with the charger supplied or advised charger. Using the wrong charger will damage the battery and may result in fire.
- Dispose of all packaging in accordance with your local recycling regulations.
- Ensure the installation position of this product is in a safe and accessible location and must be out of reach of children.

PRODUCT NOTES

This Genesis is supplied with a built-in rechargeable battery which, once fully charged, will give approximately 15 hours of light.

INCLUDED IN THIS PACKAGE

- Genesis Light
- USB-C charging cable (5V 2A USB adapter not included)
- Wireless remote control
- Brass controller case



INSTRUCTIONS

- Before use, check thoroughly for any defects and do not use if defects are found.
- Plug in and fully charge before first use. Whilst charging the Genesis will display a blue light next to the touch button, this light will turn green once the Genesis is fully charged (Charging from empty to full will take approximately 5 hours).
- Once charging is complete remove the cable from the Genesis.
- The Genesis can be turned on and off using the touch button or wireless remote control.
- The Genesis will start to dim when the battery is low.

CLEANING INSTRUCTIONS

- Always switch off before cleaning.
- Do NOT use abrasive cleaners or water to clean.
- Wipe with a soft dry cloth.

Wireless Remote Controller Settings

On / Off
Dim / Brighten
Timer 15/30/60 minutes
Genesis Touch Button Settings
Tap - On / Off
Hold - Dim / Brighten

