


GENESIS INSTRUCTIONS



CAUTION

- **This product contains a lithium battery, if you drop on a hard surface this may cause internal damage, please contact customer service for a replacement**
- Small parts are contained. Children under 5 years old should not use without supervision.
- Always unplug the charger when not in use.
- The Genesis is not suitable in damp or wet locations. Do NOT immerse in water.
- Store the Genesis in a cool, dry place when not in use.
- Do not place on or near heat sources.
- Do not cover your chosen shade and Genesis in any way when in use as this may cause overheating.
- Battery life is approximately 2 years and can be replaced, contact Pooky for further details.
- This Genesis is powered with lithium batteries and must ONLY be charged with the charger supplied or advised charger. Using the wrong charger will damage the battery and may result in fire.
- Dispose of all packaging in accordance with your local recycling regulations.
- Ensure the installation position of this product is in a safe and accessible location and must be out of reach of children.

PRODUCT NOTES

This Genesis is supplied with a built-in rechargeable battery which, once fully charged, will give approximately 9-17 hours dependent on your chosen set brightness.

INCLUDED IN THIS PACKAGE

- Genesis Light
- USB-C charging cable (5V 2A USB adapter not included)
- Wireless remote control




INSTRUCTIONS

- Before use, check thoroughly for any defect and do not use if defects are found.
- Plug in and fully charge before first use. Whilst charging the Genesis will display a blue light next to the touch button, this light will turn green once the Genesis is fully charged (Charging from empty to full will take approximately 5 hours).
- Once charging is complete remove the cable from the Genesis.
- The Genesis can be turned on and off using the touch button or wireless remote control.
- The Genesis will start to dim when the battery is low.

CLEANING INSTRUCTIONS

- Always switch off before cleaning.
- Do NOT use abrasive cleaners or water to clean.
- Wipe with a soft dry cloth.



Wireless Remote Controller Settings
On / Off
Dim / Brighten
Timer 15/30/60 minutes
Genesis Touch Button Settings
Tap - On / Off
Hold - Dim / Brighten

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

If you experience any unresolved technical issues with the product, please contact our customer service team via our website.

