Lecture 03

Registers and Timers

Agenda for Today's Lecture

- 01 Recap of pulsing and LED
- **02** Memory and Registers
- 03 Timers Intro for Lab 1.3 (3rd out of 4 parts,

Lab 1.4 is practice on coding loops).

Developing with make and Makefile

- MEAM510 tools from me.design.seas.upenn.edu/
 - copy entire Blinky directory (Makefile /inc /src)
 - rename Blinky directory name to your project name.
 - edit /src/main.c
- Many ways to develop code.
 - Makefile has set of directives (rules) to create code. We'll go a little bit into what this does later in the semester.
- Do not use Arduino for Teensy.
 - It is important to learn lower level development tools.
 - We will use Arduino later with the ESP32,

Installation issues (check Piazza):

Do not use blinky from the pjrc tutorial. Use blinky.zip from canvas

Windows


- Be careful about onedrive and sync issues. (see piazza @46)
- Google msys-1.0.dll (see piazza @35)

MacOS

• Make not working: reinstall using brew (see piazza @39)

Teensy Loader and USB Demo





01

Pulsing and LEDs

LED resistor solution

$$I_F = 20 \text{ mA}$$
 $I_F = 30 \text{ mA}$

$$V_F = \text{typ. } 3.2 + / -0.1, \text{Max } 4V$$
 $V_F = 3.3 \text{ from graph}$

Worst case current when
$$Vf = 3.1$$

Voltage across resistor is
$$5-3.1 = 1.9V$$
 Voltage is $5-3.3 = 1.7V$

$$V = IR$$
 $V = IR$

$$R = 1.9V/20mA = 95 \text{ ohms}$$
 $R = 1.7V/30mA = 60 \text{ ohm}$

If you have room for only one and are limited to the standard 5% resistor sizes:

Closest resistor that is greater than 95 ohms is 100


		5% Standard Values Decade multiples are available from $10~\Omega$ through $22~\text{M}\Omega$									
10	11	12	13	15	16	18	20	22	24	27	30
33	36	39	43	47	51	56	62	68	75	82	91

Max LED brightness limited by heat

- LED's often use pulsed modes.
 - +>efficiency
 - + > brightness
 - + >lifetime
- Most LED flashlights actually pulse
- Human eye averages pulses, apparent brightness is higher than actual light energy

Digikey

ListedParameters




02

Memory and Registers


What is memory?

Memory holds addressable data that you can READ and/or WRITE to

Addresses enable reaching specific data




Memory READ




Data buş






Addressing





Note for ATmega32U4 all addresses are 16 bits (four hex digits) All data is referenced in 8 bit chunks

Motorola Style Memory Mapping Subsystems




Motorola Style Memory Mapping Subsystems






Harvard Architecture (ATmega 32 u4)



Teensy 2.0 Pin / Port assignments



Acronyms

- Px# = Port x, x=[B,C,D,F], # pin num = [0,7]
- DDRx = Data Direction Register for Port x
 - Ex: DDRD = data direction register for port D
- CPU = Central Processing Unit
- SRAM = Static Random Access Memory
- IO = Input / Output
- GPIO = General Purpose Input/Output

#define Macros - some examples

```
#define OFF
#define ON 1
#define ever (;;)
#define teensy led(val) set(DDRD,6); if(val==ON) {set(PORTD,6);}else
if (val==OFF) {clear(PORTD, 6);}else if (val==TOGGLE) {toggle(PORTD, 6);}
Subtle Bug in teensy LED:
Normal use:
teensy LED(ON); -> teensy LED(1);
teensy LED(OFF);-> teensy LED(0);
Breaks under this case:
int condition1 = 1, condition2 = 0;
teensy LED(condition1 || condition2);
```

Note, this would not happen if teensy LED was a subroutine.

#define Macros - recommendations

Use macros where constants are involved (no runtime costs)

```
#define set(reg,bit) reg |= (1<<(bit))
#define clear(reg,bit) reg &= ~(1<<(bit))
#define toggle(reg,bit) reg ^= (1<<(bit))</pre>
```

- Macros take more program space than subroutines.
- Macros run slightly faster than subroutines.
- Macros can lead to unexpected bugs.
- Use macros sparingly e.g. short statements that will make things clearer.
- Macros can sometimes be more confusing than subroutines.

Bitwise operators

Operator	Result	Example			
(bitwise OR)	l if any of the two bits are l	1100 0011 = 1111			
& (bitwise AND)	l only if both bits are l	1001 & 0011 = 0001			
^ (bitwise XOR)	l if two bits are different	1001 ^ 0011 = 1010			
<< (bitwise left shift)	Left shifts X times	0011 << 2 = 1100			
>> (bitwise right shift)	Right shifts X times	1001 >> 2 = 0010			
~ (bitwise NOT)	Inverts all 0's and 1's	~ 1001 = 0110			


```
#define set(reg,bit) reg |= (1<<(bit))
#define clear(reg,bit) reg &= ~(1<<(bit))
#define toggle(reg,bit) reg ^= (1<<(bit))</pre>
```

Bitwise operators

Evernele	Onorotions	Dogu14				
Example	Operations	Result				
set(reg,2),	10001000 = (1<<(2))	0000001				
reg = 0x88	Shift left once	0000010				
	Shift left twice	00000100				
	reg = 0x88 = 10001000	10001000				
	OR with reg	10001100				
Δltormotive 1.	mog - b10001100.					
	reg = b10001100; reg = 0x8C;	Bit #2				
Alternative 3:	-					
	$reg = reg \mid 0x04;$					
#defi	ne set(reg,bit)	reg = (1<<(bit))				
#defi	ne clear(reg,bit)	reg &= ~(1<<(bit))				
#defi	ne toggle(reg,bit)	reg ^= (1<<(bit))				

Ex: using set to put 5V at a pin

Memory Map 0x0000 Why is set (PORTD, 2); better than using 0x000A DDRD PORTD = 0x04;? 0x000B PORTD set(PORTD,2);



Bitwise operators

Example	Operations	Result
set(reg,2), reg = 0x88	10001000 = (1<<(2)) Shift left once Shift left twice reg = 0x88 = 10001000 OR with reg	0000001 0000010 0000100 1000100 10001100
<pre>clear(reg,3), reg = 0x88</pre>	10001000 &= ~(1<<(3)) Shift left three times Invert reg = 0x88 = 10001000 AND with reg	00000001 00001000 11110111 10001000 10000000

```
#define set(reg,bit) reg |= (1<<(bit)) Bit #3
#define clear(reg,bit) reg &= ~(1<<(bit))
#define toggle(reg,bit) reg ^= (1<<(bit))</pre>
```

Bitwise operators


Example	Operations	Result
<pre>set(reg,2), reg = 0x88</pre>	10001000 = (1<<(2)) Shift left once Shift left twice reg = 0x88 = 10001000 OR with reg	00000001 0000010 00000100 10001000 10001100
<pre>clear(reg,3), reg = 0x88</pre>	10001000 &= ~(1<<(3)) Shift left three times Invert reg = 0x88 = 10001000 AND with reg	$00000001\\00001000\\\underline{11110111}\\10001000\\10000000$
<pre>toggle(reg, 2) reg = 0x88</pre>	10001000 ^= (1<<(2)) Shift left once Shift left twice reg = 0x88 = 10001000 XOR with reg (toggle bit 2)	$00000001\\0000010\\\underline{00000100}\\10001000\\10001100$

Example Program

```
/* Blink.c - Blinks internal LED
#include <avr/io.h>
                              QUESTION 1: (in private chat)
int main(void)
                              What does DDRD=0x40; do?
                              What does PORTD ^= 0x40; do?
    DDRD = 0x40;
                                         QUESTION 2 (in private chat):
    for(;;){
                                         Rewrite this line using macros
      int i;
                                         set clear toggle
                                         Assume DDRD starts as 0x00:
      PORTD ^= 0x40;
      for (i=0;i<30000; i++);
                     /* never reached */
    return 0;
```

02 Timers

Harvard Architecture (ATmega 32 u4)




Example Program

```
/* Blink.c - Blinks internal LED */
#include <avr/io.h>
int main(void)
   DDRD = 0x40;
   for(;;){
     int i;
     PORTD ^= 0x40;
     for (i=0;i<30000; i++); - Runs";" no-op, 30,000 times
   return 0; /* never reached */
```

Timer/Counters

8-bit

"Free running" counter




Timer example

Note: this code won't work as is

- 200Hz Blink -> 1/400sec on, 1/400sec off
- Q3: For 16Mhz clock how many clock cycles pass in 1/400 sec?

```
#include "teensy general.h"
#define COMPAREVALUE ??????
                                                              GND
                                                              PB0
int main()
                                                              PB1
                                                              PB<sub>2</sub>
 DDRC |= 0x40; //Port C6 as output \
                                                              PB3
 TCCR3B = 0x01; // Turn on counter (no prescale)
                                                             PB7
  for (;;) {
                                                              PD0
    if (TCNT3 > COMPAREVALUE) {
                                                              PD1
      toggle(PORTC, 6);
                                                              PD2
      TCNT3 = 0; // Reset the timer to 0
                                                              PD3
                                                              PC6
  return 0;
```

Typical Datasheet Register Description



- Our compiler uses the register name and the bit names
- Some bits are read only, some bits are write only
- Most registers bits default to 0 on reset

12

		Name	D:: -	D:: 0	D	Dir. 4	Dit 0	Dir. o	Dir. 4	D'' 0	_	
martin	Address	TCNT4	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3 unter Register Lo	Bit 2	Bit 1	Bit 0	Page	
TCNT	(0xBD)	ICN14	TWAM6	TWAM5	TWAM4	TWAM3	TWAM2	TWAM1	TWAM0			
10111	(0xBC)	TWCR	TWINT	TWEA	TWSTA	TWSTO	TWWC	TWEN	-	TWIE		
	(0xBB)	TWDR			•	2-wire Serial Inte	erface Data Regis		•			
	(0xBA)	TWAR	TWA6	TWA5	TWA4	TWA3	TWA2	TWA1	TWA0	TWGCE		
	(0xB9) (0xB8)	TWSR	TWS7	TWS6	TWS5	TWS4	TWS3 ace Bit Rate Reg	-	TWPS1	TWPS0		
	(0xB7)	Reserved		-		-wire Senai Inten	ace bit Hate Heg	ister				
	(0xB6)	Reserved										
	(0xB5)	Reserved	-	-	-	-	-	-	-	-		
	(0xB4)	Reserved	-		-	-	-	-	-	-		
	(0xB3)	Reserved	-	-	-	-	-	-	-	-		
	(0xB2)	Reserved	-	-	-	-	-	-	-	-		
	(0xB1) (0xB0)	Reserved Reserved				-	-	-				
	(0xAF)	Reserved				-		-	- :			
	(0xAE)	Reserved	-	-	-	-	-	-	-	-		
	(0xAD)	Reserved	-		-	-	-	-	-	-		
	(0xAC)	Reserved	-	-	-	-	-	-	-	-		
	(0xAB)	Reserved			-	-		-				
	(0xAA) (0xA9)	Reserved Reserved		-	-	-	-	-	-	-		
	(0xA8)	Reserved			-					-		
	(0xA7)	Reserved	-	-	-					-		
	(0xA6)	Reserved	-	-	-	-	-	-	-	-		
	(0xA5)	Reserved	-	-	-	-	-	-	-	-		
	(0xA4)	Reserved	-	-	-	-	-	-	-	-		
	(0xA3)	Reserved	-	-	-	-	-	-	-	-		
	(0xA2) (0xA1)	Reserved Reserved					-			-		
	(0xA0)	Reserved	-	-	-	-	-		-	-		
	(0x9F)	Reserved	-	-	-	-	-	-	-	-		
	(0x9E)	Reserved	-		-	-	-	-	-	-		
	(0x9D)	OCR3CH										
	(0x9C)	OCR3CL					Compare Register					
	(0x9B) OCR3BH Timer/Counter3 - Output Compare Register B High Byte (0x9A) OCR3BL Timer/Counter3 - Output Compare Register B Low Byte											
	(0x99)	OCR3AH		Timer/Counter3 - Output Compare Register B Low Byte Timer/Counter3 - Output Compare Register A High Byte								
	(0x98)	OCR3AL					Compare Register					
m < 3 mm	(0-97)	ICR3H			Timer/0	Counter3 - Input	Capture Register	High Byte				
TCNT	(0 96)	1000					Capture Register					
10111	(0.05)	TCNT3H					unter Register Hig					
	700 020	TCNT3L			Im	er/Counter3 - Co	unter Register Lo	w Byte				
TCNT	(0x93) (0x92) (6x91)	TCCR3C	FOC3A		-				- :			
	(dk91)	TCCR3B	ICNC3	ICES3	-	WGM33	WGM32	CS32	CS31	CS30		
	(0x90)	TCCR3A	COM3A1	COM3A0	COM3B1	COM3B0	COM3C1	COM3C0	WGM31	WGM30		
	(0x8F)	Reserved	-	-	-	-	-	-	-	-		
	(0x8E)	Reserved	-	-	-	-	-	-	-	-		
	(0x8D) (0x8C)	OCR1CH OCR1CL					ompare Register					
	(0x8B)	OCR1BH					Compare Register Compare Register					
	(0x8A)	OCR1BL					Compare Register					
	(0x89)	OCR1AH					ompare Register					
	(0x88)	OCR1AL					Compare Register					
	(0x87)	ICR1H					Capture Register					
TCNT	(0.86)	TCNT1H					Capture Register					
T CIVI.	(00B5)	TCNT1H TCNT1L					unter Register Hig unter Register Lo					
	11(83)	TONTIL			- IIII	CO	- negisier Lo					
maxm'	(0x83) (0x82)	TCCR1C	FOC1A	FOC1B	FOC1C					-		
TCNT	(@x81)	TCCR1B	ICNC1	ICES1	-	WGM13	WGM12	CS12	CS11	CS10		
	(UXOU)	TCCR1A	COM1A1	COM1A0	COM1B1	COM1B0	COM1C1	COM1C0	WGM11	WGM10		
	(0x7F)	DIDR1	- 40070		- ADOSD		-			AIN0D		
	(0x7E) (0x7D)	DIDR0 DIDR2	ADC7D	ADC6D	ADC5D ADC13D	ADC4D ADC12D	ADC11D	ADC10D	ADC1D ADC9D	ADC0D ADC8D		
	(0.7.5)	DIDITE			700100	ADOLED	ADOTED	ADOIDD	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	ADOUD		

Atmel

7766GS-AVR-02/2014

Address	Name	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Page
0x1B (0x3B)	PCIFR			-	-	-	-	-	PCIF0	
0x1A (0x3A)	Reserved	-	-	-	-	-	-	-	-	
0x19 (0x39)	TIFR4	OCF4D	OCF4A	OCF4B	-	-	TOV4	-	-	
0x18 (0x38)	TIFR3	-		ICF3	-	OCF3C	OCF3B	OCF3A	TOV3	
0x17 (0x37)	Reserved	-	-	-	-	-	-	-	-	
0x16 (0x36)	TIFR1	-		ICF1	-	OCF1C	OCF1B	OCF1A	TOV1	
0x15 (0x35)	TIFR0	-		-	-	-	OCF0B	OCF0A	TOV0	
0x14 (0x34)	Reserved	-	-	-	-	-	-	-	-	
0x13 (0x33)	Reserved		-	-	-	-	-	-	-	
0x12 (0x32)	Reserved	-	-	-	-	-	-	-	-	
0x11 (0x31)	PORTF	PORTF7	PORTF6	PORTF5	PORTF4	-	-	PORTF1	PORTF0	
0x10 (0x30)	DDRF	DDF7	DDF6	DDF5	DDF4	-	-	DDF1	DDF0	
0x0F (0x2F)	PINF	PINF7	PINF6	PINF5	PINF4	-	-	PINF1	PINF0	
0x0E (0x2E)	PORTE	-	PORTE6	-	-	-	PORTE2	-	-	
0x0D (0x2D)	DDRE	-	DDE6	-	-	-	DDE2	-	-	
0x0C (0x2C)			DINES				DINEO			ı
	PORTD	PORTD7	PORTD6	PORTD5	PORTD4	PORTD3	PORTD2	PORTD1	PORTD0	
0x0A (0x2A)	DDRD	DDD7	DDD6	DDD5	DDD4	DDD3	DDD2	DDD1	DDD0	
0x09 (0x29)		PIND7	PINDO	PINDS	PIND4	PINDS	PIND2	PINDI	PINDO	
0x08 (0x28)	PORTC	PORTC7	PORTC6	-	-	-	-	-	-	
0x07 (0x27)	DDRC	DDC7	DDC6	-	-	-	-	-	-	
0x06 (0x26)	PINC	PINC7	PINC6	-	-	-	-	-	-	
0x05 (0x25)	PORTB	PORTB7	PORTB6	PORTB5	PORTB4	PORTB3	PORTB2	PORTB1	PORTB0	
0x04 (0x24)	DDRB	DDB7	DDB6	DDB5	DDB4	DDB3	DDB2	DDB1	DDB0	
0x03 (0x23)	PINB	PINB7	PINB6	PINB5	PINB4	PINB3	PINB2	PINB1	PINB0	
0x02 (0x22)	Reserved	-	-	-	-	-	-	-	-	
0x01 (0x21)	Reserved	-	-	-	-	-	-	-	-	
0x00 (0x20)	Reserved				-	-	-	-	-	

- Note: 1. For compatibility with future devices, reserved bits should be written to zero if accessed. Reserved I/O memory addresses
 - 2. I/O registers within the address range \$00 \$1F are directly bit-accessible using the SBI and CBI instructions. In these reqisters, the value of single bits can be checked by using the SBIS and SBIC instructions.
 - 3. Some of the status flags are cleared by writing a logical one to them. Note that the CBI and SBI instructions will operate on all bits in the I/O register, writing a one back into any flag read as set, thus clearing the flag. The CBI and SBI instructions work with registers 0x00 to 0x1F only.
 - 4. When using the I/O specific commands IN and OUT, the I/O addresses \$00 \$3F must be used. When addressing I/O registers as data space using LD and ST instructions, \$20 must be added to these addresses. The ATmega16U4/ATmega32U4 is a complex microcontroller with more peripheral units than can be supported within the 64 location reserved in Opcode for the IN and OUT instructions. For the Extended I/O space from \$60 - \$1FF in SRAM, only the ST/STS/STD and LD/LDS/LDD instructions can be used.

∕ltmel

ATmega32 Registers 2 out of 4 pages

(on Canvas/Files/Resources/Teensy Files)

MEAM.Design: The Teensy 2.0

GENERAL

Hall of Fame

COURSES

MEAM 101

MEAM 201

MEAM 510

MEAM 520

IPD 501

ESAP

GUIDES

Laser Cutting

3D Printing

Machining

ProtoTRAK

Tap Chart PUMA 260

MAEVARM

IVI/ (L V/ (I V

Teensy

PHANToM

BeagleBoard

Phidget

S62

Materials

The Teensy 2.0 from PJRC.COM (Paul J Stoffregen and Robin C Coon) is an 8bit MCU built around the ATmega32U4 processor. It includes a clock speed of 16 MHz with 32K of programmable flash, 1K of EEPROM, 2.5K of SRAM, 25 GPIO lines, 32 working registers, four timer/counters, one high-speed timer, 12 channels of 10-bit ADC, and a variety of communication protocols, including USART, I2C, SPI, JTAG, and USB. The module is programmed via a USB cable with no intervening hardware, and all development tools are freely-available online.

General Information

How to Obtain an Teensy

Board Pinout & Functionality

Getting Started #1: Plug in USB (PCJR.com)

Getting Started #2: Download Loading software (PCJR.com)

Getting Started #3: C Compiler (PCJR.com)

Programming Reference


System Clocks

I/O Ports (GPIO)

Timers/Counters

http://medesign.seas.upenn.edu/

Analog-to-Digital Conversion



Login Register

MEAM.Design - ATmega32 Programming - Timers/Counters Hall of Fame

The ATmega32U4 contains 4 different timers: Timer 0 (8-bit, dual output compare); Timer 1 (16-bit, triple output compare, single input capture); Timer 3 (16-bit, single output compare, single input capture); and Timer 4 (10-bit high speed, triple output compare). The timer channels are all multiplexed with GPIO pins, and can be found at the following locations:

COURSES

MEAM 201

ESAP

GUIDES

Laser Cutting

3D Printing Machining

ProtoTRAK

Tap Chart

PUMA 260

MAEVARM

Teensy **PHANTOM**

GENERAL

Laboratories

MEAM 101 Timer 0

Configuration Details

MEAM 510

MEAM 520 OC0A B7 IPD 501

output compare, timer 0, channel A OC0B D0 output compare, timer 0, channel B

Timer 1

Configuration Details

B5 OC1A output compare, timer 1, channel A OC1B output compare, timer 1, channel B OC1C B7 output compare, timer 1, channel C

IPC1

Timer 3

BeagleBoard

Phidget Configuration Details S62

Materials OC3A output compare, timer 3, channel A

D4 input capture, timer 1

Summary of ATMega documentation (has 431 pages!)

Atmel-7766-8-bit-AVR-ATmegal6U4-32U4 Datasheet.pdf available on canvas:

Files > Resources > Teensy Files >

Login Register

GENERAL Hall of Fame

Laboratories

COURSES **MEAM 101 MEAM 201 MEAM 510 MEAM 520** IPD 501 **ESAP**

MEAM.Design - ATmega32 Programming - Timers/Counters - Timer 0 Configuration Details

Timer 0 is an 8-bit free-running timer with two independent output compare units and PWM support. The output compare pins are OC0A and OC0B, which are multiplexed to B7 and D0.

Important Registers

TCNT0	timer/counter 0 value
TCCR0A	timer/counter 0 control register A
TCCR0B	timer/counter 0 control register B
OCR0A	timer/counter 0 output compare register A
OCR0B	timer/counter 0 output compare register B
TIFR0	timer/counter 0 interrupt flags

GUIDES

Laser Cutting

Clock Source - The default clock source for Timer 0 is the system clock. You can set the prescaler by modifying CS00, CS01, and CS02 in TCCR0B:

Timer Modes (Waveform Generation) - The timer can operate in one of six modes, as set by the WGM00, WGM01, and WGM02 bits spread across TCCR0A and

3D Printing				
Machining	TCCR0B:	TCCR0B:	TCCR0B:	
0	CS02	CS01	CS00	
ProtoTRAK	0	0	0	OFF
Tap Chart	0	0	1	/1
PUMA 260	0	1	0	/8
MAEVARM				
	0	1	1	/64
Teensy	1	0	0	/256
PHANToM	1	0	1	/1024


BeagleBoard

Phidget

S62

Materials

TCCR0B. The mode controls how the timer will count (either UP or UP/DOWN), what the maximum value will be (either 0xFF or whatever is in OCR0A), and whether to drive the output compare pin(s). Once the maximum value is reached, the timer will either reset to 0x00 and continue counting (UP modes), or will



Clock Source

Bit

• Q4 What value should be written to TCCR3B to change it from the initialized value to set the prescaler to /1

e e e e e e e e e e e e e e e e e e e					
Register name	→ TCCR3B:	TCCR3B:	TCCR3B:	Prescaler	Clock Source Frequency
Bit name	→ CS32	CS31	CS30		
BII Horra	0	0	0	OFF	Source Off
	0	0	1	/1	16Mhz
	0	1	0	/8	2Mhz
	0	1	1	/64	250khz
	1	0	0	/256	62.5khz
	1	0	1	/1024	15.625khz


	ICNC3	ICES3	_	WGM33	WGM32	CS32	CS31	CS30	TCCR3B
Read/Write	R/W	R/W	R	R/W	R/W	R/W	R/W	R/W	
Initial Value	0	0	0	0	0	0	0	0	

Timer example

Note: this code won't work as is

```
GND
#include "teensy general.h"
                                                                PB<sub>0</sub>
#define COMPAREVALUE 40000
                                                                PB1
                                                                PB<sub>2</sub>
int main()
                                                                PB3
                                                                PB7
 DDRC = 0x40; //Port C6 as output
                                                                PD0
  TCCR3B = 0x01; // Turn on counter (no prescale)
                                                                PD1
  for (;;) {
                                                                PD2
    if (TCNT3 > COMPAREVALUE) {
                                                                PD3
      toggle(PORTC, 6);
                                                                PC6
      TCNT3 = 0; // Reset the timer to 0
  return 0;
```

Waveform




Acronyms

- DDRx = Data Direction Register for Port x
 - Ex: DDRD = data direction register for port D
- CPU = Central Processing Unit
- SRAM = Static Random Access Memory
- IO = Input / Output
- GPIO = General Purpose Input/Output


Register names – don't really need to memorize

- TCNT \mathbf{x} Timer Counter \mathbf{x} [0,1,3,4]
- TCCRxy Timer Counter Control Register y [A,B] for timer x
- OCRxy Output Compare Register for timer x Channel y



Timer/Counter 0 Output Compare

"Free running" 8-bit counter




Output Compare Register (e.g. like OCR3A)


Timer 3 Output Compare

- Output Compare Register OCR3A
 - Actually 2 Byte OCR3AH, OCR3AL handled through unsigned short int OCR3A
- Output Compare (Timer 3 channel A)

TCCR3A:	TCCR3A:	
COM3A1	COM3A0	
0	0	no change
0	1	toggle
1	0	clear
1	1	set



Waveform




• Q5 fill in the ???? to use the timer to toggle port C6

return 0;

```
#include "teensy general.h"
                                                           GND
#define COMPAREVALUE 40000
                                                         SS PB0
                                                        SCLK PB1
int main()
                                                        MOSI PB2
                                                        MISO PB3
 DDRC =0x40; //Port C6 as output
  TCCR3B = 0x01; // Turn on counter (no prescale) COA PB7
  ?????? // Register set pin PC6 to toggle on match
                                                        INTO PDO
  ???
                                                        INT1 PD1
                                                        INT2 PD2
  for(;;) {
                                                        INT3 PD3
    if (TCNT3 > COMPAREVALUE) {
                                                      OC3A PC6
         togglo(PORTC, 6),
                                                        ICP3 PC7
          TCNT3 = 0; // Reset the timer to 0
```

Note: this code won't work as is For 20 Hz Lab 1.3



Waveform Generator Modes

TCCR3B:	CCR3B: TCCR3B: TCCR3A: TCC		TCCR3A:	Function			
WGM33	WGM32	WGM31	WGM30				
Normal: Timer UP to a value reset to 0x0000:							
0	0	0	0	(mode 0) UP to 0xFFFF (16-bit)			
0	1	0	0	(mode 4) UP to OCR3A			
1	1	0	0	(mode 12) UP to ICR3			
Single-Slope: Timer UP to a value, reset to 0x0000 (set/reset PWM):							
0 1 0 1 (mode 5) UP to 0x00FF (8-bit), PWM mode							
0	1	1	1	(mode 7) UP to 0x03FF (10-bit), PWM mode			
1 1 1 0 (mode 14) UP to ICR3, PWM mode				(mode 14) UP to ICR3, PWM mode			
Dual-Slope: Timer LIP to a value DOWN to 0x0000 (set/reset PWM):							


Bit 7 6 5 4 3 2 1 0

| ICNC3 | ICES3 | - | WGM33 | WGM32 | CS32 | CS31 | CS30 | TCCR3B |
| Read/Write | R/W | R/W

 Read/Write
 R/W
 R/W


• Q6 fill in the ????? so the timer resets when TCNT3 = OCR3A

```
#include "teensy general.h"
#define COMPAREVALUE 40000
                                                            GND
                                                          SS PB0
int main()
                                                        SCLK PB1
                                                        MOSI PB2
    DDRC =0x40; //Port C6 as output
                                                        MISO PB3
    TCCR3A = 0x40; // set pin PC6 to toggle on match
                                                        COA PB7
    ?????; // reset Timer at OCR3A
                                                        INTO PDO
    OCR3A = COMPAREVALUE;
                                                        INT1 PD1
    for(;;) {
          if (TCNT3 > COMPAREVALUE) {
                                                        INT2 PD2
          toggle(POPTC, 6);
                                                        INT3 PD3
         TCNT3 = 0; // Reset the timer to 0
                                                      OC3A PC6
                                                        ICP3 PC7
  return 0;
```



Note: this code won't work as is For 20 Hz Lab 1.3


```
#include "teensy general.h"
#define COMPAREVALUE 40000
int main()
    DDRC =0x40: //Port C6 as output
   set(TCCR3A,COM3A0); // set PC6 to toggle
   set(TCCR3B,WGM32); // Reset timer on OCR3A
   set(TCCR3B,CS30); // Turn on clock source
    OCR3A = COMPAREVALUE;
                Preferred way to change bits in
   while(1);
                registers as it's easier to
    return 0;
                 understand
```



Note: this code won't work as is For 20 Hz Lab 1.3

Timer/Counter 0


"Free running" 8-bit counter



Low Byte TCNT0

Timer/Counter 1, 3


"Free running" 16-bit counter



High Byte TCNT1H TCNT3H Low Byte TCNT1L TCNT3L

Timer/Counter 4


"Free running" 10-bit counter



What if we used Timer0 (8bit) instead of Timer3 (16bit)?

```
#include "teensy general.h"
#define COMPAREVALUE 40000
int main()
   DDRC =0x40; //Port C6 as output
   set(TCCR3A,COM3A0); // set PC6 to toggle
   set(TCCR3B,WGM32); // Reset timer on OCR3A
   set(TCCR3B,CS30); // Turn on clock source
   OCR3A = COMPAREVALUE;
                         Change registers from TCCR3A/B to
                         TCCR0A/B and associated bits
   while(1);
                         Change pin and DDRx from PC6 to PB7
   return 0;
```

Teensy 2.0 Pinout (reminder)



Summary

- set(register, bit) to put l at bit# in register
- clear (register, bit) to put 0 at bit# in register
- Most registers start with 0's in all bits at reset.
- Timer subsystems run in parallel with main code.
- Look at medesign.upenn.edu for register summaries.
- Our Teensy boards ATmega32u4's run at 16Mhz

Answer in CHAT

Answer how you feel about each topic below with:

- 1. I don't understand this topic at all
- 2. I don't know now, but know what to do to get by
- 3. I understand some, but expect to get the rest later
- 4. I understand completely already

- A. Bitwise operators and C
- **B. Registers** and Memory Maps
- C. Programming **Timers** on atmega32
- D. Add any other comments