up: Chapter 9 -- Exceptions and Interrupts

prev: 9.9 Exception Summary
next: Chapter 10 -- Initialization

9.10 Error Code Summary

Table 9-7 summarizes the error information that is available with each exception.

Table 9-7. Error-Code Summary

Description Number	Interrupt	Error Code
Divide error	Θ	No
Debug exceptions	1	No
Breakpoint	3	No
Overflow	4	No
Bounds check	5	No
Invalid opcode	6	No
Coprocessor not available	7	No
System error	8	Yes (always 0)
Coprocessor Segment Overrun	9	No
Invalid TSS	10	Yes
Segment not present	11	Yes
Stack exception	12	Yes
General protection fault	13	Yes
Page fault	14	Yes
Coprocessor error	16	No
Two-byte SW interrupt	0-255	No

up: Chapter 9 -- Exceptions and Interrupts

prev: 9.9 Exception Summary next: Chapter 10 -- Initialization