



EL2520

Control Theory and Practice

Signal Norms and System Gain

The Small Gain Theorem


Elling W. Jacobsen

Div of Decision and Control Systems

School of Electrical Engineering and Computer Science

KTH


Multivariable feedback control



Multi-Input-Multi-Output (MIMO):

- all signals are vectors, all transfer-functions are matrices
- need scalar measures of signal size and system amplification

Systems as "mapping of signals"




Key components:

- Signal norm: quantifies "size" of signals
- System gain: quantifies system's (maximum) amplification
- Admits natural extensions from scalar to multivariable systems
 - frequency domain analysis and design for MIMO systems
- Enables analysis of fundamental performance limitations
- Enables analysis of robustness

Vector norms

Vector (spatial) norms measure the “size” of vectors.

- common choice: Euclidian norm (also known as 2-norm)




$$|z|^2 = \sum_i z_i^2 = z^T z$$

Signal norms

Signals are functions of time (or frequency)

- signal norms measure size across both space and time.



summing up over channels

summing up over time

Signal norms

The *peak-norm*, or L_∞ -norm, of a signal is defined as

$$\|z\|_\infty = \sup_{t \geq 0} |z(t)|$$

A signal is *bounded* if its peak-norm is bounded ($\|z\|_\infty < \infty$)

The *energy-norm*, or L_2 -norm, of a signal is defined as


$$\|z\|_2 = \sqrt{\int_{-\infty}^{\infty} |z(t)|^2 dt}$$

A signal is *finite-energy* if $\|z\|_2 < \infty$

Note: - bounded signals may have infinite energy (and vice versa)
- we will only work with the 2-norm in this course

The energy-gain of a system

Measures maximum “energy amplification” of system



The amplification for a specific signal $u \neq 0$ is given by

$$\frac{\|y\|_2}{\|u\|_2} = \frac{\|\mathcal{S}u\|_2}{\|u\|_2}$$

The system gain is the maximum amplification (over all finite-energy signals)

$$\|\mathcal{S}\| = \sup_{0 < \|u\|_2 < \infty} \frac{\|\mathcal{S}u\|_2}{\|u\|_2}$$

Energy gain of scalar linear systems

Stable scalar linear time-invariant system $\mathcal{S} : Y(s) = G(s)U(s)$

Assume that $|G(i\omega)| \leq K$ with equality for $\omega = \omega^*$


Then, Parseval's theorem yields

$$\begin{aligned}\|y\|_2^2 &= \frac{1}{2\pi} \int_{-\infty}^{\infty} |Y(i\omega)|^2 d\omega = \\ &= \frac{1}{2\pi} \int_{-\infty}^{\infty} |G(i\omega)|^2 |U(i\omega)|^2 d\omega \leq K^2 \|u\|_2^2\end{aligned}$$

Since equality holds for $u(t) = \sin(\omega^* t)$, we have


$$\|\mathcal{S}\| = \sup_{\omega} |G(i\omega)| = \|G\|_{\infty}$$

The energy-gain of scalar linear system is the \mathcal{H}_{∞} -norm of the transfer-function G



Quiz 1: energy gains and Bode diagrams

Quiz: the Bode amplitude diagrams below represent two different linear time-invariant systems. Which one has the largest energy-gain?



Quiz 2: H_infinity norm

- Determine the \mathcal{H}_∞ - norm of the systems

$$G_1(s) = \frac{2}{2s+1}$$

$$G_2(s) = \frac{2s}{s+1}$$


Example: gain of nonlinear system

Static nonlinear system $\mathcal{S} : y(t) = f(u(t))$

where

$$|f(x)| \leq K|x|$$

with equality for $x = x^*$



Since

$$\|y\|_2^2 = \int_{-\infty}^{\infty} |f(u(t))|^2 dt \leq \int_{-\infty}^{\infty} K^2 |u(t)|^2 dt = K^2 \|u\|_2^2$$

the energy gain is

$$\|\mathcal{S}\| = \sup_u \frac{\|y\|_2}{\|u\|_2} = K$$

Example: gain of static linear systems

Consider the static linear system $y = Au$ with gain

$$\|A\| = \sup_{u \neq 0} \frac{|Au|}{|u|}$$

Since

$$\|A\|_2^2 = \sup_{u \neq 0} \frac{|Au|^2}{|u|^2} = \sup_{u \neq 0} \frac{u^T A^T A u}{u^T u} = \lambda_{\max}(A^T A)$$

Thus, the gain is the square root of the maximum eigenvalue of $A^T A$.

- The square roots of $\text{eig}(A^T A)$ are called the *singular values* of A ; more about this in Video 5

Quiz: a flavour of multivariable systems

Quiz: What is the gain of the following (static) systems?

a) $y = \begin{bmatrix} 0 & 1 \\ 0 & 0 \end{bmatrix} u$

b) $y = \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix} u$


What are the corresponding “worst-case” input vectors?
(vectors u with $|u|=1$ that give the maximum value of $|y|$)

Input-output stability

Definition. A system \mathcal{S} is *input-output stable* if $\|\mathcal{S}\| < \infty$

The Small Gain Theorem

Theorem. Consider the interconnection



If S_1 and S_2 are input-output stable and the loop gain

$$\|S_1\| \cdot \|S_2\| < 1$$

Then, the closed-loop system with r_1, r_2 as inputs and e_1, e_2, y_1, y_2 as outputs is input-output stable.

Proof sketch

$$e_1 = r_1 + \mathcal{S}_2(r_2 + y_1)$$

$$y_1 = \mathcal{S}_1 e_1$$

$$\|e_1\| \leq \|r_1\| + \|\mathcal{S}_2\|(\|r_2\| + \|\mathcal{S}_1\| \cdot \|e_1\|)$$

$$\|e_1\| \leq \frac{\|r_1\| + \|\mathcal{S}_2\| \cdot \|r_2\|}{1 - \|\mathcal{S}_2\| \cdot \|\mathcal{S}_1\|}$$

Hence, the gain from r_1, r_2 to e_1 is finite.


A similar argument proves that the gain from r_1, r_2 to e_2 is finite

We will present a rigorous proof later in the course (based on Nyquist)

Note: for linear system, it is sufficient that $\|\mathcal{S}_1 \mathcal{S}_2\| \leq 1$

Quiz: a nonlinear interconnection

Is the feedback interconnection



with $G(s) = \frac{0.4}{s + 1}$ and $|f(y)| \leq 2|y|$ input-output stable?

Summary

- Systems as mappings of signals
- Norm
 - vector norms: measure size of vector “across channels”
 - signal norms: measure size of signal across time and space
- Gain
 - the maximum amplification of bounded energy signals
 - for stable linear systems, gain is the infinity norm of G
- Input-output stability and the small gain theorem