



SAKERPLUS

CORDLESS LEAF BLOWER


BF170

BF171

BF172


BF173

BF174



To reduce the risk of injury, the user must read and understand the Operator's Manual before using this product. Save these instructions for future reference.

PRODUCT OVERVIEW AND USAGE



1. Start the turbo fan

Press the power button to start blowing, release the power button to stop

2. Charging

The product is suitable for both docking and line charging, and supports fast charging chargers.

SPECIFICATIONS

NAME	Cordless Leaf Blower
MODEL	BF170/BF171/BF172/BF173/BF174
BATTERY CAPACITY	21V 3000mAh
RATED POWER	350W
WIND PRESSURE	21oz/600g
WIND SPEED	76MPH
AIR VOLUME	260CFM
WEIGHT	35oz/1000g


MAINTENANCE

1. Please keep this product out of reach of children and pets.
2. Please store in a dry environment . Do not place this product in a high temperature or in a car for exposure .
3. Do not overcharge or over discharge the battery, otherwise it will damage the battery .
4. Please regularly remove the attachments from the air outlet and air intake .
5. Do not press or rub the air intake and air outlet with your fingernails or sharp objects to avoid damaging the product .
6. Do not use alcohol, nail polish remover or detergent to clean this product, otherwise it may cause malfunction, cracking or fading.

PRECAUTIONS

To reduce the risk of malfunction, electric shock, injury, fire, death, and damage to equipment or property, be sure to follow the safety precautions below.

A. Charging



The indicator light on the charger turns red when charging and turns green when fully charged.

Do not damage, modify, forcibly bend, pull, twist the charging cable, place heavy objects on it, or squeeze the charging cable while charging. If the charging cable is damaged, be sure to replace it to avoid danger.

B. Use and Storage

1. Do not block or insert foreign objects into the air intake and air outlet during operation, otherwise the product will be damaged .
2. Do not immerse this product in water.
3. Do not use this product in a humid environment. Please keep this product dry.
4. Do not use it with wet hands .
5. Do not use it near LPG or other flammables (such as volatile agents, paint thinners, sprays, etc.), otherwise it may cause an explosion or a fire due to a short circuit.
6. Do not leave the product with the power on, otherwise it may cause a fire due to a short circuit.
7. Do not store in highly humid places.
8. Do not store within the reach of children and infants.
9. Do not use this product near a bathtub, shower, wash basin or other equipment filled with water .
10. Do not place the air inlet close to your hair to prevent your hair from being sucked into the fan .

C. If an abnormality or failure occurs

If an abnormality or malfunction occurs, such as no air flow, frequent stops, redness inside, or smoke coming out , please stop using the product immediately. Using this product in this situation may cause injury or cause a fire due to a short circuit.

Tips: The illustrations of products, accessories, etc. in the manual are schematic diagrams and are for reference only. Due to product updates and upgrades, the actual product may differ slightly from the schematic diagram. Please refer to the actual product.



CORDLESS LEAF BLOWER

BF170/BF171/BF172/BF173/BF174



SATISFACTION GUARANTEED

We are confident in the quality of the product. In the process of daily use, if the product has quality problems or have any questions about the product, please feel free to contact us, we are always there. Made in China



CONTACT US AT: cs@sakerplus.com