注意事项:

1、如果不记得设备修改后的密码了,进不去设备,系统重启时,按住 Ctrl+B,按照如下步骤重置密码

```
bootloader creation Data : Dec 6 2017, 15:59:
Initializing I2C Bus:OK
Initializing SPI Bus:OK
Initializing EEPROM:OK
CPLD userspace init ok
cpld init done
Pres Ctrl+B o break auto startup ... 3
Enter Password:*********
Default Password,Please Set New Password.
       BootLoader Menu
   1. Default Startup
   2. Serial Menu
   3. Network Menu
   4. Startup Select
   5. File Manager
   6. Reboot

    Password Manager

Enter your choice(1-7):7
       PassWord Manager
   1. Modify the menu password
  2. Clear the console login password 0. Return
Enter your choice(0-2):2
Clear the console login password Succeed!
        PassWord Manager
   1. Modify the menu password
   2. Clear the console login password
   0. Return
Enter your choice(0-2):
```

重置过程中的密码为:

交换机、AP: Admin@huawei.com

路由器: Admin@huawei