



# SDOF linear oscillator

## *Response to Harmonic Loading*

Giacomo Boffi

<http://www.stru.polimi.it/home/boffi/>  
boffi@stru.polimi.it

Dipartimento di Ingegneria Strutturale, Politecnico di Milano



# Undamped Oscillator



# The Equation of Motion

The *SDOF* equation of motion for a harmonic loading is:

$$m \ddot{x} + k x = p_0 \sin \omega t.$$



# The Equation of Motion

The *SDOF* equation of motion for a harmonic loading is:

$$m \ddot{x} + k x = p_0 \sin \omega t.$$

We seek a particular solution to this equation, in terms of a harmonic function with the same circular frequency,  $\omega$ ,

$$\xi(t) = C \sin \omega t, \quad \ddot{\xi}(t) = -\omega^2 C \sin \omega t.$$



# The Equation of Motion

The *SDOF* equation of motion for a harmonic loading is:

$$m \ddot{x} + k x = p_0 \sin \omega t.$$

We seek a particular solution to this equation, in terms of a harmonic function with the same circular frequency,  $\omega$ ,

$$\xi(t) = C \sin \omega t, \quad \ddot{\xi}(t) = -\omega^2 C \sin \omega t.$$

Substituting  $x$  with  $\xi$  and simplifying, we get

$$C(k - \omega^2 m) = p_0.$$



# The Particular Solution

Starting from our last equation,

$$C(k - \omega^2 m) = p_0,$$

solving for  $C$  we get  $C = \frac{p_0}{k - \omega^2 m}$



# The Particular Solution

Starting from our last equation,

$$C(k - \omega^2 m) = p_0,$$

solving for  $C$  we get  $C = \frac{p_0}{k - \omega^2 m}$

- collecting  $k$  in the right member divisor:  $C = \frac{p_0}{k} \frac{1}{1 - \omega^2 \frac{m}{k}}$



# The Particular Solution

Starting from our last equation,

$$C(k - \omega^2 m) = p_0,$$

solving for  $C$  we get  $C = \frac{p_0}{k - \omega^2 m}$

- collecting  $k$  in the right member divisor:  $C = \frac{p_0}{k} \frac{1}{1 - \omega^2 \frac{m}{k}}$
- but  $k/m = \omega_n^2$ , so that, with  $\beta = \omega/\omega_n$ , we get:  $C = \frac{p_0}{k} \frac{1}{1 - \beta^2}$ .



# The Particular Solution

Starting from our last equation,

$$C(k - \omega^2 m) = p_0,$$

solving for  $C$  we get  $C = \frac{p_0}{k - \omega^2 m}$

- collecting  $k$  in the right member divisor:  $C = \frac{p_0}{k} \frac{1}{1 - \omega^2 \frac{m}{k}}$
- but  $k/m = \omega_n^2$ , so that, with  $\beta = \omega/\omega_n$ , we get:  $C = \frac{p_0}{k} \frac{1}{1 - \beta^2}$ .

We can now write the particular solution, with the dependencies on  $\beta$  singled out in the second term:

$$\xi(t) = \frac{p_0}{k} \frac{1}{1 - \beta^2} \sin \omega t.$$



# Response Ratio

Denoting with  $\Delta_{st}$  the static deformation,  $\Delta_{st} = p_0/k$ , we may write the particular solution in terms of  $\Delta_{st}$  and the *Response Ratio*,  $R(t; \beta)$ , whose amplitude depends *only* on the *frequency ratio*  $\beta = \frac{\omega}{\omega_n}$ ,

$$\xi(t) = \Delta_{st} R(t; \beta).$$



# Response Ratio

Denoting with  $\Delta_{st}$  the static deformation,  $\Delta_{st} = p_0/k$ , we may write the particular solution in terms of  $\Delta_{st}$  and the *Response Ratio*,  $R(t; \beta)$ , whose amplitude depends *only* on the *frequency ratio*  $\beta = \frac{\omega}{\omega_n}$ ,

$$\xi(t) = \Delta_{st} R(t; \beta).$$

It is then useful to introduce the *dynamic amplification factor*  $D(\beta)$ :

$$R(t; \beta) = \frac{1}{1 - \beta^2} \sin \omega t = D(\beta) \sin \omega t.$$


# Response Ratio

Denoting with  $\Delta_{st}$  the static deformation,  $\Delta_{st} = p_0/k$ , we may write the particular solution in terms of  $\Delta_{st}$  and the *Response Ratio*,  $R(t; \beta)$ , whose amplitude depends *only* on the *frequency ratio*  $\beta = \frac{\omega}{\omega_n}$ ,

$$\xi(t) = \Delta_{st} R(t; \beta).$$

It is then useful to introduce the *dynamic amplification factor*  $D(\beta)$ :

$$R(t; \beta) = \frac{1}{1 - \beta^2} \sin \omega t = D(\beta) \sin \omega t.$$



$D(\beta)$  is stationary and almost equal to 1 when  $\omega \ll \omega_n$  (this is a *quasi-static* behaviour), it grows out of bound when  $\beta \Rightarrow 1$  (*resonance*), it is negative for  $\beta > 1$  and goes to 0 when  $\omega \gg \omega_n$  (*high-frequency loading*).



# Response from Rest

We write  $x(t)$ ,  $x(0)$  and finally equate to 0:

$$x(t) = A \sin \omega_n t + B \cos \omega_n t + \Delta_{st} \frac{1}{1 - \omega^2/\omega_n^2} \sin \omega t,$$
$$x(0) = B = 0.$$



# Response from Rest

We write  $x(t)$ ,  $x(0)$  and finally equate to 0:

$$x(t) = A \sin \omega_n t + B \cos \omega_n t + \Delta_{st} \frac{1}{1 - \omega^2/\omega_n^2} \sin \omega t,$$
$$x(0) = B = 0.$$

We do as above for the velocity:

$$\dot{x}(t) = \omega_n A \cos \omega_n t - \omega_n B \sin \omega_n t + \Delta_{st} \frac{\omega}{1 - \omega^2/\omega_n^2} \cos \omega t,$$
$$\dot{x}(0) = \omega_n A + \Delta_{st} \frac{\omega}{1 - \omega^2/\omega_n^2} = 0.$$



# Response from Rest

We write  $x(t)$ ,  $x(0)$  and finally equate to 0:

$$x(t) = A \sin \omega_n t + B \cos \omega_n t + \Delta_{st} \frac{1}{1 - \omega^2/\omega_n^2} \sin \omega t,$$
$$x(0) = B = 0.$$

We do as above for the velocity:

$$\dot{x}(t) = \omega_n A \cos \omega_n t - \omega_n B \sin \omega_n t + \Delta_{st} \frac{\omega}{1 - \omega^2/\omega_n^2} \cos \omega t,$$
$$\dot{x}(0) = \omega_n A + \Delta_{st} \frac{\omega}{1 - \omega^2/\omega_n^2} = 0.$$

Solving for  $A$  and substituting, we have the response from rest:

$$x(t) = \Delta_{st} D(\beta) (\sin \omega t - \beta \sin \omega_n t).$$



# Resonant Response

We have seen that the response to harmonic loading with zero initial conditions is

$$x(t; \beta) = \Delta_{st} \frac{(\sin \omega t - \beta \sin \omega_n t)}{1 - \beta^2}.$$



# Resonant Response

We have seen that the response to harmonic loading with zero initial conditions is

$$x(t; \beta) = \Delta_{st} \frac{(\sin \omega t - \beta \sin \omega_n t)}{1 - \beta^2}.$$

To determine resonant response, we may take the limit for  $\beta \rightarrow 1$ :

$$\lim_{\beta \rightarrow 1} x(t; \beta) = \frac{\Delta_{st}}{2} (\sin \omega t - \omega t \cos \omega t).$$



# Resonant Response

We have seen that the response to harmonic loading with zero initial conditions is

$$x(t; \beta) = \Delta_{st} \frac{(\sin \omega t - \beta \sin \omega_n t)}{1 - \beta^2}.$$

To determine resonant response, we may take the limit for  $\beta \rightarrow 1$ :

$$\lim_{\beta \rightarrow 1} x(t; \beta) = \frac{\Delta_{st}}{2} (\sin \omega t - \omega t \cos \omega t).$$

As you can see, there is a term in quadrature with the loading, whose amplitude grows linearly and without bounds.



# Damped Oscillator



# The equation of motion

The *SDOF* equation of motion for a harmonic loading is:

$$m \ddot{x} + c \dot{x} + k x = p_0 \sin \omega t.$$



# The equation of motion

The SDOF equation of motion for a harmonic loading is:

$$m \ddot{x} + c \dot{x} + k x = p_0 \sin \omega t.$$

A particular solution to this equation is a harmonic function  $G \sin(\omega t - \theta)$  not in phase with input; it is however equivalent and convenient to write :

$$\begin{aligned}\xi(t) &= G_1 \sin \omega t + G_2 \cos \omega t, \\ \dot{\xi}(t) &= \omega (G_1 \cos \omega t - G_2 \sin \omega t), \\ \ddot{\xi}(t) &= -\omega^2 (G_1 \sin \omega t + G_2 \cos \omega t).\end{aligned}$$



# The equation of motion

The SDOF equation of motion for a harmonic loading is:

$$m \ddot{x} + c \dot{x} + k x = p_0 \sin \omega t.$$

A particular solution to this equation is a harmonic function  $G \sin(\omega t - \theta)$  not in phase with input; it is however equivalent and convenient to write :

$$\begin{aligned}\xi(t) &= G_1 \sin \omega t + G_2 \cos \omega t, \\ \dot{\xi}(t) &= \omega (G_1 \cos \omega t - G_2 \sin \omega t), \\ \ddot{\xi}(t) &= -\omega^2 (G_1 \sin \omega t + G_2 \cos \omega t).\end{aligned}$$

Substituting  $x$  with  $\xi$  and simplifying, we get

$$(G_2(\omega_n^2 - \omega^2) + 2G_1\omega\omega_n\zeta) \cos \omega t + (G_1(\omega_n^2 - \omega^2) - 2G_2\omega\omega_n\zeta - p_0/m) \sin \omega t = 0.$$



# The Particular Equation

Evaluating the previous equation for  $t = 0$  and  $t = \frac{\pi}{2\omega}$ , we get the following linear system in  $G_1$ ,  $G_2$ :

$$\begin{aligned} G_2(\omega_n^2 - \omega^2) + G_1 2\zeta \omega \omega_n &= 0, \\ G_1(\omega_n^2 - \omega^2) - G_2 2\zeta \omega \omega_n &= p_0/m. \end{aligned}$$



# The Particular Equation

Evaluating the previous equation for  $t = 0$  and  $t = \frac{\pi}{2\omega}$ , we get the following linear system in  $G_1$ ,  $G_2$ :

$$\begin{aligned} G_2(\omega_n^2 - \omega^2) + G_1 2\zeta \omega \omega_n &= 0, \\ G_1(\omega_n^2 - \omega^2) - G_2 2\zeta \omega \omega_n &= p_0/m. \end{aligned}$$

Solving and doing the usual substitutions for  $\Delta_{st}$  and  $\beta$ , we can write:

$$\xi(t) = \Delta_{st} \left( \frac{1 - \beta^2}{(2\beta\zeta)^2 + (1 - \beta^2)^2} \sin \omega t + \frac{-2\beta\zeta}{(2\beta\zeta)^2 + (1 - \beta^2)^2} \cos \omega t \right).$$



# The Particular Equation

Evaluating the previous equation for  $t = 0$  and  $t = \frac{\pi}{2\omega}$ , we get the following linear system in  $G_1$ ,  $G_2$ :

$$\begin{aligned} G_2(\omega_n^2 - \omega^2) + G_1 2\zeta \omega \omega_n &= 0, \\ G_1(\omega_n^2 - \omega^2) - G_2 2\zeta \omega \omega_n &= p_0/m. \end{aligned}$$

Solving and doing the usual substitutions for  $\Delta_{st}$  and  $\beta$ , we can write:

$$\xi(t) = \Delta_{st} \left( \frac{1 - \beta^2}{(2\beta\zeta)^2 + (1 - \beta^2)^2} \sin \omega t + \frac{-2\beta\zeta}{(2\beta\zeta)^2 + (1 - \beta^2)^2} \cos \omega t \right).$$

To write the *stationary response* in terms of a *dynamic amplification factor*, it is convenient to reintroduce the phase difference  $\theta$ :

$$\xi(t) = \Delta_{st} R(t; \beta, \zeta), \quad R = D(\beta, \zeta) \sin(\omega t - \theta).$$



# The angle of phase


Let's start analyzing the phase difference  $\theta(\beta, \zeta)$ . Its expression is:

$$\theta(\beta, \zeta) = \arctan \frac{2\zeta\beta}{1 - \beta^2}.$$

# The angle of phase

Let's start analyzing the phase difference  $\theta(\beta, \zeta)$ . Its expression is:


$$\theta(\beta, \zeta) = \arctan \frac{2\zeta\beta}{1 - \beta^2}.$$



# The angle of phase

Let's start analyzing the phase difference  $\theta(\beta, \zeta)$ . Its expression is:

$$\theta(\beta, \zeta) = \arctan \frac{2\zeta\beta}{1 - \beta^2}.$$



$\theta(\beta, \zeta)$  has a sharper variation around  $\beta = 1$  for decreasing values of  $\zeta$ , but it is apparent that, in the case of slightly damped structures, the response is approximately in phase for low frequencies of excitation, and in opposition for high frequencies. It is worth mentioning that for  $\beta = 1$  we have that the response is in perfect quadrature with the load: this is very important to detect resonant response in dynamic tests of structures.



# Dynamic Magnification Ratio


The dynamic magnification factor,  $D$ , is the amplitude of the stationary response normalized with respect to  $\Delta_{st}$ :

$$D(\beta, \zeta) = \frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}}$$

# Dynamic Magnification Ratio

The dynamic magnification factor,  $D$ , is the amplitude of the stationary response normalized with respect to  $\Delta_{st}$ :


$$D(\beta, \zeta) = \frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}}$$



# Dynamic Magnification Ratio

The dynamic magnification factor,  $D$ , is the amplitude of the stationary response normalized with respect to  $\Delta_{st}$ :

$$D(\beta, \zeta) = \frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}}$$




- $D(\beta, \zeta)$  has larger peak values for decreasing values of  $\zeta$ ,

# Dynamic Magnification Ratio

The dynamic magnification factor,  $D$ , is the amplitude of the stationary response normalized with respect to  $\Delta_{st}$ :

$$D(\beta, \zeta) = \frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}}$$




- $D(\beta, \zeta)$  has larger peak values for decreasing values of  $\zeta$ ,
- the approximate value of the peak, very good for a slightly damped structure, is  $1/2\zeta$ ,

# Dynamic Magnification Ratio

The dynamic magnification factor,  $D$ , is the amplitude of the stationary response normalized with respect to  $\Delta_{st}$ :

$$D(\beta, \zeta) = \frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}}$$




- $D(\beta, \zeta)$  has larger peak values for decreasing values of  $\zeta$ ,
- the approximate value of the peak, very good for a slightly damped structure, is  $1/2\zeta$ ,
- for larger damping, peaks move toward the origin, until for  $\zeta = \frac{1}{\sqrt{2}}$  the peak is in the origin,

# Dynamic Magnification Ratio

The dynamic magnification factor,  $D$ , is the amplitude of the stationary response normalized with respect to  $\Delta_{st}$ :

$$D(\beta, \zeta) = \frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}}$$



- $D(\beta, \zeta)$  has larger peak values for decreasing values of  $\zeta$ ,
- the approximate value of the peak, very good for a slightly damped structure, is  $1/2\zeta$ ,
- for larger damping, peaks move toward the origin, until for  $\zeta = \frac{1}{\sqrt{2}}$  the peak is in the origin,
- for dampings  $\zeta > \frac{1}{\sqrt{2}}$  we have no peaks.

# Dynamic Magnification Ratio (2)

The location of the response peak is given by the equation

$$\frac{d D(\beta, \zeta)}{d \beta} = 0,$$

that solved gives the root

$$\beta_0 = \sqrt{1 - 2\zeta^2}.$$

# Dynamic Magnification Ratio (2)

The location of the response peak is given by the equation

$$\frac{d D(\beta, \zeta)}{d \beta} = 0,$$

that solved gives the root

$$\beta_0 = \sqrt{1 - 2\zeta^2}.$$

As we are interested in non negative  $\beta$ , we are restricted to  $0 < \zeta \leq \frac{1}{\sqrt{2}}$ .

In this interval, substituting  $\beta_0$  in the expression of the response ratio, we have

$$D_{max} = \frac{1}{2\zeta} \frac{1}{\sqrt{1 - \zeta^2}}.$$

# Dynamic Magnification Ratio (2)

The location of the response peak is given by the equation

$$\frac{d D(\beta, \zeta)}{d \beta} = 0,$$

that solved gives the root

$$\beta_0 = \sqrt{1 - 2\zeta^2}.$$

As we are interested in non negative  $\beta$ , we are restricted to  $0 < \zeta \leq \frac{1}{\sqrt{2}}$ .

In this interval, substituting  $\beta_0$  in the expression of the response ratio, we have

$$D_{max} = \frac{1}{2\zeta} \frac{1}{\sqrt{1 - \zeta^2}}.$$

Note that, for a relatively large damping ratio,  $\zeta = 20\%$ , the error of  $1/2\zeta$  with respect to  $D_{max}$  is in order of 2%.



# Harmonic Exponential Loading

Consider:

$$\ddot{x} + 2\zeta\omega_n\dot{x} + \omega_n^2x = \frac{p_0}{m} \exp(i(\omega t - \phi))$$

in general the phase can be disregarded as we can represent its effects using a complex number factor ( $\exp(i(\omega t - \phi)) = \exp(i\phi) \exp(i\omega t)$ ).



# Harmonic Exponential Loading

Consider:

$$\ddot{x} + 2\zeta\omega_n\dot{x} + \omega_n^2x = \frac{p_0}{m} \exp(i(\omega t - \phi))$$

in general the phase can be disregarded as we can represent its effects using a complex number factor ( $\exp(i(\omega t - \phi)) = \exp(i\phi) \exp(i\omega t)$ ). The particular solution, and its derivatives, are

$$\xi = G \exp(i\omega t), \quad \dot{\xi} = i\omega G \exp(i\omega t), \quad \ddot{\xi} = -\omega^2 G \exp(i\omega t),$$

where  $G$  is a complex constant.



# Harmonic Exponential Loading

Consider:

$$\ddot{x} + 2\zeta\omega_n\dot{x} + \omega_n^2x = \frac{p_0}{m} \exp(i(\omega t - \phi))$$

in general the phase can be disregarded as we can represent its effects using a complex number factor ( $\exp(i(\omega t - \phi)) = \exp(i\phi) \exp(i\omega t)$ ). The particular solution, and its derivatives, are

$$\xi = G \exp(i\omega t), \quad \dot{\xi} = i\omega G \exp(i\omega t), \quad \ddot{\xi} = -\omega^2 G \exp(i\omega t),$$


where  $G$  is a complex constant. Substituting, removing the dependency on  $\exp(i\omega t)$  and solving for  $G$  yields

$$G = \Delta_{st} \left[ \frac{1}{(1 - \beta^2) + i(2\zeta\beta)} \right] = \Delta_{st} \left[ \frac{(1 - \beta^2) - i(2\zeta\beta)}{(1 - \beta^2)^2 + (2\zeta\beta)^2} \right].$$

# Response in the complex plane

The stationary response is

$$\xi(t) = \Delta_{st} \frac{(1 - \beta^2) - i(2\zeta\beta)}{(1 - \beta^2)^2 + (2\zeta\beta)^2} \exp(i\omega t)$$




# Response in the complex plane

The *stationary response* is

$$\xi(t) = \Delta_{st} \frac{(1 - \beta^2) - i(2\zeta\beta)}{(1 - \beta^2)^2 + (2\zeta\beta)^2} \exp(i\omega t)$$

- we plot  $G$  in the complex plane,




# Response in the complex plane

The *stationary response* is

$$\xi(t) = \Delta_{st} \frac{(1 - \beta^2) - i(2\zeta\beta)}{(1 - \beta^2)^2 + (2\zeta\beta)^2} \exp(i\omega t)$$

- we plot  $G$  in the complex plane,
- we multiply  $G$  by  $\exp(i\omega t)$ , that is equivalent to rotate  $G$  by the angle  $\omega t$ ,




# Response in the complex plane

The *stationary response* is

$$\xi(t) = \Delta_{st} \frac{(1 - \beta^2) - i(2\zeta\beta)}{(1 - \beta^2)^2 + (2\zeta\beta)^2} \exp(i\omega t)$$

- we plot  $G$  in the complex plane,
- we multiply  $G$  by  $\exp(i\omega t)$ , that is equivalent to rotate  $G$  by the angle  $\omega t$ ,
- projecting the resulting vector on the axes, we have the real and imaginary part of the response,




# Response in the complex plane

The *stationary response* is

$$\xi(t) = \Delta_{st} \frac{(1 - \beta^2) - i(2\zeta\beta)}{(1 - \beta^2)^2 + (2\zeta\beta)^2} \exp(i\omega t)$$

- we plot  $G$  in the complex plane,
- we multiply  $G$  by  $\exp(i\omega t)$ , that is equivalent to rotate  $G$  by the angle  $\omega t$ ,
- projecting the resulting vector on the axes, we have the real and imaginary part of the response,
- these two vector are rotated 90 degrees with respect to the response to real harmonic load,  $p_0 \sin \omega t$ .





# Measuring Support Accelerations

We have seen that in seismic analysis the loading is proportional to the ground acceleration. A simple oscillator, when properly damped, may serve the scope of measuring support accelerations.



# Measuring Support Accelerations

We have seen that in seismic analysis the loading is proportional to the ground acceleration. A simple oscillator, when properly damped, may serve the scope of measuring support accelerations.

- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2x = -a_g \sin \omega t,$

# Measuring Support Accelerations

We have seen that in seismic analysis the loading is proportional to the ground acceleration. A simple oscillator, when properly damped, may serve the scope of measuring support accelerations.

- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2x = -a_g \sin \omega t,$
- the stationary response is  $\xi = \frac{m a_g}{k} D(\beta, \zeta) \sin(\omega t - \theta).$

# Measuring Support Accelerations

We have seen that in seismic analysis the loading is proportional to the ground acceleration. A simple oscillator, when properly damped, may serve the scope of measuring support accelerations.

- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2x = -a_g \sin \omega t,$
- the stationary response is  $\xi = \frac{m a_g}{k} D(\beta, \zeta) \sin(\omega t - \theta).$

If we take into account that  $D$  is nearly equal to 1 in the range  $0.0 < \beta < 0.6$  for  $\zeta = 0.7$ , we see that the displacements will be proportional to the accelerations of the support for applied frequencies up to about six-tenths of the natural frequency of the instrument, if the damping ratio is  $\zeta \approx 0.7$ .



# Measuring Displacements

Consider now a harmonic *displacement* of the support,  
 $u_g(t) = u_g \sin \omega t$ . The support acceleration (disregarding the sign) is  
 $a_g(t) = \omega^2 u_g \sin \omega t$ .



# Measuring Displacements

Consider now a harmonic *displacement* of the support,  
 $u_g(t) = u_g \sin \omega t$ . The support acceleration (disregarding the sign) is  
 $a_g(t) = \omega^2 u_g \sin \omega t$ .

- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2 x = -\omega^2 u_g \sin \omega t$ ,



# Measuring Displacements

Consider now a harmonic *displacement* of the support,

$u_g(t) = u_g \sin \omega t$ . The support acceleration (disregarding the sign) is  
 $a_g(t) = \omega^2 u_g \sin \omega t$ .


- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2 x = -\omega^2 u_g \sin \omega t$ ,
- the stationary response is  $\xi = u_g \beta^2 D(\beta, \zeta) \sin(\omega t - \theta)$ .

# Measuring Displacements

Consider now a harmonic *displacement* of the support,

$u_g(t) = u_g \sin \omega t$ . The support acceleration (disregarding the sign) is  $a_g(t) = \omega^2 u_g \sin \omega t$ .

- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2 x = -\omega^2 u_g \sin \omega t$ ,
- the stationary response is  $\xi = u_g \beta^2 D(\beta, \zeta) \sin(\omega t - \theta)$ .




# Measuring Displacements

Consider now a harmonic *displacement* of the support,

$u_g(t) = u_g \sin \omega t$ . The support acceleration (disregarding the sign) is  $a_g(t) = \omega^2 u_g \sin \omega t$ .

- With the equation of motion:  $\ddot{x} + 2\zeta\beta\omega_n\dot{x} + \omega_n^2 x = -\omega^2 u_g \sin \omega t$ ,
- the stationary response is  $\xi = u_g \beta^2 D(\beta, \zeta) \sin(\omega t - \theta)$ .



We see that the displacement of the instrument is approximately equal to the support displacement for all the excitation frequencies greater than the natural frequency of the instrument, for a damping ratio  $\zeta \approx .5$ .



# Vibration Isolation



# Vibration Isolation

Vibration isolation is a subject too broad to be treated in detail, we'll present the basic principles involved in two problems,



# Vibration Isolation

Vibration isolation is a subject too broad to be treated in detail, we'll present the basic principles involved in two problems,

- prevention of harmful vibrations in supporting structures due to oscillatory forces produced by operating equipment,



# Vibration Isolation

Vibration isolation is a subject too broad to be treated in detail, we'll present the basic principles involved in two problems,

- prevention of harmful vibrations in supporting structures due to oscillatory forces produced by operating equipment,
- prevention of harmful vibrations in sensitive instruments due to vibrations of their supporting structures.



# Force Isolation

A rotating machine produces an oscillatory force  $p_0 \sin \omega t$  due to unbalance in its rotating part, has a mass  $m$  and is mounted on a SDOF spring-damper support.



# Force Isolation

A rotating machine produces an oscillatory force  $p_0 \sin \omega t$  due to unbalance in its rotating part, has a mass  $m$  and is mounted on a SDOF spring-damper support.

Its steady-state relative displacement support is given by

$$x_{ss} = \frac{p_0}{k} D \sin(\omega t - \theta).$$

This result depend on the assumption that the supporting structure deflections are negligible respect to the relative system motion.

The steady-state spring and damper forces are



# Force Isolation

A rotating machine produces an oscillatory force  $p_0 \sin \omega t$  due to unbalance in its rotating part, has a mass  $m$  and is mounted on a SDOF spring-damper support.

Its steady-state relative displacement support is given by

$$x_{ss} = \frac{p_0}{k} D \sin(\omega t - \theta).$$

This result depend on the assumption that the supporting structure deflections are negligible respect to the relative system motion.

The steady-state spring and damper forces are

$$f_S = k x_{ss} = p_0 D \sin(\omega t - \theta),$$

$$f_D = c \dot{x}_{ss} = \frac{c p_0 D \omega}{k} \cos(\omega t - \theta) = 2 \zeta \beta p_0 D \cos(\omega t - \theta).$$



# Transmitted force

The spring and damper forces are in quadrature, so the amplitude of the steady-state reaction force is given by

$$f_{\max} = p_0 D \sqrt{1 + (2\zeta\beta)^2}$$



# Transmitted force

The spring and damper forces are in quadrature, so the amplitude of the steady-state reaction force is given by

$$f_{\max} = p_0 D \sqrt{1 + (2\zeta\beta)^2}$$

The ratio of the maximum transmitted force to the amplitude of the applied force is the *transmissibility ratio* (TR),

$$\text{TR} = \frac{f_{\max}}{p_0} = D \sqrt{1 + (2\zeta\beta)^2}.$$


# Transmitted force

The spring and damper forces are in quadrature, so the amplitude of the steady-state reaction force is given by

$$f_{\max} = p_0 D \sqrt{1 + (2\zeta\beta)^2}$$

The ratio of the maximum transmitted force to the amplitude of the applied force is the *transmissibility ratio* (TR),

$$\text{TR} = \frac{f_{\max}}{p_0} = D \sqrt{1 + (2\zeta\beta)^2}.$$





# Displacement Isolation

Another problem concerns the harmonic support motion  $u_g(t) = u_{g_0} \exp i\omega t$  forcing a steady-state relative displacement of some supported (spring+damper) equipment of mass  $m$  (using exp notation)

$x_{ss} = u_{g_0} \beta^2 D \exp i\omega t$ , and the mass total displacement is given by

$$\begin{aligned}x_{\text{Tot}} &= x_{ss} + u_g(t) = u_{g_0} \left( \frac{\beta^2}{(1 - \beta^2) + 2i\zeta\beta} + 1 \right) \exp i\omega t \\&= u_{g_0} (1 + 2i\zeta\beta) \frac{1}{(1 - \beta^2) + 2i\zeta\beta} \exp i\omega t \\&= u_{g_0} \sqrt{1 + (2\zeta\beta)^2} D \exp i(\omega t - \varphi).\end{aligned}$$

# Displacement Isolation

Another problem concerns the harmonic support motion  $u_g(t) = u_{g_0} \exp i\omega t$  forcing a steady-state relative displacement of some supported (spring+damper) equipment of mass  $m$  (using exp notation)

$x_{ss} = u_{g_0} \beta^2 D \exp i\omega t$ , and the mass total displacement is given by

$$\begin{aligned}x_{\text{Tot}} &= x_{ss} + u_g(t) = u_{g_0} \left( \frac{\beta^2}{(1 - \beta^2) + 2i\zeta\beta} + 1 \right) \exp i\omega t \\&= u_{g_0} (1 + 2i\zeta\beta) \frac{1}{(1 - \beta^2) + 2i\zeta\beta} \exp i\omega t \\&= u_{g_0} \sqrt{1 + (2\zeta\beta)^2} D \exp i(\omega t - \varphi).\end{aligned}$$

If we define the transmissibility ratio TR as the ratio of the maximum total response to the support displacement amplitude, we find that, as in the previous case,

$$\text{TR} = D \sqrt{1 + (2\zeta\beta)^2}.$$



# Isolation Effectiveness

Define the isolation effectiveness,

$$\text{IE} = 1 - \text{TR},$$

$\text{IE}=1$  means complete isolation, i.e.,  $\beta = \infty$ , while  $\text{IE}=0$  is no isolation, and takes place for  $\beta = \sqrt{2}$ .

As effective isolation requires low damping, we can approximate  $\text{TR} \approx 1/(\beta^2 - 1)$ , in which case we have  $\text{IE} = (\beta^2 - 2)/(\beta^2 - 1)$ .



# Isolation Effectiveness

Define the isolation effectiveness,

$$\text{IE} = 1 - \text{TR},$$

$\text{IE}=1$  means complete isolation, i.e.,  $\beta = \infty$ , while  $\text{IE}=0$  is no isolation, and takes place for  $\beta = \sqrt{2}$ .

As effective isolation requires low damping, we can approximate  $\text{TR} \approx 1/(\beta^2 - 1)$ , in which case we have  $\text{IE} = (\beta^2 - 2)/(\beta^2 - 1)$ . Solving for  $\beta^2$ , we have  $\beta^2 = (2 - \text{IE})/(1 - \text{IE})$ , but

$$\beta^2 = \omega^2/\omega_n^2 = \omega^2 (m/k) = \omega^2 (W/gk) = \omega^2 (\Delta_{\text{st}}/g)$$

where  $W$  is the weight of the mass and  $\Delta_{\text{st}}$  is the static deflection under self weight. Finally, from  $\omega = 2\pi f$  we have



# Isolation Effectiveness

Define the isolation effectiveness,

$$\text{IE} = 1 - \text{TR},$$

$\text{IE}=1$  means complete isolation, i.e.,  $\beta = \infty$ , while  $\text{IE}=0$  is no isolation, and takes place for  $\beta = \sqrt{2}$ .

As effective isolation requires low damping, we can approximate  $\text{TR} \approx 1/(\beta^2 - 1)$ , in which case we have  $\text{IE} = (\beta^2 - 2)/(\beta^2 - 1)$ . Solving for  $\beta^2$ , we have  $\beta^2 = (2 - \text{IE})/(1 - \text{IE})$ , but

$$\beta^2 = \omega^2/\omega_n^2 = \omega^2 (m/k) = \omega^2 (W/gk) = \omega^2 (\Delta_{\text{st}}/g)$$

where  $W$  is the weight of the mass and  $\Delta_{\text{st}}$  is the static deflection under self weight. Finally, from  $\omega = 2\pi f$  we have

$$f = \frac{1}{2\pi} \sqrt{\frac{g}{\Delta_{\text{st}}} \frac{2 - \text{IE}}{1 - \text{IE}}}$$



# Isolation Effectiveness (2)

The strange looking

$$f = \frac{1}{2\pi} \sqrt{\frac{g}{\Delta_{st}} \frac{2 - IE}{1 - IE}}$$

can be plotted  $f$  vs  $\Delta_{st}$



# Isolation Effectiveness (2)

The strange looking

$$f = \frac{1}{2\pi} \sqrt{\frac{g}{\Delta_{st}} \frac{2 - IE}{1 - IE}}$$

can be plotted  $f$  vs  $\Delta_{st}$

# Isolation Effectiveness (2)




The strange looking

$$f = \frac{1}{2\pi} \sqrt{\frac{g}{\Delta_{st}} \frac{2 - IE}{1 - IE}}$$

can be plotted  $f$  vs  $\Delta_{st}$  for different values of IE, obtaining a design chart.

Knowing the frequency of excitation and the required level of vibration isolation efficiency (IE), one can determine the minimum static deflection (proportional to the spring flexibility) required to achieve the required IE. It is apparent that any isolation system must be very flexible to be effective.





# Evaluation of viscous-damping ratio



# Evaluation of damping

The mass and stiffness of physical systems of interest are usually evaluated easily, but this is not feasible for damping, as the energy is dissipated by different mechanisms, some one not fully understood... it is even possible that dissipation cannot be described in term of viscous-damping, But it generally is possible to measure an equivalent viscous-damping ratio by experimental methods:

- free-vibration decay method,



# Evaluation of damping

The mass and stiffness of physical systems of interest are usually evaluated easily, but this is not feasible for damping, as the energy is dissipated by different mechanisms, some one not fully understood... it is even possible that dissipation cannot be described in term of viscous-damping, But it generally is possible to measure an equivalent viscous-damping ratio by experimental methods:

- free-vibration decay method,
- resonant amplification method,



# Evaluation of damping

The mass and stiffness of physical systems of interest are usually evaluated easily, but this is not feasible for damping, as the energy is dissipated by different mechanisms, some one not fully understood... it is even possible that dissipation cannot be described in term of viscous-damping, But it generally is possible to measure an equivalent viscous-damping ratio by experimental methods:

- free-vibration decay method,
- resonant amplification method,
- half-power (bandwidth) method,



# Evaluation of damping

The mass and stiffness of physical systems of interest are usually evaluated easily, but this is not feasible for damping, as the energy is dissipated by different mechanisms, some one not fully understood... it is even possible that dissipation cannot be described in term of viscous-damping, But it generally is possible to measure an equivalent viscous-damping ratio by experimental methods:

- free-vibration decay method,
- resonant amplification method,
- half-power (bandwidth) method,
- resonance cyclic energy loss method.



# Free vibration decay

We already have discussed the free-vibration decay method,

$$\zeta = \frac{\delta_m}{2\pi m (\omega_n/\omega_D)}$$

with  $\delta_m = \ln \frac{x_n}{x_{n+m}}$ , *logarithmic decrement*. The method is simple and its requirements are minimal, but some care must be taken in the interpretation of free-vibration tests, because the damping ratio decreases with decreasing amplitudes of the response,



# Free vibration decay

We already have discussed the free-vibration decay method,

$$\zeta = \frac{\delta_m}{2\pi m (\omega_n/\omega_D)}$$

with  $\delta_m = \ln \frac{x_n}{x_{n+m}}$ , *logarithmic decrement*. The method is simple and its requirements are minimal, but some care must be taken in the interpretation of free-vibration tests, because the damping ratio decreases with decreasing amplitudes of the response, meaning that for a very small amplitude of the motion the effective values of the damping can be underestimated.



# Resonant amplification

This method assumes that it is possible to measure the stiffness of the structure, and that damping is small.



# Resonant amplification

This method assumes that it is possible to measure the stiffness of the structure, and that damping is small.

The experimenter (*a*) measures the steady-state response  $x_{ss}$  of a SDOF system under a harmonic loading for a number of different excitation frequencies (eventually using a smaller frequency step when close to the resonance),



# Resonant amplification

This method assumes that it is possible to measure the stiffness of the structure, and that damping is small.

The experimenter (a) measures the steady-state response  $x_{ss}$  of a SDOF system under a harmonic loading for a number of different excitation frequencies (eventually using a smaller frequency step when close to the resonance), (b) finds the maximum value  $D_{\max} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$  of the dynamic magnification factor,



# Resonant amplification

This method assumes that it is possible to measure the stiffness of the structure, and that damping is small.

The experimenter (a) measures the steady-state response  $x_{ss}$  of a SDOF system under a harmonic loading for a number of different excitation frequencies (eventually using a smaller frequency step when close to the resonance), (b) finds the maximum value  $D_{\max} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$  of the dynamic magnification factor, (c) uses the approximate expression (good for small  $\zeta$ )  $D_{\max} = \frac{1}{2\zeta}$  to write

$$D_{\max} = \frac{1}{2\zeta} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$$



# Resonant amplification

This method assumes that it is possible to measure the stiffness of the structure, and that damping is small.

The experimenter (a) measures the steady-state response  $x_{ss}$  of a SDOF system under a harmonic loading for a number of different excitation frequencies (eventually using a smaller frequency step when close to the resonance), (b) finds the maximum value  $D_{\max} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$  of the dynamic magnification factor, (c) uses the approximate expression (good for small  $\zeta$ )  $D_{\max} = \frac{1}{2\zeta}$  to write

$$D_{\max} = \frac{1}{2\zeta} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$$

and finally (d) has

$$\zeta = \frac{\Delta_{st}}{2 \max\{x_{ss}\}}.$$



# Resonant amplification

This method assumes that it is possible to measure the stiffness of the structure, and that damping is small.

The experimenter (a) measures the steady-state response  $x_{ss}$  of a SDOF system under a harmonic loading for a number of different excitation frequencies (eventually using a smaller frequency step when close to the resonance), (b) finds the maximum value  $D_{\max} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$  of the dynamic magnification factor, (c) uses the approximate expression (good for small  $\zeta$ )  $D_{\max} = \frac{1}{2\zeta}$  to write

$$D_{\max} = \frac{1}{2\zeta} = \frac{\max\{x_{ss}\}}{\Delta_{st}}$$

and finally (d) has

$$\zeta = \frac{\Delta_{st}}{2 \max\{x_{ss}\}}.$$

The most problematic aspect here is getting a good estimate of  $\Delta_{st}$ , if the results of a static test aren't available.



# Half power

The adimensional frequencies where the response is  $1/\sqrt{2}$  times the peak value can be computed from the equation

$$\frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}} = \frac{1}{\sqrt{2}} \frac{1}{2\zeta\sqrt{1 - \zeta^2}}$$



# Half power

The adimensional frequencies where the response is  $1/\sqrt{2}$  times the peak value can be computed from the equation

$$\frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}} = \frac{1}{\sqrt{2}} \frac{1}{2\zeta\sqrt{1 - \zeta^2}}$$

squaring both sides and solving for  $\beta^2$  gives

$$\beta_{1,2}^2 = 1 - 2\zeta^2 \mp 2\zeta\sqrt{1 - \zeta^2}$$



# Half power

The adimensional frequencies where the response is  $1/\sqrt{2}$  times the peak value can be computed from the equation

$$\frac{1}{\sqrt{(1 - \beta^2)^2 + (2\beta\zeta)^2}} = \frac{1}{\sqrt{2}} \frac{1}{2\zeta\sqrt{1 - \zeta^2}}$$

squaring both sides and solving for  $\beta^2$  gives

$$\beta_{1,2}^2 = 1 - 2\zeta^2 \mp 2\zeta\sqrt{1 - \zeta^2}$$

For small  $\zeta$  we can use the binomial approximation and write

$$\beta_{1,2} = \left(1 - 2\zeta^2 \mp 2\zeta\sqrt{1 - \zeta^2}\right)^{\frac{1}{2}} \approx 1 - \zeta^2 \mp \zeta\sqrt{1 - \zeta^2}$$



# Half power (2)

From the approximate expressions for the difference of the half power frequency ratios,

$$\beta_2 - \beta_1 = 2\zeta\sqrt{1 - \zeta^2} \approx 2\zeta$$

and their sum

$$\beta_2 + \beta_1 = 2(1 - \zeta^2) \approx 2$$

we can deduce that

$$\frac{\beta_2 - \beta_1}{\beta_2 + \beta_1} = \frac{f_2 - f_1}{f_2 + f_1} \approx \frac{2\zeta\sqrt{1 - \zeta^2}}{2(1 - \zeta^2)} \approx \zeta, \text{ or } \zeta \approx \frac{f_2 - f_1}{f_2 + f_1}$$

where  $f_1$ ,  $f_2$  are the frequencies at which the steady state amplitudes equal  $1/\sqrt{2}$  times the peak value, frequencies that can be determined from a dynamic test where detailed test data is available.



# Resonance Cyclic Energy Loss

If it is possible to determine the phase of the s-s response, it is possible to measure  $\zeta$  from the amplitude  $\rho$  of the resonant response, because the external force is equilibrated *only* by the viscous force, as both spring and inertia are in quadrature with the excitation:

$$p_0 = c \dot{x} = 2\zeta\omega_n m (\omega_n\rho)$$

so that we have

$$\zeta = \frac{p_0}{2m\omega_n^2\rho}$$