ARM60 tracked excavator R3 — dimensional interfaces





All dimensions in mm. Kinematic reference only; use the supplied STEP files for manufacturing.

Printer-bed splitting is deferred. Purchased shafts, bearings and hubs must match their interface drawings.