

Adirondack Chair, Build Plan

Workshop project, garage bench. Built on Dad's tools. Western red cedar.

Overview

A classic fan back Adirondack chair in western red cedar, finished with exterior oil. Cut on the garage bench using Dad's tools. Planned for the backyard near the raised beds. Take it slow, dry fit everything before glue. No rush on this one.

Cut List

Part	Quantity	Dimensions (T x W x L)	Material
Rear legs	2	1.5 in x 5.5 in x 36 in	Cedar
Front legs	2	1.5 in x 2.5 in x 21 in	Cedar
Seat slats	6	0.75 in x 2.5 in x 22 in	Cedar
Seat support, front	1	1.5 in x 2.5 in x 22 in	Cedar
Back slats	7	0.75 in x 2.5 in x 36 in	Cedar
Lower back brace	1	0.75 in x 3.5 in x 22 in	Cedar
Upper back brace	1	0.75 in x 3.5 in x 22 in	Cedar
Armrests	2	0.75 in x 5.5 in x 28 in	Cedar
Arm support posts	2	1.5 in x 2.5 in x 11 in	Cedar

Hardware and Supplies

- Exterior grade construction screws, 1.25 in and 2.5 in, stainless.
- Waterproof wood glue.
- 120 and 220 grit sandpaper.
- Exterior penetrating oil finish, natural tone.

Steps

- 1 Mill and cut all parts. Label each with a pencil. Sand to 120 before assembly.
- 2 Build the seat frame and attach the rear and front legs. Check square.
- 3 Fasten the seat slats with even spacing, a pencil's width apart.
- 4 Shape and attach the back slats to the braces, then mount to the seat.
- 5 Add the arm support posts and armrests last. Ease all edges.
- 6 Final sand to 220, two coats of oil, light buff between coats.

Estimated shop time: four to six Saturday afternoons. Measure twice. The measuring square was Dad's. Use it well.