# 5. FLUID DYNAMICS

### BERNOULLI'S EQUATION:

	$\sum r_s = m u_s$		
Forces ac	ting on the fluid element sho	own in the figure,	
$F_g = Gr$	avitational Force	$F_P$ = Pressure Force	
r - w	F	E - Turkulant Force	


$$F_g$$
 = Gravitational Force  $F_P$  = Pressure Force  $F_V$  = Viscous Force  $F_T$  = Turbulent Force  $F_S$  = Surface Tension Force  $F_C$  = Compressible Force  $\left(F_g + F_P + F_V + F_T + F_S + F_C\right)_S = m \ a_S$ 

$$(F_g + F_P + F_V + F_T + F_S + F_C)_s = m \, a_s$$

$$\therefore (F_g + F_P + F_V + F_T)_s = m \, a_s \, (Reynold's \, Equation)$$

$$\therefore (F_g + F_P + F_V)_s = m \, a_s \, (Navier - Stoke's \, Equation)$$

$$\therefore (F_g + F_P) = m \, a_s \, (Euler's \, Equation)$$



Bernoulli's Eq. For Steady and incompressible Flow, Pressure Head + Kinetic Head + Potential or Datum Head = Total Head = Const.  $\frac{P}{\rho a} + \frac{V^2}{2a} + z = H$ Bernoulli's Eq. For Steady and incompressible Flow,

 $dW = \rho g dV$ 

Net mechanical energy of fluid in an ideal flow remains constant.

### VARIOUS FORMS OF RERNOULLI'S FOUATION.

VARIOUS FORMS OF BERNOULLI'S EQUATION.				
Energy Per unit mass,			Energy Per unit Volume,	
$P V^2$			$V^2$	
$\frac{P}{\rho} + \frac{V^2}{2} + gz = Constant$		ıt	$P + \rho \frac{v}{2} + \rho gz = Constant$	
P = Static Pressure		$\rho(V^2/2)$ = Dynamic Pressure (Rise		$\rho gz =$ Hydrostatic Pressure (Rise in
		in pressure due to drop in K.E.)		pressure due to drop in P.E.)
Energy Per unit weight,	At stagnation point, Stagnation Pressure = Static Pressure + Dynamic Pressure			
$P V^2$	Piezometric Pressure = Static Pressure + Hydrostatic Pressure			
$\frac{1}{\gamma} + \frac{1}{2g} + z = Constant$				

#### LIMITATIONS/ ASSUMPTIONS IN BERNOULLI'S EQUATION


- 1. Flow is Steady.
- 2. Incompressible Flow.
- 3. Heat Transfer effects are neglected.
- 4. In Irrotational Flow, B. Eq. is valid across any two stream line but for Rotational flow, B. Eq. is valid only along stream line not across the stream line.
- 5. Involvement of shaft work (Pump & Turbine): Heads need to balance when energy per unit mass is added or removed. E.g. Pump is adding head & turbine is Using head to gain shaft work.
- Valid only for ideal flow. But by introducing head loss, we can use the B. Eq. for real flow.

**HEAD LOSS:** Energy given by the fluid to overcome resistance against the flow per unit weight is called head loss. **NOTE:** In the absence of a pump, Real flow takes place from higher total head to lower total head.

#### KINETIC ENERGY CORRECTION FACTOR ( $\alpha$ ):

When the velocity profile is non uniform, Total velocity head and avg. velocity head are not equal. cal Velocity – 11 & Avg. Velocity – V

Local velocity = $u \propto Avg$ . velocity = $v$			
$d(\dot{KE}) = \frac{1}{2}d\dot{m} u^2 \Rightarrow \dot{KE} = \frac{1}{2}\iint u^3 dA$	$\dot{KE} = \alpha \frac{1}{2} \rho A V^3$	$\alpha = \frac{1}{AV^3} \iint u^3 dA$	
Always $\alpha \geq 1$	For Laminar Flow	For turbulent flow through	
For uniform Flow $\alpha = 1$	through pipe $\alpha = 2$	pipes, $1.1 \le \alpha \le 1.3$	



#### DIFFERENCE IN PIEZOMETRIC HEAD:


$$\mathbf{P}_{A} = \mathbf{P}_{B} \Rightarrow P_{1} + \gamma_{w} z_{1} = P_{2} + \gamma_{w} (z_{2} - h_{m}) + \gamma_{m} h_{m}$$
$$\therefore \Delta P^{*} = h_{m} (\gamma_{m} - \gamma_{w})$$

$$P_{A} = P_{B} \Rightarrow P_{1} + \gamma_{w} z_{1} = P_{2} + \gamma_{w} (z_{2} - h_{m}) + \gamma_{m} h_{m}$$

$$\therefore \Delta P^{*} = h_{m} (\gamma_{m} - \gamma_{w})$$

$$\therefore \Delta h^{*} = h_{m} \left(\frac{\gamma_{m}}{\gamma_{w}} - 1\right) = h_{m} \left(\frac{S_{m}}{S_{w}} - 1\right)$$

$$S_{m} \gg S_{w} \Rightarrow \Delta h^{*} = h_{m} \left(\frac{S_{m}}{S_{w}}\right)$$



**EQUATION OF POWER:**  $P(in I) = h \rho g Q \& P(in W) = h \rho g \dot{Q}$ 

#### FREE LIQUID JET:


$u = V \cos \theta$	v	$= V \sin \theta$	H = Max. I	Height	T = Time of Flight
$s = ut + \frac{1}{2}a$	$t^2$	x = V	$\cos \theta t$	<i>y</i> =	$V\sin\theta \ t + \frac{1}{2}(-g)t^2$

From above both equations,

$$y = x(\tan \theta) - \left(\frac{g \sec^2 \theta}{2 V^2}\right) x^2 (Parabolic Eq.)$$

$$y = x(\tan \theta) - \left(\frac{g \sec^2 \theta}{2 V^2}\right) x^2 (Parabolic Eq.)$$

$$H = \frac{V^2 \sin^2 \theta}{2g} = \frac{v^2}{2g} (\because V^2 - U^2 = 2aS) \quad T = \frac{2v}{g} (\because V = U + at \& T = t_a + t_d)$$



### **VELOCITY MEASUREMENT**

$$\frac{V^2}{2g} = H - h^*$$

## 1. PITOT TUBE + PIEZOMETER:

$$h_{stag} = \frac{P}{\gamma} + \frac{V^2}{2g}$$
  $h_{stat} = \frac{P}{\gamma}$   $h^* = h_{stat} + z$   $H = h_{stag} + z$ 

$$h_{stat} = \frac{P}{\gamma}$$

$$h^* = h_{stat} + z$$
  
 $H = h_{stag} + z$ 


From above equations, we can find velocity head or velocity in the pipe.

$$V_{th} = \sqrt{2g(H - h^*)} = \sqrt{2gh}$$
 (From the Fig.)

Coefficient Of Velocity or Prob Factor  $C_V = \frac{Actual Velocity}{Theoretical Velocity}$ Actual Velocity

$$V_{act} = C_V \sqrt{2g(H - h^*)} = C_V \sqrt{2gh}$$

It can't use for gaseous fluid.




**NOTE:** If  $C_V$  is not give,  $C_V = 1$ .

#### 2. PITOT-STATIC TUBE:

$$V_{th} = \sqrt{2g\Delta h^*}$$

From the previous derivations,

$$V_{act} = C_V \sqrt{2g h_m \left(\frac{S_m}{S_w} - 1\right)}$$



#### **DISCHARGE/ FLOW MEASUREMENT:**

**OBSTRUCTION FLOWMETER:** E.g. Orifice Meter, Venturi Meter, Nozzle Meter. **Head-loss in Obstruction Flowmeter:** 


$$\left(\frac{P}{\gamma} + \frac{V^2}{2g} + z\right)_1 = \left(\frac{P}{\gamma} + \frac{V^2}{2g} + z\right)_2 + h_l \Rightarrow h_l = \Delta h^* - \left(\frac{V_2^2 - V_1^2}{2g}\right)$$

$$h_{l} = \Delta h^{*} - \frac{V_{2}^{2}A_{2}^{2}}{2g \Delta h^{*}} \left(1 - \frac{A_{2}^{2}}{A_{1}^{2}}\right) \frac{\Delta h^{*}}{A_{2}^{2}} = \Delta h^{*} - \frac{Q_{act}^{2}}{Q_{th}^{2}} \Delta h^{*}$$

$$\therefore h_{l} = \Delta h^{*} (1 - C_{d}^{2})$$

$$Q_{act}^{2} = V_{2}^{2}A_{2}^{2} \qquad Q_{th}^{2} = 2g \Delta h^{*} [A_{1}^{2}A_{2}^{2}/(A_{1}^{2} - A_{2}^{2})]$$
**VENTURI METER:**

$$\frac{n_l - \Delta n (1 - C_d)}{O_{-1}^2 - 2a \Lambda h^* [4^2 4^2 / (4^2 - 4^2)]}$$




$$h_l = \Delta h^* (1 - C_d^2)$$

VENTURI METER: 
$$h_l = \Delta h^* (1 - C_d^2)$$
 
$$Q_{act}^2 = V_2^2 A_2^2 \qquad Q_{th}^2 = 2g \Delta h^* [A_1^2 A_2^2 / (A_1^2 - A_2^2)]$$
 By Considering  $h_l = 0$ ,

$$\Delta h^* = \frac{V_2^2}{2g} \left( 1 - \frac{A_2^2}{A_1^2} \right) \Rightarrow V_2 = \frac{A_1}{\sqrt{A_1^2 - A_2^2}} \sqrt{2g \, \Delta h^*}$$

$$Q_{th} = \frac{A_1 A_2}{\sqrt{A_1^2 - A_2^2}} \sqrt{2g \, \Delta h^*} \Rightarrow Q_{th} = Q_{act}$$



 $Q_{th}$  equation is same for all measuring device.

$$PART - I: \frac{A_1 A_2}{\sqrt{A_1^2 - A_2^2}} = \frac{\pi}{4} \frac{D_1^2 D_2^2}{\sqrt{D_1^4 - D_2^4}}$$

$$Q_{th} \text{ equation is same for all measuring device.}$$

$$Coefficient of Discharge, C_d = \frac{Q_{act}}{Q_{th}} \qquad Coefficient of Contraction, C_c = \frac{A_c}{A_2} = \frac{V_2}{V_c}$$
In Venturi Meter, To Reduce Minor Losses in Diffuser, Converging Angle (20°) > Divergence Angle (7° to 15°)
$$PART - I: \frac{A_1 A_2}{\sqrt{A_1^2 - A_2^2}} = \frac{\pi}{4} \frac{D_1^2 D_2^2}{\sqrt{D_1^4 - D_2^4}} \qquad PART - II: \sqrt{2g \Delta h^*} \Rightarrow \Delta h^* = h_m \left(\frac{S_m}{S_w} - 1\right) = \frac{\Delta P^*}{\gamma}$$

	Venturi Meter	Nozzle Meter	Orifice Meter
$C_d$	0.95-0.98 (High)	0.85 (Medium)	0.65 (Low)
$h_{loss}$	Low	Medium	High
Accuracy	High	Medium	Low
Cost	High	Medium	Low


**VORTEX MOTION:** It's motion of fluid along a curved path is known as vortex motion.

E.g. Whirlpool, Tornado, Water Sink, etc...


1. 
$$V_r = 0$$
,  $V_\theta$  exists.

#### 2. Stream Lines are curved.

To the chiefe.	21 Stream Emes are car vea.		
TYPE OF VORTEX FLOW			
FREE VORTEX FLOW	FORCED VORTEX FLOW		
It's naturally (By the virtue of motion itself) exists.	Appling external torque for generating Vortex flow.		
External Torque is equal to zero.	Constant External Torque is applied.		
$T = 0 \Rightarrow \frac{d(mv  r)}{dt} = 0 \Rightarrow mv  r = Constant$	Angular Velocity of every partial is same.		
$T = 0 \Rightarrow \frac{dt}{dt} = 0 \Rightarrow mv \ r = Constant$	$T = Const. \Rightarrow \omega = Const. \Rightarrow v \propto r$		
Singularity Point: $r = 0 \Rightarrow v = not \ defined$	$r = 0 \Rightarrow v = 0$		
Flow is irrotational. E.g. Bernoulli's equation can be	Flow is rotational. E.g. Bernoulli's equation can be		
applied between any point.	applied between any point lying on same stream lines.		
Valid for any 2 random points,	Valid for any 2 random points,		
$\frac{P_A}{\gamma} + \frac{V_A^2}{2g} + z_A = \frac{P_B}{\gamma} + \frac{V_B^2}{2g} + z_B$	$\frac{P_A}{\gamma} - \frac{V_A^2}{2g} + z_A = \frac{P_B}{\gamma} - \frac{V_B^2}{2g} + z_B$		



#### **EQUATION OF PRESSURE:**



Note: Forced Vortex Flow is Part of Rigid Body Motion.

FREE VORTEX FLOW	FORCED VORTEX FLOW
$v r = r^2 \omega = C$	$v = C r \Leftrightarrow \omega = Const.$
$\frac{P_A}{\gamma} + \frac{V_A^2}{2g} + z_A = \frac{P_B}{\gamma} + \frac{V_B^2}{2g} + z_B(From  dP  Eq.)$	$\frac{P_A}{\gamma} - \frac{V_A^2}{2g} + z_A = \frac{P_B}{\gamma} - \frac{V_B^2}{2g} + z_B(From  dP  Eq.)$
Hence, the flow is irrotational.	Hence, the flow is rotational.

**EQUATIONS OF ISOBAR:** Constant pressure imaginary curve in vortex (Forced) flow. 
$$\frac{P_A}{\gamma} + \frac{V_A^2}{2g} + z_A = \frac{P_B}{\gamma} + \frac{V_B^2}{2g} + z_B \Rightarrow h = \frac{V_B^2 - V_A^2}{2g} = \frac{r^2 \omega^2}{2g} \propto r^2 \begin{bmatrix} \because z_A - z_B, V_A = 0, V_B = r\omega \\ It's \ Parabolic \ Curve \end{bmatrix}$$

#### **VOLUME OF PARABOLOID:** Volume of revolution of parabola. E.g. Circumscribing cylinder with parabola.

<b>Circumscribed</b> refers to a shape surrounding another shape. $\forall_{par.} = \frac{\pi \omega^2 R^4}{\sigma} = \frac{1}{2} \forall_{cyl.} (\because r_{max} = R)$	
g + L	