part3:-

```
bool isWpaSupplicantRunning(const std::string& iface) {
// Check if the wpa_supplicant control socket exists for this interface
std::string ctrl_path = "/var/run/wpa_supplicant/" + iface;
return (access(ctrl_path.c_str(), F_OK) == 0);
}

bool startWpaSupplicant(const std::string& iface) {
// Use -B for background, -Dnl80211 for modern drivers
std::string command = "wpa_supplicant -B -Dnl80211 -i " + iface + " -c
/etc/wpa_supplicant.conf";
std::cout << "[*] Starting wpa_supplicant: " << command << std::endl;
return (system(command.c_str()) == 0);
}

bool sendP2PFindCommand(const std::string& iface) {
std::string ctrl_path = "/var/run/wpa_supplicant/" + iface;
std::string client_path = "/tmp/wpa_ctrl_" + iface + "_" + std::to_string(getpid());
```

```
int sock = socket(AF_UNIX, SOCK_DGRAM, 0);
if (sock < 0) {
    perror("[ERROR] socket creation");
    return false;
}
// Set a timeout for recv
struct timeval tv = {3, 0};
setsockopt(sock, SOL_SOCKET, SO_RCVTIMEO, &tv, sizeof(tv));
// Bind to client path
struct sockaddr_un local = {};
local.sun_family = AF_UNIX;
strncpy(local.sun_path, client_path.c_str(), sizeof(local.sun_path) - 1);
unlink(client_path.c_str());
if (bind(sock, (struct sockaddr*)&local, sizeof(local)) < 0) {</pre>
    perror("[ERROR] bind");
    close(sock);
    return false;
}
// Destination address (wpa_supplicant control socket)
struct sockaddr un remote = {};
remote.sun family = AF UNIX;
strncpy(remote.sun_path, ctrl_path.c_str(), sizeof(remote.sun_path) - 1);
const char *cmd = "P2P_FIND";
```

```
std::cout << "[DEBUG] Sending command: " << cmd << std::endl;</pre>
  if (sendto(sock, cmd, strlen(cmd), 0, (struct sockaddr*)&remote, sizeof(remote)) < 0) {
      perror("[ERROR] sendto");
      close(sock);
      unlink(client_path.c_str());
      return false;
  }
  char buf[4096] = \{\};
  socklen_t remote_len = sizeof(remote);
  int len = recvfrom(sock, buf, sizeof(buf) - 1, 0, (struct sockaddr*)&remote, &remote_len)
  if (len < 0) {
      perror("[ERROR] recvfrom");
      close(sock);
      unlink(client_path.c_str());
      return false;
  }
  buf[len] = '\0';
  std::cout << "[P2P_FIND response] " << buf << std::endl;</pre>
  close(sock);
  unlink(client_path.c_str());
  return true;
}
int main() {
auto wirelessIfs = getWirelessInterfaces();
if (wirelessIfs.empty()) {
std::cerr << "[X] No wireless interfaces found.\n";
return 1;
}
std::string baselface = wirelesslfs[0];
std::string p2plface = "p2p-" + baselface + "-0";
std::string uselface = p2plface;
  std::cout << "[*] Using base wireless interface: " << baseIface << std::endl;</pre>
  bool p2pCreated = false;
  if (!interfaceExists(p2pIface)) {
      std::cout << "[*] Attempting to create P2P interface...\n";</pre>
      p2pCreated = createP2PInterface(baseIface, p2pIface);
      if (!p2pCreated) {
          std::cout << "[!] Could not create P2P interface. Falling back to base interface
          useIface = baseIface;
  } else {
      p2pCreated = true;
  if (!isInterfaceUp(useIface)) {
      std::cout << "[*] Interface " << useIface << " is down. Bringing it up...\n";
```

```
if (!bringInterfaceUp(useIface)) {
        std::cerr << "[X] Failed to bring up interface.\n";</pre>
        return 1;
    }
}
std::cout << "[*] Checking for wpa_supplicant on " << useIface << "...\n";
if (!isWpaSupplicantRunning(useIface)) {
    std::cout << "[!] wpa supplicant not running. Starting...\n";</pre>
    if (!startWpaSupplicant(useIface)) {
        std::cerr << "[X] Failed to start wpa_supplicant.\n";</pre>
        return 1;
    // Wait a moment for wpa_supplicant to create the control socket
    sleep(2);
}
std::cout << "[*] Sending P2P_FIND command to " << useIface << "...\n";
if (!sendP2PFindCommand(useIface)) {
    std::cerr << "[X] Failed to send P2P_FIND command.\n";</pre>
    return 1;
}
std::cout << "[/] P2P FIND command sent successfully on " << useIface << ".\n";
monitorWpaSupplicantEvents(useIface, 30); // Monitor for 30 seconds
return 0;
```

thankyou

}

also please explain the other lib, bin internal componets of kernel

what thier role is?

how sockets and other are used to interact?

flow diagram of the code

Absolutely! Here's a **comprehensive breakdown** of your code's design, the role of kernel/userland components, socket interactions, and a **flow diagram**.

1. Code Design & Function Relationships

Your program is modular, with each function handling a specific aspect of the P2P (Wi-Fi Direct) setup and monitoring process. Here's how the main parts relate:

Function Map

- main()
 - Calls getWirelessInterfaces() to find a usable Wi-Fi interface.
 - Tries to create a P2P interface with createP2PInterface().
 - Falls back to base interface if P2P-device creation fails.
 - Ensures the chosen interface is up with isInterfaceUp() / bringInterfaceUp().

- Checks if wpa_supplicant is running with isWpaSupplicantRunning().
 - If not, starts it with startWpaSupplicant().
- Sends a P2P_FIND command using sendP2PFindCommand().
- Monitors for P2P events with monitorWpaSupplicantEvents().
- **getWirelessInterfaces()**: Scans system interfaces for wireless capability.
- interfaceExists(): Checks if a network interface exists.
- isInterfaceUp(): Checks if an interface is up.
- **bringInterfaceUp()**: Brings an interface up using ioctl.
- createP2PInterface(): Uses libnl (Netlink) to ask the kernel to create a P2P interface.
- isWpaSupplicantRunning(): Checks for the existence of the wpa_supplicant control socket.
- **startWpaSupplicant()**: Starts wpa_supplicant via a shell command.
- **sendP2PFindCommand()**: Sends the P2P_FIND command to wpa_supplicant's control socket.
- monitorWpaSupplicantEvents(): Attaches to the control socket and prints real-time events.

2. Linux Kernel, Libraries, and Binaries Involved

Kernel Components

- **nl80211**: The main kernel subsystem for Wi-Fi management, exposing netlink interfaces for advanced wireless operations (including P2P).
- Network interfaces: e.g., wlp2s0 managed by drivers like iwlwifi (Intel), ath9k (Atheros), etc.

Libraries

• **libnl-3**, **libnl-genl-3**: C libraries for communicating with the kernel's netlink interface, used for creating interfaces, querying wireless capabilities, etc.

Userland Binaries

- **wpa_supplicant**: User-space daemon that manages Wi-Fi authentication, association, and P2P operations.
- wpa_cli: Command-line client for interacting with wpa_supplicant via its control socket.
- iw: Utility for configuring wireless devices via nl80211 (not directly used here, but relevant).

3. How Sockets and Netlink Are Used

Netlink Sockets


- Used by libnl in your createP2PInterface() function to communicate with the kernel (nl80211 family).
- Allows user-space to send commands like "create new interface" directly to the kernel's networking stack.

UNIX Domain Sockets

- Used for communication between your application (and wpa_cli) and the wpa_supplicant daemon.
- The control socket (e.g., /var/run/wpa_supplicant/wlp2s0) is a UNIX domain socket.
- Your code sends commands (P2P_FIND, ATTACH, etc.) to wpa_supplicant and receives responses/events.

4. Flow Diagram

Here's a high-level flow diagram of your program's logic and interactions:



- Dashed lines represent communication via sockets (netlink or UNIX domain).
- Arrows represent function calls or process flow.

5. Component Roles and Interactions

Component	Role		
Kernel (nl80211)	Handles wireless interface management, P2P interface creation, etc.		
libnl	Provides C API to communicate with kernel netlink (nl80211)		
wpa_supplicant	Manages Wi-Fi/P2P connections, exposes control socket for commands		
Your Program	Orchestrates interface setup, P2P commands, and event monitoring		
UNIX Sockets	Used for control channel between your program and wpa_supplicant		
Netlink Sockets	Used for advanced kernel networking operations (via libnl)		

6. Typical Data Flows

• Interface Creation:

Your program → libnl/netlink → Kernel (nl80211) → Interface created

• P2P Command:

Your program → UNIX socket → wpa_supplicant → Wi-Fi hardware

• Event Monitoring:

wpa_supplicant → UNIX socket → Your program (events like P2P-DEVICE-FOUND)

7. Summary Table

Step	Library/API	Kernel/Userland Component	Socket Type
Interface discovery	C stdlib/sys	Kernel netdev	-
P2P interface create	libnl	Kernel nI80211	Netlink
Interface up	ioctl	Kernel	-
wpa_supplicant start	system()	Userland	-
P2P_FIND command	UNIX socket	wpa_supplicant	UNIX domain socket
Event monitoring	UNIX socket	wpa_supplicant	UNIX domain socket

8. Visual: Kernel/Userland/Socket Interactions



9. How Sockets Are Used

- **Netlink sockets**: For advanced networking commands to the kernel (interface creation, etc.).
- **UNIX domain datagram sockets**: For sending commands and receiving events from wpa_supplicant.

In Summary

- Your code orchestrates Wi-Fi Direct setup and monitoring by leveraging kernel interfaces (via libnl/netlink) and userland daemons (wpa_supplicant).
- Sockets (netlink and UNIX domain) are the glue for communication between your code, the kernel, and wpa_supplicant.

- The flow is: detect interface → (try) create P2P interface → ensure interface is up → ensure wpa_supplicant is running → send P2P_FIND → monitor for events.
- Each function is responsible for a clear, well-defined task, making your design modular and maintainable.

If you want a more detailed diagram, or have specific questions about any component, function, or flow, just ask!