# OBD-II PIDs

From Wikipedia, the free encyclopedia

OBD-II PIDs (On-board diagnostics Parameter IDs) are codes used to request data from a vehicle, used as a diagnostic tool.

SAE standard J/1979 defines many PIDs, but manufacturers also define many more PIDs specific to their vehicles. All light duty vehicles (i.e. less than 8,500 pounds) sold in North America since 1996, as well as medium duty vehicles (i.e. 8,500-14,000 pounds) beginning in 2005, and heavy duty vehicles (i.e. greater than 14,000 pounds) beginning in 2010, [1] are required to support OBD-II diagnostics, using a standardized data link connector, and a subset of the SAE J/1979 defined PIDs (or SAE J/1939 as applicable for medium/heavy duty vehicles), primarily for state mandated emissions inspections.

Typically, an automotive technician will use PIDs with a scan tool connected to the vehicle's OBD-II connector.

- The technician enters the PID
- The scan tool sends it to the vehicle's controller area network (CAN)-bus, VPW, PWM, ISO, KWP. (After 2008, CAN only)
- A device on the bus recognizes the PID as one it is responsible for, and reports the value for that PID to the bus
- ullet The scan tool reads the response, and displays it to the technician

# Contents 1 Modes 2 Standard PIDs 2.1 Mode 01 2.2 Mode 02 2.3 Mode 03 2.4 Mode 04 2.5 Mode 05 2.6 Mode 09 2.7 Bitwise encoded PIDs 2.7.1 Mode 1 PID 00 2.7.2 Mode 1 PID 01 2.7.3 Mode 1 PID 41 2.7.4 Mode 1 PID 78 2.7.5 Mode 3 (no PID required) 2.7.6 Mode 9 PID 08 2.7.7 Mode 9 PID 0B 2.8 Enumerated PIDs 2.8.1 Mode 1 PID 03 2.8.2 Mode 1 PID 12

2.8.3 Mode 1 PID 1C

2.8.4 Fuel Type Coding

3 Non-standard PIDs

4 CAN (11-bit) bus format

- 4.1 Query
- 4.2 Response
- 5 See also
- 6 References
- 7 External links

# Modes

There are 10 modes of operation described in the latest OBD-II standard SAE J1979. They are as follows:

Mode (hex)	Description
01	Show current data
02	Show freeze frame data
03	Show stored Diagnostic Trouble Codes
04	Clear Diagnostic Trouble Codes and stored values
05	Test results, oxygen sensor monitoring (non CAN only)
06	Test results, other component/system monitoring (Test results, oxygen sensor monitoring for CAN only)
07	Show pending Diagnostic Trouble Codes (detected during current or last driving cycle)
08	Control operation of on-board component/system
09	Request vehicle information
OA	Permanent Diagnostic Trouble Codes (DTCs) (Cleared DTCs)

Vehicle manufacturers are not required to support all modes. Each manufacturer may define additional modes above #9 (e.g.: mode 22 as defined by SAE J2190 for Ford/GM, mode 21 for Toyota) for other information e.g. the voltage of the traction battery in a hybrid electric vehicle (HEV). [2]

# Standard PIDs

The table below shows the standard OBD-II PIDs as defined by SAE J1979. The expected response for each PID is given, along with information on how to translate the response into meaningful data. Again, not all vehicles will support all PIDs and there can be manufacturer-defined custom PIDs that are not defined in the OBD-II standard.

Note that modes 1 and 2 are basically identical, except that Mode 1 provides current information, whereas Mode 2 provides a snapshot of the same data taken at the point when the last diagnostic trouble code was set. The exceptions are PID 01, which is only available in Mode 1, and PID 02, which is only available in Mode 2 PID 02 returns zero, then there is no snapshot and all other Mode 2 data is meaningless.

When using Bit-Encoded-Notation, quantities like C4 means bit 4 from data byte C. Each bit is numerated from 0 to 7, so 7 is the most significant bit and 0 is the least significant bit.

A							I	3							(	2							Ι	)							
A7	A6	A5	A4	АЗ	A2	A1	A0	В7	В6	В5	В4	ВЗ	В2	В1	ВО	С7	C6	C5	C4	СЗ	C2	C1	C0	D7	D6	D5	D4	D3	D2	D1	DO

#### Mode 01

PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>
00	4	PIDs supported [01 - 20]				Bit encoded [A7D0] == [PID \$01PID \$20] See below
01	4	Monitor status since DTCs cleared. (Includes malfunction indicator lamp (MIL) status and number of DTCs.)				Bit encoded. See below
02	2	Freeze DTC				
03	2	Fuel system status				Bit encoded. See below

2016/2/2		OBD-II PIE	Os - Wikipedia, the fre	e encyclopedia		
04	1	Calculated engine load value	0	100	%	A*100/255
05	1	Engine coolant temperature	-40	215	° C	A-40
06	1	Short term fuel % trim—Bank 1	-100 Subtracting Fuel (Rich Condition)	99.22 Adding Fuel (Lean Condition)	%	(A-128) * 100/128
07	1	Long term fuel % trim—Bank 1	-100 Subtracting Fuel (Rich Condition)	99.22 Adding Fuel (Lean Condition)	%	(A-128) * 100/128
08	1	Short term fuel % trim—Bank 2	-100 Subtracting Fuel (Rich Condition)	99.22 Adding Fuel (Lean Condition)	%	(A-128) * 100/128
09	1	Long term fuel % trim—Bank 2	-100 Subtracting Fuel (Rich Condition)	99.22 Adding Fuel (Lean Condition)	%	(A-128) * 100/128
OA	1	Fuel pressure	0	765	kPa (gauge)	A*3
0B	1	Intake manifold absolute pressure	0	255	kPa (absolute)	A
0C	2	Engine RPM	0	16, 383. 75	rpm	((A*256)+B)/4
OD	1	Vehicle speed	0	255	km/h	A
0E	1	Timing advance	-64	63. 5	relative to #1 cylinder	(A-128)/2
0F	1	Intake air temperature	-40	215	° C	A-40
10	2	MAF air flow rate	0	655. 35	grams/sec	((A*256)+B) / 100
11	1	Throttle position	0	100	%	A*100/255
12	1	Commanded secondary air status				Bit encoded. See below
13	1	Oxygen sensors present				[A0A3] == Bank 1, Sensors 1-4. [A4A7] == Bank 2
14	2	Bank 1, Sensor 1: Oxygen sensor voltage, Short term fuel trim	0 -100 (1ean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
15	2	Bank 1, Sensor 2: Oxygen sensor voltage, Short term fuel trim	0 -100 (1ean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
16	2	Bank 1, Sensor 3: Oxygen sensor voltage, Short term fuel trim	0 -100 (1ean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
17	2	Bank 1, Sensor 4: Oxygen sensor voltage, Short term fuel trim	0 -100(lean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
18	2	Bank 2, Sensor 1: Oxygen sensor voltage, Short term fuel trim	0 -100 (1ean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
19	2	Bank 2, Sensor 2: Oxygen sensor voltage, Short term fuel trim	0 -100 (1ean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
1 A	2	Bank 2, Sensor 3: Oxygen sensor voltage, Short term fuel trim	0 -100 (1ean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used

2016/2/2		000-111 103	vvikipedia, the ire	e elicyclopedia		
						in trim calc)
1B	2	Bank 2, Sensor 4: Oxygen sensor voltage, Short term fuel trim	0 -100(lean)	1.275 99.2(rich)	Volts %	A/200 (B-128) * 100/128 (if B==\$FF, sensor is not used in trim calc)
1C	1	OBD standards this vehicle conforms to				Bit encoded. See below
1D	1	Oxygen sensors present				Similar to PID 13, but [A0A7] == [B1S1, B1S2, B2S1, B2S2, B3S1, B3S2, B4S1, B4S2]
1E	1	Auxiliary input status				A0 == Power Take Off (PTO) status (1 == active) [A1A7] not used
1F	2	Run time since engine start	0	65, 535	seconds	(A*256)+B
20	4	PIDs supported [21 - 40]				Bit encoded [A7D0] == [PID \$21PID \$40] See below
21	2	Distance traveled with malfunction indicator lamp (MIL) on	0	65, 535	km	(A*256) +B
22	2	Fuel rail Pressure (relative to manifold vacuum)	0	5177. 265	kPa	((A*256)+B) * 0.079
23	2	Fuel rail Pressure (diesel, or gasoline direct inject)	0	655, 350	kPa (gauge)	((A*256)+B) * 10
24	4	O2S1_WR_lambda(1): Equivalence Ratio Voltage	0 0	1. 999 7. 999	N/A V	((A*256)+B)*2/65535 or ((A*256)+B)/32768 ((C*256)+D)*8/65535 or ((C*256)+D)/8192
25	4	O2S2_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
26	4	O2S3_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
27	4	O2S4_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
28	4	O2S5_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
29	4	O2S6_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
2A	4	O2S7_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
2В	4	O2S8_WR_lambda(1): Equivalence Ratio Voltage	0	2 8	N/A V	((A*256)+B)*2/65535 ((C*256)+D)*8/65535
2C	1	Commanded EGR	0	100	%	A*100/255
2D	1	EGR Error	-100	99. 22	%	(A-128) * 100/128
2E	1	Commanded evaporative purge	0	100	%	A*100/255
2F	1	Fuel Level Input	0	100	%	A*100/255
30	1	# of warm-ups since codes cleared	0	255	N/A	A
31	2	Distance traveled since codes cleared	0	65, 535	km	(A*256)+B
32	2	Evap. System Vapor Pressure	-8, 192	8, 192	Pa	((A*256)+B)/4 (A and B are two's complement signed)
33	1	Barometric pressure	0	255	kPa (Absolute)	A
34	4	O2S1_WR_lambda(1): Equivalence Ratio Current	0 -128	1. 999 127. 99	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128

2016/2/2		OBD-II PIDs -	Wikipedia, the fre	e encyclopedia		
35	4	O2S2_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128
36	4	O2S3_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32768 ((C*256)+D)/256 - 128
37	4	O2S4_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128
38	4	O2S5_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128
39	4	O2S6_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128
3A	4	O2S7_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128
3B	4	O2S8_WR_lambda(1): Equivalence Ratio Current	0 -128	2 128	N/A mA	((A*256)+B)/32,768 ((C*256)+D)/256 - 128
3C	2	Catalyst Temperature Bank 1, Sensor 1	-40	6, 513. 5	° C	((A*256)+B)/10 - 40
3D	2	Catalyst Temperature Bank 2, Sensor 1	-40	6, 513. 5	° C	((A*256)+B)/10 - 40
3E	2	Catalyst Temperature Bank 1, Sensor 2	-40	6, 513. 5	° C	((A*256)+B)/10 - 40
3F	2	Catalyst Temperature Bank 2, Sensor 2	-40	6, 513. 5	° C	((A*256)+B)/10 - 40
40	4	PIDs supported [41 - 60]				Bit encoded [A7D0] == [PID \$41PID \$60] See below
41	4	Monitor status this drive cycle				Bit encoded. See below
42	2	Control module voltage	0	65. 535	V	((A*256)+B)/1000
43	2	Absolute load value	0	25, 700	%	((A*256)+B)*100/255
44	2	Fuel/Air commanded equivalence ratio	0	2	N/A	((A*256)+B)/32768
45	1	Relative throttle position	0	100	%	A*100/255
46	1	Ambient air temperature	-40	215	° C	A-40
47	1	Absolute throttle position B	0	100	%	A*100/255
48	1	Absolute throttle position C	0	100	%	A*100/255
49	1	Accelerator pedal position D	0	100	%	A*100/255
4A	1	Accelerator pedal position E	0	100	%	A*100/255
4B	1	Accelerator pedal position F	0	100	%	A*100/255
4C	1	Commanded throttle actuator	0	100	%	A*100/255
4D	2	Time run with MIL on	0	65, 535	minutes	(A*256) +B
4E	2	Time since trouble codes cleared	0	65, 535	minutes	(A*256)+B
4F	4	Maximum value for equivalence ratio, oxygen sensor voltage, oxygen sensor current, and intake manifold absolute pressure	0, 0, 0, 0	255, 255, 255, 2550	, V, mA, kPa	A, B, C, D*10
50	4	Maximum value for air flow rate from mass air flow sensor	0	2550	g/s	A*10, B, C, and D are reserved for future use
51	1	Fuel Type				From fuel type table see below
52	1	Ethanol fuel %	0	100	%	A*100/255
53	2	Absolute Evap system Vapor Pressure	0	327. 675	kPa	((A*256)+B)/200
54	2	Evap system vapor pressure	-32, 767	32, 768	Pa	((A*256)+B)-32767
55	2	Short term secondary oxygen sensor trim bank 1 and bank 3	-100	99. 22	%	(A-128)*100/128 (B-128)*100/128

2016/2/2		OBD-II PIDs - Y	Wikipedia, the fre	ee encyclopedia		
56	2	Long term secondary oxygen sensor trim bank 1 and bank 3	-100	99. 22	%	(A-128)*100/128 (B-128)*100/128
57	2	Short term secondary oxygen sensor trim bank 2 and bank 4	-100	99. 22	%	(A-128)*100/128 (B-128)*100/128
58	2	Long term secondary oxygen sensor trim bank 2 and bank 4	-100	99. 22	%	(A-128)*100/128 (B-128)*100/128
59	2	Fuel rail pressure (absolute)	0	655, 350	kPa	((A*256)+B) * 10
5A	1	Relative accelerator pedal position	0	100	%	A*100/255
5B	1	Hybrid battery pack remaining life	0	100	%	A*100/255
5C	1	Engine oil temperature	-40	210	° C	A - 40
5D	2	Fuel injection timing	-210.00	301. 992	0	(((A*256)+B)-26,880)/128
5E	2	Engine fuel rate	0	3212. 75	L/h	((A*256)+B)*0.05
5F	1	Emission requirements to which vehicle is designed				Bit Encoded
60	4	PIDs supported [61 - 80]				Bit encoded [A7D0] == [PID \$61PID \$80] See below
61	1	Driver's demand engine - percent torque	-125	125	%	A-125
62	1	Actual engine - percent torque	-125	125	%	A-125
63	2	Engine reference torque	0	65, 535	Nm	A*256+B
64	5	Engine percent torque data	-125	125	%	A-125 Idle B-125 Engine point 1 C-125 Engine point 2 D-125 Engine point 3 E-125 Engine point 4
65	2	Auxiliary input / output supported				Bit Encoded
66	5	Mass air flow sensor				
67	3	Engine coolant temperature				
68	7	Intake air temperature sensor				
69	7	Commanded EGR and EGR Error				
6A	5	Commanded Diesel intake air flow control and relative intake air flow position				
6B	5	Exhaust gas recirculation temperature				
6C	5	Commanded throttle actuator control and relative throttle position				
6D	6	Fuel pressure control system				
6E	5	Injection pressure control system				
6F	3	Turbocharger compressor inlet pressure				
70	9	Boost pressure control				
71	5	Variable Geometry turbo (VGT) control				
72	5	Wastegate control				
73	5	Exhaust pressure				
74	5	Turbocharger RPM				
75	7	Turbocharger temperature				
76	7	Turbocharger temperature				
77	5	Charge air cooler temperature (CACT)				
78	9	Exhaust Gas temperature (EGT) Bank 1				Special PID. See below
79	9	Exhaust Gas temperature (EGT) Bank 2				Special PID. See below
7 A	7	Diesel particulate filter (DPF)				
<b>7</b> B	7	Diesel particulate filter (DPF)				
7C	9	Diesel Particulate filter (DPF) temperature				
7D	1	NOx NTE control area status				
7E	1	PM NTE control area status				
<b>7</b> F	13	Engine run time				

80	4	PIDs supported [81 - A0]				Bit encoded [A7D0] == [PID \$81PID \$A0] See below
81	21	Engine run time for Auxiliary Emissions Control Device (AECD)				
82	21	Engine run time for Auxiliary Emissions Control Device (AECD)				
83	5	NOx sensor				
84		Manifold surface temperature				
85		NOx reagent system				
86		Particulate matter (PM) sensor				
87		Intake manifold absolute pressure				
AO	4	PIDs supported [A1 - C0]				Bit encoded [A7D0] == [PID \$A1PID \$C0] See below
CO	4	PIDs supported [C1 - E0]				Bit encoded [A7D0] == [PID \$C1PID \$E0] See below
C3	?	?	?	?	?	Returns numerous data, including Drive Condition ID and Engine Speed*
C4	?	?	?	?	?	B5 is Engine Idle Request B6 is Engine Stop Request*
PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>

### Mode 02

Mode 02 accepts the same PIDs as mode 01, with the same meaning, but information given is from when the freeze frame was created.

You have to send the frame number in the data section of the message.

PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>
02	2	DTC that caused freeze frame to be stored.				BCD encoded. Decoded as in mode 3

# Mode 03

PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>
N/A	n*6	Request trouble codes				3 codes per message frame. See below

# Mode 04

PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>
N/A	0	Clear trouble codes / Malfunction indicator lamp (MIL) / Check engine light				Clears all stored trouble codes and turns the MIL off.

# Mode 05

PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>
0100		OBD Monitor IDs supported (\$01 - \$20)				
0101		02 Sensor Monitor Bank 1 Sensor 1	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage

2016/2/2	OBD-II PIDs - V	Vikipedia, the	free encyclo	pedia	
0102	02 Sensor Monitor Bank 1 Sensor 2	0.00	1.275	Volts	0.005 Rich to lean sensor threshold voltage
0103	02 Sensor Monitor Bank 1 Sensor 3	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
0104	02 Sensor Monitor Bank 1 Sensor 4	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
0105	02 Sensor Monitor Bank 2 Sensor 1	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
0106	02 Sensor Monitor Bank 2 Sensor 2	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
0107	02 Sensor Monitor Bank 2 Sensor 3	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
0108	02 Sensor Monitor Bank 2 Sensor	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
0109	02 Sensor Monitor Bank 3 Sensor	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
010A	02 Sensor Monitor Bank 3 Sensor 2	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
010B	02 Sensor Monitor Bank 3 Sensor 3	0.00	1.275	Volts	0.005 Rich to lean sensor threshold voltage
010C	02 Sensor Monitor Bank 3 Sensor 4	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
010D	02 Sensor Monitor Bank 4 Sensor	0.00	1. 275	Volts	0.005 Rich to lean sensor threshold voltage
010E	02 Sensor Monitor Bank 4 Sensor 2	0.00	1.275	Volts	0.005 Rich to lean sensor threshold voltage
010F	02 Sensor Monitor Bank 4 Sensor 3	0.00	1.275	Volts	0.005 Rich to lean sensor threshold voltage
0110	02 Sensor Monitor Bank 4 Sensor 4	0.00	1.275	Volts	0.005 Rich to lean sensor threshold voltage
0201	02 Sensor Monitor Bank 1 Sensor 1	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
0202	02 Sensor Monitor Bank 1 Sensor 2	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
0203	02 Sensor Monitor Bank 1 Sensor 3	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
0204	02 Sensor Monitor Bank 1 Sensor 4	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
0205	02 Sensor Monitor Bank 2 Sensor	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
0206	02 Sensor Monitor Bank 2 Sensor 2	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
0207	02 Sensor Monitor Bank 2 Sensor 3	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
0208	02 Sensor Monitor Bank 2 Sensor 4	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
0209	02 Sensor Monitor Bank 3 Sensor 1	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
020A	02 Sensor Monitor Bank 3 Sensor 2	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
020B	02 Sensor Monitor Bank 3 Sensor 3	0.00	1. 275	Volts	0.005 Lean to Rich sensor threshold voltage
020C	02 Sensor Monitor Bank 3 Sensor 4	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
020D	02 Sensor Monitor Bank 4 Sensor	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
020E	02 Sensor Monitor Bank 4 Sensor 2	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage
020F	02 Sensor Monitor Bank 4 Sensor 3	0.00	1.275	Volts	0.005 Lean to Rich sensor threshold voltage

0210		02 Sensor Monitor Bank 4 Sensor 4	0.00	1. 275	L VOLTS	0.005 Lean to Rich sensor threshold voltage
PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>

### Mode 09

PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>
00	4	Mode 9 supported PIDs (01 to 20)				Bit encoded. [A7D0] = [PID \$01PID \$20] See below
01	1	VIN Message Count in PID 02. Only for ISO 9141-2, ISO 14230-4 and SAE J1850.				Usually value will be 5.
02	17-20	Vehicle Identification Number (VIN)				17-char VIN, ASCII-encoded and left-padded with null chars (0x00) if needed to.
03	1	Calibration ID message count for PID 04. Only for ISO 9141-2, ISO 14230-4 and SAE J1850.				It will be a multiple of 4 (4 messages are needed for each ID).
04	16	Calibration ID				Up to 16 ASCII chars. Data bytes not used will be reported as null bytes (0x00).
05	1	Calibration verification numbers (CVN) message count for PID 06. Only for ISO 9141- 2, ISO 14230-4 and SAE J1850.				
06	4	Calibration Verification Numbers (CVN)				Raw data left-padded with null characters (0x00). Usually displayed as hex string.
07	1	In-use performance tracking message count for PID 08 and 0B. Only for ISO 9141-2, ISO 14230-4 and SAE J1850.	8	10		8 if sixteen (16) values are required to be reported, 9 if eighteen (18) values are required to be reported, and 10 if twenty (20) values are required to be reported (one message reports two values, each one consisting in two bytes).
08	4	In-use performance tracking for spark ignition vehicles				4 or 5 messages, each one containing 4 bytes (two values). See below
09	1	ECU name message count for PID OA				
OA	20	ECU name				ASCII-coded. Right-padded with null chars (0x00).
ОВ	4	In-use performance tracking for compression ignition vehicles				5 messages, each one containing 4 bytes (two values). See below
PID (hex)	Data bytes returned	Description	Min value	Max value	Units	Formula <sup>[a]</sup>

a. In the formula column, letters A, B, C, etc. represent the decimal equivalent of the first, second, third, etc. bytes of data. Where a (?) appears, contradictory or incomplete information was available.

### Bitwise encoded PIDs

Some of the PIDs in the above table cannot be explained with a simple formula. A more elaborate explanation of these data is provided here:

### Mode 1 PID 00

A request for this PID returns 4 bytes of data. Each bit, from MSB to LSB, represents one of the next 32 PIDs and is giving information about if it is supported.

For example, if the car response is BE1FA813, it can be decoded like this:

Hexadecimal			В			Е					1			I	7			A	1			8					1				3	
Binary	1	0	1	1	1	1	1	0	0	0	0	1	1	1	1	1	1	0	1	0	1	0	0	0	0	0	0	1	0	0	1	1
Supported?	Yes	No	Yes	Yes	Yes	Yes	Yes	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	No	No	No	No	No	No	Yes	No	No	Yes	Yes
PID number	01	02	03	04	05	06	07	08	09	0A	ОВ	0C	OD	0E	0F	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F	20

So, supported PIDs are: 01, 03, 04, 05, 06, 07, 00, 00, 00, 00, 11, 13, 15, 10, 15 and 20

Mode 1 PID 01

A request for this PID returns 4 bytes of data, labeled A B C and D.

The first byte(A) contains two pieces of information. Bit A7 (MSB of byte A, the first byte) indicates whether or not the MIL (check engine light) is illuminated. Bits A6 through A0 represent the number of diagnostic trouble codes currently flagged in the ECU.

The second, third, and fourth bytes (B, C and D) give information about the availability and completeness of certain onboard tests. Note that test availability is indicated by set (1) bit and completeness is indicated by reset (0) bit.

Bit	Name	Definition
A7	MIL	Off or On, indicates if the CEL/MIL is on (or should be on)
A6-A0	DTC_CNT	Number of confirmed emissions-related DTCs available for display.
В7	RESERVED	Reserved (should be 0)
В3	NO NAME	<pre>0 = Spark ignition monitors supported 1 = Compression ignition monitors supported</pre>

Here are the common bit B definitions, they are test based.

	Test available	Test incomplete
Misfire	В0	B4
Fuel System	B1	B5
Components	B2	В6

The third and fourth bytes are to be interpreted differently depending on if the engine is spark ignition or compression ignition. In the second (B) byte, bit 3 indicates how to interpret the C and D bytes, with 0 being spark and 1 (set) being compression.

The bytes C and D for spark ignition monitors:

	Test available	Test incomplete
Catalyst	CO	DO
Heated Catalyst	C1	D1
Evaporative System	C2	D2
Secondary Air System	C3	D3
A/C Refrigerant	C4	D4
Oxygen Sensor	C5	D5
Oxygen Sensor Heater	C6	D6
EGR System	C7	D7

And the bytes C and D for compression ignition monitors:

	Test available	Test incomplete
NMHC Catalyst <sup>[a]</sup>	CO	DO
NOx/SCR Monitor	C1	D1
Boost Pressure	C3	D3
Exhaust Gas Sensor	C5	D5
PM filter monitoring	C6	D6
EGR and/or VVT System	C7	D7

a. NMHC may stand for Non-Methane HydroCarbons, but J1979 does not enlighten us. The translation would be the ammonia sensor in the SCR catalyst.

Mode 1 PID 41

A request for this PID returns 4 bytes of data. The first byte is always zero. The second, third, and fourth bytes give information about the availability and completeness of certain on-board tests. Note that test availability is represented by a set (1) bit and completeness is represented by a reset (0) bit:

	Test enabled	Test incomplete
Reserved	В3	В7
Components	B2	В6
Fuel System	B1	B5
Misfire	ВО	B4
EGR System	C7	D7
Oxygen Sensor Heater	C6	D6
Oxygen Sensor	C5	D5
A/C Refrigerant	C4	D4
Secondary Air System	C3	D3
Evaporative System	C2	D2
Heated Catalyst	C1	D1
Catalyst	C0	DO

Mode 1 PID 78

A request for this PID will return 9 bytes of data. The first byte is a bit encoded field indicating which EGT sensors are supported:

Byte	Description
A	Supported EGT sensors
В-С	Temperature read by EGT11
D-E	Temperature read by EGT12
F-G	Temperature read by EGT13
H-I	Temperature read by EGT14

The first byte is bit-encoded as follows:

Bit	Description
A7-A4	Reserved
А3	EGT bank 1, sensor 4 Supported?
A2	EGT bank 1, sensor 3 Supported?
A1	EGT bank 1, sensor 2 Supported?
A0	EGT bank 1, sensor 1 Supported?

The remaining bytes are 16 bit integers indicating the temperature in degrees Celsius in the range -40 to 6513.5 (scale 0.1), using the usual  $(A \times 256 + B)/10 - 40$  formula (MSB is A, LSB is B). Only values for which the corresponding sensor is supported are meaningful.

The same structure applies to PID 79, but values are for sensors of bank 2.

Mode 3 (no PID required)

A request for this mode returns a list of the DTCs that have been set. The list is encapsulated using the ISO 15765-2 protocol.

If there are two or fewer DTCs (4 bytes) they are returned in an ISO-TP Single Frame (SF). Three or more DTCs in the list are reported in multiple frames, with the exact count of frames dependent on the communication type and addressing details.

Each trouble code requires 2 bytes to describe. The text description of a trouble code may be decoded as follows. The first character in the trouble code is determined by the first two bits in the first byte:

#### 2016/2/2

A7-A6	First DTC character
00	P - Powertrain
01	c - Chassis
10	B - Body
11	U - Network

The two following digits are encoded as 2 bits. The second character in the DTC is a number defined by the following table:

A5-A4	Second	DTC	character
00	0		
01	1		
10	2		
11	3		

The third character in the DTC is a number defined by

A3-A0	Third	DTC	character
0000	0		
0001	1		
0010	2		
0011	3		
0100	4		
0101	5		
0110	6		
0111	7		
1000	8		
1001	9		
1010	A		
1011	В		
1100	С		
1101	D		
1110	Е		
1111	F		

The fourth and fifth characters are defined in the same way as the third, but using bits B7-B4 and B3-B0. The resulting five-character code should look something like "U0158" and can be looked up in a table of OBD-II DTCs. Hexadecimal characters (0-9, A-F), while relatively rare, are allowed in the last 3 positions of the code itself.

Mode 9 PID 08

It provides information about track in-use performance for catalyst banks, oxygen sensor banks, evaporative leak detection systems, EGR systems and secondary air system.

The numerator for each component or system tracks the number of times that all conditions necessary for a specific monitor to detect a malfunction have been encountered. The denominator for each component or system tracks the number of times that the vehicle has been operated in the specified conditions.

The count of data items should be reported at the beginning (the first byte).

All data items of the In-use Performance Tracking record consist of two (2) bytes and are reported in this order (each message contains two items, hence the message length is 4).

	• •				
Mnemonic	Description				
OBDCOND	OBD Monitoring Conditions Encountered Counts				
IGNCNTR	Ignition Counter				
CATCOMP1	Catalyst Monitor Completion Counts Bank 1				
CATCOND1	Catalyst Monitor Conditions Encountered Counts Bank 1				
CATCOMP2	Catalyst Monitor Completion Counts Bank 2				
CATCOND2	Catalyst Monitor Conditions Encountered Counts Bank 2				
02SCOMP1	O2 Sensor Monitor Completion Counts Bank 1				
02SCOND1	O2 Sensor Monitor Conditions Encountered Counts Bank 1				
02SCOMP2	02 Sensor Monitor Completion Counts Bank 2				
02SCOND2	O2 Sensor Monitor Conditions Encountered Counts Bank 2				
EGRCOMP	EGR Monitor Completion Condition Counts				
EGRCOND	EGR Monitor Conditions Encountered Counts				
AIRCOMP	AIR Monitor Completion Condition Counts (Secondary Air)				
AIRCOND	AIR Monitor Conditions Encountered Counts (Secondary Air)				
EVAPCOMP	EVAP Monitor Completion Condition Counts				
EVAPCOND	EVAP Monitor Conditions Encountered Counts				
SO2SCOMP1	Secondary O2 Sensor Monitor Completion Counts Bank 1				
S02SCOND1	Secondary O2 Sensor Monitor Conditions Encountered Counts Bank 1				
S02SC0MP2	Secondary O2 Sensor Monitor Completion Counts Bank 2				
S02SCOND2	Secondary O2 Sensor Monitor Conditions Encountered Counts Bank 2				

### Mode 9 PID 0B

It provides information about track in-use performance for NMHC catalyst, NOx catalyst monitor, NOx adsorber monitor, PM filter monitor, exhaust gas sensor monitor, EGR/ VVT monitor, boost pressure monitor and fuel system monitor.

All data items consist of two (2) bytes and are reported in this order (each message contains two items, hence message length is 4):

OBDCOND OBD Monitoring Conditions	scription s Encountered Counts
0	s Encountered Counts
TONONTO I C	
IGNCNTR   Ignition Counter	
HCCATCOMP NMHC Catalyst Monitor Cor	mpletion Condition Counts
HCCATCOND NMHC Catalyst Monitor Con	nditions Encountered Counts
NCATCOMP   NOx/SCR Catalyst Monitor	Completion Condition Counts
NCATCOND   NOx/SCR Catalyst Monitor	Conditions Encountered Counts
NADSCOMP NOx Adsorber Monitor Comp	pletion Condition Counts
NADSCOND NOx Adsorber Monitor Cond	ditions Encountered Counts
PMCOMP PM Filter Monitor Complete	tion Condition Counts
PMCOND PM Filter Monitor Condition	ions Encountered Counts
EGSCOMP Exhaust Gas Sensor Monito	or Completion Condition Counts
EGSCOND Exhaust Gas Sensor Monito	or Conditions Encountered Counts
EGRCOMP   EGR and/or VVT Monitor Co	ompletion Condition Counts
EGRCOND   EGR and/or VVT Monitor Co	onditions Encountered Counts
BPCOMP Boost Pressure Monitor Co	ompletion Condition Counts
BPCOND Boost Pressure Monitor Co	onditions Encountered Counts
FUELCOMP Fuel Monitor Completion (	Condition Counts
FUELCOND Fuel Monitor Conditions I	Encountered Counts

# Enumerated PIDs

Some PIDs are to be interpreted specially, and aren't necessarily exactly bitwise encoded, or in any scale. The values for these PIDs are enumerated.

Mode 1 PID 03

A request for this PID returns 2 bytes of data. The first byte describes fuel system #1.

Value	Description				
1	pen loop due to insufficient engine temperature				
2	losed loop, using oxygen sensor feedback to determine fuel mix				
4	Open loop due to engine load OR fuel cut due to deceleration				
8	Open loop due to system failure				
16	Closed loop, using at least one oxygen sensor but there is a fault in the feedback system				

Any other value is an invalid response. There can only be one bit set at most.

The second byte describes fuel system #2 (if it exists) and is encoded identically to the first byte.

Mode 1 PID 12

A request for this PID returns a single byte of data which describes the secondary air status.

Value	Description
1	Upstream
2	Downstream of catalytic converter
4	From the outside atmosphere or off
8	Pump commanded on for diagnostics

Any other value is an invalid response. There can only be one bit set at most.

Mode 1 PID 1C

A request for this PID returns a single byte of data which describes which OBD standards this ECU was designed to comply with. The different values the data byte can hold are shown below, next to what they mean:

2016/2/2	OBD-II PIDs - Wikipedia, the t
Value	Description
1	OBD-II as defined by the CARB
2	OBD as defined by the EPA
3	OBD and OBD-II
4	OBD-I
5	Not OBD compliant
6	EOBD (Europe)
7	EOBD and OBD-II
8	EOBD and OBD
9	EOBD, OBD and OBD II
10	JOBD (Japan)
11	JOBD and OBD II
12	JOBD and EOBD
13	JOBD, EOBD, and OBD II
14	Reserved
15	Reserved
16	Reserved
17	Engine Manufacturer Diagnostics (EMD)
18	Engine Manufacturer Diagnostics Enhanced (EMD+)
19	Heavy Duty On-Board Diagnostics (Child/Partial) (HD OBD-C)
20	Heavy Duty On-Board Diagnostics (HD OBD)
21	World Wide Harmonized OBD (WWH OBD)
22	Reserved
23	Heavy Duty Euro OBD Stage I without NOx control (HD EOBD-I)
24	Heavy Duty Euro OBD Stage I with NOx control (HD EOBD-I N)
25	Heavy Duty Euro OBD Stage II without NOx control (HD EOBD-II)
26	Heavy Duty Euro OBD Stage II with NOx control (HD EOBD-II N)
27	Reserved
28	Brazil OBD Phase 1 (OBDBr-1)
29	Brazil OBD Phase 2 (OBDBr-2)
30	Korean OBD (KOBD)
31	India OBD I (IOBD I)
32	India OBD II (IOBD II)
33	Heavy Duty Euro OBD Stage VI (HD EOBD-IV)
34-250	Reserved
251-255	Not available for assignment (SAE J1939 special meaning)

# Fuel Type Coding

Mode 1 PID 51 returns a value from an enumerated list giving the fuel type of the vehicle. The fuel type is returned as a single byte, and the value is given by the following table:

2010/2/2	ODD-II I ID3 - Winpedia, the IIV
Value	Description
00	Not available
01	Gasoline
02	Methanol
03	Ethanol
04	Diesel
05	LPG
06	CNG
07	Propane
08	Electric
09	Bifuel running Gasoline
OA	Bifuel running Methanol
OB	Bifuel running Ethanol
OC	Bifuel running LPG
OD	Bifuel running CNG
OE	Bifuel running Propane
0F	Bifuel running ElectricityNO LONGER IN USE
10	Bifuel running electric and combustion engine-NO LONGER IN USE
11	Hybrid gasolineNO LONGER IN USE
12	Hybrid EthanolNO LONGER IN USE
13	Hybrid DieselNO LONGER IN USE
14	Hybrid ElectricNO LONGER IN USE
15	Hybrid running electric and combustion engineNO LONGER IN USE
16	Hybrid RegenerativeNO LONGER IN USE
17	Bifuel running dieselNO LONGER IN USE

Any other value is reserved by ISO/SAE. There are currently no definitions for flexible-fuel vehicle.

### Non-standard PIDs

The majority of all OBD-II PIDs in use are non-standard. For most modern vehicles, there are many more functions supported on the OBD-II interface than are covered by the standard PIDs, and there is relatively minor overlap between vehicle manufacturers for these non-standard PIDs.

There is very limited information available in the public domain for non-standard PIDs. The primary source of information on non-standard PIDs across different manufacturers is maintained by the US-based Equipment and Tool Institute and only available to members. The price of ETI membership for access to scan codes varies based on company size defined by annual sales of automotive tools and equipment in North America:

Annual Sales in North America	Annual Dues
Under \$10,000,000	\$5,000
\$10,000,000 - \$50,000,000	\$7,500
Greater than \$50,000,000	\$10,000

However, even ETI membership will not provide full documentation for non-standard PIDs. ETI state: [3][4]

Some OEMs refuse to use ETI as a one-stop source of scan tool information. They prefer to do business with each tool company separately. These companies also require that you enter into a contract with them. The charges vary but here is a snapshot as of April 13th, 2015 of the per year charges:

GM	\$50,000
Honda	\$5,000
Suzuki	\$1,000
BMW	\$25,500 plus \$2,000 per update. Updates occur annually.

# CAN (11-bit) bus format

The PID query and response occurs on the vehicle's CAN bus. Standard OBD requests and responses use functional addresses. The diagnostic reader initiates a query using CAN ID \$7DF, which acts as a broadcast address, and accepts responses from any ID in the range \$7E8 to \$7EF. ECUs that can respond to OBD queries listen both to the functional broadcast ID of \$7DF and one assigned ID in the range \$7EO to \$7E7. Their response has an ID of their assigned ID plus 8 e.g. \$7E8 through \$7EF.

This approach allows up to eight ECUs, each independently responding to OBD queries. The diagnostic reader can use the ID in the ECU response frame to continue communication with a specific ECU. In particular, multi-frame communication requires a response to the specific ECU ID rather than to ID \$7DF.

CAN bus may also be used for communication beyond the standard OBD messages. Physical addressing uses particular CAN IDs for specific modules (e.g., 720 for the instrument cluster in Fords) with proprietary frame payloads.

### Query

The functional PID query is sent to the vehicle on the CAN bus at ID 7DFh, using 8 data bytes. The bytes are:

	Byte							
PID Type	0 1		2	3	4	5	6	7
SAE additional		Mode 01 = show current data; 02 = freeze frame; etc.	PID code (e.g.: 05 = Engine coolant temperature)  not used (may be 55h)					
	Number of additional data bytes: 3	Custom mode: (e.g.: 22 = enhanced data)	PID code (e.g.: 4980h) not used (may be 00h o			or 55h	)	

# Response

The vehicle responds to the PID query on the CAN bus with message IDs that depend on which module responded. Typically the engine or main ECU responds at ID 7E8h. Other modules, like the hybrid controller or battery controller in a Prius, respond at 07E9h, 07E8h, 07E8h, etc. These are 8h higher than the physical address the module responds to. Even though the number of bytes in the returned value is variable, the message uses 8 data bytes regardless (CAN bus protocol form Frameformat with 8 data bytes). The bytes are:

		Byte						
PID Type	0	1	2	3	4	5	6	7
SAE Standard 7E8h, 7E9h, 7EAh, etc.	Number of additional data bytes: 3 to 6	Custom mode Same as query, except that 40h is added to the mode value. So: 41h = show current data; 42h = freeze frame; etc.	PID code (e.g.: 05 = Engine coolant temperature)	value of the specified parameter, byte 0	value, byte 1 (optional)	value, byte 2 (optional)	value, byte 3 (optional)	not used (may be 00h or 55h)
Vehicle specific 7E8h, or 8h + physical ID of module.	Number of additional data bytes: 4to 7	Custom mode: same as query, except that 40h is added to the mode value. (e.g.: 62h = response to mode 22h request)	PID code (e.g.: 4980h)		value of the specified parameter, byte 0	value, byte 1 (optional)	value, byte 2 (optional)	value, byte 3 (optional)
Vehicle specific 7E8h, or 8h + physical ID of module.	Number of additional data bytes: 3	7Fh this a general response usually indicating the module doesn't recognize the request.	Custom mode: (e.g.: 22h = enhanced diagnostic data by PID, 21h = enhanced data by offset)  and used (may be 00h)					

### See also

■ On-board diagnostics

- Engine control unit
- ELM327 very common chip used in OBD-II interfaces
- OBDuino on board computer using Arduino connected to OBD-II port

### References

- 1. "Basic Information | On-Board Diagnostics (OBD)". US EPA. 16 March 2015. Retrieved 24 June 2015.
- 2. "Escape PHEV TechInfo PIDs". Electric Auto Association Plug in Hybrid Electric Vehicle. Retrieved 11 December 2013.
- 3. "ETI Full Membership FAQ". The Equipment and Tool Institute. Retrieved 29 November 2013. showing cost of access to OBD-II PID documentation
- 4. "Special OEM License Requirements". The Equipment and Tool Institute. Retrieved 13 April 2015.

### External links

- OBD-II Error Codes Definition (http://www.autocodes.com/), description and repair information for most makes of vehicles.
- OBD II Error Codes Definition and Lookup (http://www.obd-codes.com), including manufacturer-specific codes.
- Generic/Manufacturer OBD2 Codes and Their Meanings (http://www.totalcardiagnostics.com/support/index.php? \_m=knowledgebase&\_a=viewarticle&kbarticleid=23)
- Engine Trouble Codes Meanings (http://www.enginetroublecode.com/), Engine trouble code look-up and meanings.
- Directive 98/69/EC of the European Parliament and of the Council of 13 October 1998 (http://eurlex.europa.eu/LexUriServ/LexUriServ.do?uri=CONSLEG:1998L0069:19981228:EN:PDF).
- CAN Bus Vehicles (http://www.auterraweb.com/aboutcan.html) Partial list of 2003-2007 vehicles which support the OBD-II CAN bus standard.
- Fault Code Examples (http://kbmsystems.net/files/Engine%20ECU%20Fault%20Code%20Reading%20with%20OBDKey.pdf) Sample fault code data read using the OBDKey Bluetooth, OBDKey USB and OBDKey WLAN vehicle interface units.

Retrieved from "https://en.wikipedia.org/w/index.php?title=OBD-II PIDs&oldid=699100860"

Categories: Technology-related lists | Automotive technologies | Electronics lists

- This page was last modified on 10 January 2016, at 06:56.
- Text is available under the Creative Commons Attribution-ShareAlike License; additional terms may apply. By using this site, you agree to the Terms of Use and Privacy Policy. Wikipedia® is a registered trademark of the Wikimedia Foundation, Inc., a non-profit organization.