

A

A

B




B

C


C

D

D



When flashing programs to MCU, this jumper MUST BE disconnected. The MCU should receive its power from the SWD device (another RPi Pico, Picoprobe).



Sheet: /Power/
File: power.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 4/8

A

A

B



B

C

C

D

D



Sheet: /Pulse IO/
File: pulse-io.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 5/8

A

A

B


B

C

C

D

D




Sheet: /MIDI In/
File: midi-in.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 6/8





Sheet: /MCU/
File: mcu.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 7/8





1 2 3 4 5 6

A

A

B



B

C

C

D

D



Sheet: /Pots/
File: pots.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 10/8

1 2 3 4 5 6