



EMBEDDED SYSTEM DESIGN MEMORY

Doan Duy, Ph. D.

Email: duyd@uit.edu.vn



Objective and Content

Overview of memory

Memory Organization

Example



- Overview of memory
- Memory Organization

Example



Role of memory in embedded systems

Traditional roles: Storage and Communication for Programs

In embedded systems:

- Communication with Sensors and Actuators
- Often much more constrained than in general-purpose computing: Size, power, reliability, etc.

→ Can be important for programmers to understand these constraints?



Practical Issues

- Types of memory
 - volatile vs. non-volatile, SRAM vs. DRAM
- Memory maps
 - Harvard architecture
 - Memory-mapped I/O
- Memory organization
 - statically allocated
 - stacks
 - heaps (allocation, fragmentation, garbage collection)
- The memory model of C
- Memory hierarchies
 - scratchpads, caches, virtual memory)
- Memory protection
 - segmented spaces



Memory mapping

Memory Map of an ARM CortexTM -M3 architecture

peripherals G F private peripheral bus external devices

0xFFFFFFFF

0xE0000000 0xDFFFFFFF

0xA0000000 0x9FFFFFFF

Defines the mapping of addresses physical to memory.

C

E

(DRAM)

peripherals

(memory-mapped registers)

data memory

(SRAM)

data memory

(memory mapped)

0x60000000 0x5FFFFFFF

0x40000000 0x3FFFFFFF

0x20000000 0x1FFFFFF

0x00000000

program memory (flash)

■Note that this does not define how much physical memory there is!

10/15/2021

Copyrights 202


GB

GB

GB



Questions for understanding



• Why is it called an 8-bit microcontroller?

- What is the difference between an 8-bit microcontroller and a 32-bit microcontroller?
- Why use volatile memory? Why not always use non-volatile memory?



Objective and Content

Overview of memory

Memory Organization

Example



Memory organization for Programs

- ☐ Statically-allocated memory
 - Compiler chooses the address at which to store a variable.
- ☐ Stack
 - Dynamically allocated memory with a Last-in, First-out (LIFO) strategy
- Heap
 - Dynamically allocated memory



Memory allocation (1)

What is meant by the following C code:

```
char x;
void foo(void) {
    x = 0x20;
    ...
}
```

An 8-bit quantity (hex 0x20) is stored at an address in statically allocated memory in internal RAM determined by the compiler.



Memory allocation (2)

■What is meant by the following C code:

```
char *x;
void foo(void) {
    x = 0x20;
    ...
}
```

An 16-bit quantity (hex 0x0020) is stored at an address in statically allocated memory in internal RAM determined by the compiler.



Memory allocation (3)

■What is meant by the following C code:

```
char *x, y;
void foo(void) {
    x = 0x20;
    y = *x;
    ...
}
```

The 8-bit quantity in the I/O register at location 0x20 is loaded into y, which is at a location in internal SRAM determined by the compiler.



Memory allocation (4)

Where are x, y, z in memory?

```
char foo() {
 char *x, y;
 x = 0x20;
 y = *x;
 return y;
char z;
int main(void) {
 z = foo();
```

x occupies 2 bytes on the stack, y occupies 1 byte on the stack, and z occupies 1 byte in static memory.



Memory allocation (5)

■What is meant by the following C code:

```
void foo(void) {
  char *x, y;
  x = &y;
  *x = 0x20;
  ...
}
```

16 bits for x and 8 bits for y are allocated on the stack, then x is loaded with the address of y, and then y is loaded with the 8-bit quantity 0x20.



Memory allocation (6)

What goes into z in the following program:

```
char foo() {
      char y;
      uint16_t x;
      x = 0x20;
      y = *x;
      return y;
char z;
int main(void) {
      z = foo();
```

z is loaded with the 8-bit quantity in the I/O register at location 0x20.



Dynamically-Allocated Memory The Heap

- An operating system typically offers a way to dynamically allocate memory on a "heap".
- Memory management (malloc() and free()) can lead to many problems with embedded systems:
 - Memory leaks (allocated memory is never freed)
 - Memory fragmentation (allocatable pieces get smaller)
- Automatic techniques ("garbage collection") often require stopping everything and reorganizing the allocated memory. This is deadly for real-time programs.




Memory Hierarchies

- **Cache:**
 - A subset of memory addresses is mapped to SRAM
 - Accessing an address not in SRAM results in *cache miss*
 - A miss is handled by copying contents of DRAM to SRAM
- ☐ Scratchpad:
 - SRAM and DRAM occupy disjoint regions of memory space
 - Software manages what is stored where
- Segmentation
 - Logical addresses are mapped to a subset of physical addresses
 - Permissions regulate which tasks can access which memory




Memory Hierarchies



Here, the cache or scratchpad, main memory, and disk or flash share the same address space.



Memory Hierarchies



- Here, each distinct piece of memory hardware has its own segment of the address space.
- This requires more careful software design, but gives more direct control over timing.



Objective and Content


Overview of memory


Memory Organization

Example



Berkeley Microblaze Personality Memory Map







Understanding memory architectures is essential to programming embedded systems!





Q&A

