```
#include<avr/io.h>
int main()
{
    DDRD&=!(1<<PD1); //PD2 - input pin, sensor signal
    DDRD |=(1<<PD2); // PD2 - output pin,piezobuzzer
    while(1)
    {
        if(PIND&(1<<PD1)) // if input to port D pin 1 is high ie.if(PD1==1)
            PORTD&=!(1<<PD2);//buzzer on,PD2=0
        else
            PORTD |=(1<<PD2);//buzzer off, PD2=1
    }
}</pre>
```