Assembly TOP of Arduino. V111 Fixed 5V C5 J7 J11 C16 **J**3 E | C10 R15 C12 J5 D4 C13 D1 R1 4 **J**6 D2 R2 R3 D3 C25 **R6** R14 C3 R21 R24 80 R25 U1 030 S Y1 Y2 5 C31 SW2 R 7 U5 C18 C17 C33 R27 C4 R23 С9 R18 C27 28 C11 2 Zí R9 82 **J2** R10 **R28 U4** Z2 U2 U6 C15 C1 R22 **R26** R17 C20 C21 C32 Ξ C19 C26 RIS F2 C29 C23 F3 C22 C24 SW1 **C2** J9